

---

Title:

DOMUS, USER'S GUIDE, Part 1, Version 3.

---

 **REGNECENTRALEN**

RC SYSTEM LIBRARY: FALKONERALLE 1 DK-2000 COPENHAGEN F

---

RCSL No: 43-GL8375

Edition: January 1979

Author: Knud Henningsen

---

Keywords:

DOMUS, MUS, Operating System, Loader, Disc.

---

Abstract:

This manual describes the disc operating system DOMUS for the RC 3600 line of computers.

(80 printed pages)

---

Copyright A/S Regnecentralen, 1978  
Printed by A/S Regnecentralen, Copenhagen

Users of this manual are cautioned that the specifications contained herein are subject to change by RC at any time without prior notice. RC is not responsible for typographical or arithmetic errors which may appear in this manual and shall not be responsible for any damages caused by reliance on any of the materials presented.

---

CONTENTS	PAGE
1. INTRODUCTION.....	1
1.1 Terminology.....	2
1.2 Files.....	5
1.3 Drives and Subcatalogs - Load from.....	6
1.4 The Operating System Process S.....	7
1.5 Core Storage Management.....	8
1.5.1 Core Item.....	8
1.5.2 Core Allocation Strategy.....	9
1.5.3 Core Item Classification.....	10
1.5.4 Process Hierachy.....	11
2. WORKING CYCLE OF S.....	12
2.1 The S mode.....	12
2.2 Mode Shifts:.....	12
2.3 Events.....	13
2.3.1 Console Command.....	13
2.3.2 Internal Command.....	13
2.3.3 Internal Request.....	13
2.4 The Operating Process.....	14
3. THE S COMMAND LANGUAGE.....	15
3.1 Basic Elements.....	15
3.2 Numbers.....	15
3.3 Texts.....	16
3.4 Names.....	16
3.5 Items.....	17
3.6 S-Commands.....	17
3.7 Comments, Blanks, Blind characters.....	18

4.	S-FUNCTIONS.....	19
4.1	BEGIN.....	21
4.2	BOOT.....	23
4.3	BREAK.....	24
4.4	CLEAN.....	25
4.5	CLEAR.....	26
4.6	CONNECT.....	27
4.7	DRIVE.....	28
4.8	END.....	30
4.9	FREE.....	32
4.10	GET.....	33
4.11	INIT.....	36
4.12	INT.....	37
4.13	KILL.....	39
4.14	LIST.....	40
4.15	LOAD.....	43
4.16	RELEASE.....	46
4.17	START.....	47
4.18	STOP.....	48
4.19	Utility program load.....	49
4.20	WATT.....	51

## APPENDIXES

A.	CHARACTER SET USED BY DOMUS.....	A-1
B.	SURVEY OF S-COMMANDS.....	B-1
C.	SURVEY OF ERROR MESSAGES AND NUMBERS.....	C-1
D.	SYSTEM ERROR MESSAGES.....	D-1
E.	SURVEY OF CORE ADMINISTRATION.....	E-1
F.	SYSTEM BOOTSTRAP.....	F-1
G.	SYSTEM GENERATION.....	G-1
H.	REFERENCES.....	H-1

1. INTRODUCTION.

1.

The Disc Operating Multiprogramming Utility System, DOMUS, can be used with any RC3600 computer of 32 Kb or larger memory, together with any combination of discs and an operator device, e.g. a teletype.

The main features of DOMUS are:

- Parallel processing including interprocess communication and interrupt processing.
- A strong framework for i/o processing, both on character level and on record oriented level.
- The operating system takes care of core storage allocation, program load from disc files, process creation and removal.
- The operating system itself has only a minor part resident in core, the major part residing on a disc. Also user programs can use this facility.
- Easy operation of the operating system by a human operator or by user programs sending internal commands to the operating system.
- Support for the MUSIL TEXT EDITOR and the MUSIL COMPILER and other utilities, and support for driver programs for all hardware modules of the RC3600 system.

- Address An address may be a word address, which is a 16 bit unsigned integer, corresponding to a physical address in core store. Or it may be a byteaddress, which is a word address left shifted one and with a one added in bit 15 if the byte addressed within the word is to the right. Byteaddressing is only possible in addressing low core storage area (address <64KB).
- Bit A computer word consists of 16 bits, numbered from left to right:  
B0, B1, B2,.....B15.
- Byte A computer word is regarded as two 8 bit bytes. The left one bit0 to bit7 has a even address and the right one bit8 to bit15 an odd address.
- Character A character is a byte. The common alphabet within the system is the ASCII alphabet see appendix A.
- Text A text is a sequence of characters. Starting at a byte address and containing in a left to right packing. A text is terminated by a Null character with byte value zero.
- Descriptor A collection of information, which describes an object, is called a descriptor. Descriptors are found as part of items and as part of zones.
- Item An item is a core area, which is headed by a descriptor, the first part of which usually has a standard layout. This ensures that an item always may be in some chain and possibly also in

a queue. The first words of an item contains the fields:

ident: nitem/xitem ident  
 next: next item in a queue  
 prev: previous item in a queue  
 chain: next item in a chain  
 size: the size of the core area of item  
 name: (3words) A text identifying the item.

Field

A field is a displacement, which identifies a piece of information within a descriptor. Some important fields are predefined in the system assembler, and/or in the musil compiler.

Chain

(linked lenear list). A chain consists of a chain head and a number of chain elements. The head and each element point at the next item in the chain, the last element equals zero.

Queue

(doubly linked cyclical linear list). A queue consists of one or more queue elements. One of the elements is the queue head. A queue element consists of two consecutive words pointing at the next element in the queue and the previous element in the queue respectively.

When a queue is empty the head points at itself. When an element is not in a queue it normally points at itself.

Length

The term length is used to express the number of bytes contained in some core area.

Size

The term size is used to express the number of words contained in some core area.

<u>Program</u>	A collection of instructions and data which may be executed or accessed by one or more processes.
<u>Process</u>	A sequential execution of programs under control of the monitor. All information about a process is collected in a process descriptor.
<u>Monitor</u>	The nucleus of the system which implements multiprogramming, i.e. a parallel execution of several processes on a single processor.
<u>Device</u>	A collection of units which can receive data from the processor or transmit data to the processor, often in parallel with the execution of computer instructions.
<u>Driver</u>	A process executing a driver program in order to central i/o to a device.
<u>Disc</u>	Any random access storage unit connected to the computer.
<u>Drive</u>	A disc unit station in the system. All drives are numbered from zero to a maximum and are administered by the cat process.
<u>File</u>	A logical collection of data residing on a disc having a name (discfile). Sometimes we shall denote a roll of paper tape or a collection of data between tape marks on a magtape reel as a file too.
<u>Zone</u>	A collection of information and associated storage areas necessary to perform operation on files and devices.



1.2 Files.

1.2

Files residing on discs are identified with a name consisting of 5 ascii characters. DOMUS only accepts filenames beginning with a letter and continued by letters and digits, only the first 5 characters being significant.

There exists no explicit type of the different files in the system, they may however be classified in 4 different types:

- Text Files

Consist of a sequence of ascii characters, the NULL char (a zero byte) being totally ignored, terminated by an EM char (byte value 25) or the physical end of medium.

- Relocatable Binary Files

Contain a program/process which can be loaded and started by DOMUS. The file is terminated by the physical end of medium.

- Absolute Binary Files

Contain a stand-alone program which can be bootstrapped by DOMUS. The file is terminated by the physical end of medium.

- Data Files

Contain data produced by user programs. These files are of no interest for DOMUS.

### 1.3 Drives and Subcatalogs - Load from.

1.3

At system bootstrap one of possibly more logical units of the master device is chosen as current logical unit and the main catalog of the unit is chosen as current catalog.

This logical unit is hereafter referred to as the master drive of the system and recognized as drive no. zero in the command language of 'S' [Fully strictly speaking a logical unit may be a part of or include several disc drives, ref. 4].

The logical units and the subcatalogs accessible for the system are those logical units fixed at generation time and described in the 'CATW' - process, and those subcatalogs described in the system file 'SSYSC' on unit zero, refer to app. G.

Programs are loaded from the files on the current subcatalog in use if any, in which case the current drive specification is dummy.\*If no file of the specified name is present in the subcatalog or if no subcatalog is specified the main catalog on current drive is used.

If the program descriptor word indicates, that parameters is called for, the items are transferred to core immediate following the last word part of the program. The parameter items are fetched from the command line, refer to section 3.6.

In case the program itself includes a process description the program and the process are linked into the monitor queues. As the monitor-process-scheduler turns over the control, the process starts to execute the program loaded. In parallel the operating system invites for a new command.

\*Note: The description given in the 'SSYSC'-file covers the unit ident. belonging to the subcatalog looked up.

1.4 The Operating System Process S

1.4

The DOMUS-system consists of the following basic software components:

- Monitor
- Utility Procedures
- Basic i/o
- Character i/o
- Record i/o
- Paging System
- Master Device Driver
- Operator Device Driver
- File Management System
- Operating System S

The operating system S takes care of core storage management, including program load from disc files, program/process removal. It executes commands keyed in on the operator device or sent to the process from another process in the system.

## 1.5 Core Storage Management


1.5

### 1.5.1 Core Items

1.5.1

Programs and processes are organized as described in ref.1. After system initialization the available core storage above the basic system is organized as one large item of core storage. When the system works, pieces of that core storage is occupied by additional programs, procedures, processes or data. Core storage is allocated in disjoint pieces, called core items, all chained together in ascending order in the one and same chain, the core item chain. Refer to app. E.

The core item is headed by a 8 word descriptor with the following contents:



The ident field is used to classify a coreitem as a nitem or a xitem the former restricted to be used as a low core storage allocating element only (addressroom: 0-64KB, ref.2).

	FREE	USED
NITEM:	ident:=0	Ident:=0/corresp.xitem. address
XITEM:	ident:=-1	ident:=-1

The owner field contains the process description address of the process which allocated the item.

The current load address field points out the first address to use during load of a program or a process.

The chain field points out the next core item (the head + 0 address) in the item chain, or is set to zero if the item is the last item in the chain.

The size field contains the size of the core item.

The name field contains the item name.

## 1.5.2 Core Allocation Strategy.

1.5.2

As mentioned in section 1.5.1 two different types of core storage allocating elements exist.

The so-called nitem should be used for those program parts working on byteaddresses, refer to ref 1. Notice: the program descriptor and the processdescriptor should always reside in low core and the program descriptor should be the first part of a program.

A correspondence exist between nitems and xitems of the same name generated in the same task-composite items - in which case the corresponding xitem is pointed out from the nitem, which is placed first in the coreitem chain. Refer to app. E.

If a xitem is to be allocated this item is allocated first. The core item chain is searched for the last free item of sufficient size, and in this item space is reserved from the higher end and backwards.

If a nitem is to be allocated this item is allocated next. The core item chain is searched for the first free item of sufficient size, with a lower address than the evt. corresponding xitem. In this item space is reserved from the lower end and forwards. Notice: the nitem is not allowed to be placed in the higher core, whereas the xitem could be placed anywhere.

### 1.5.3 Core Item Classification.

Core items are divided into 3 subclasses:

Free core items:        The item is not owned by any process, i.e. the core is not used.

Used core item:        The item is owned by a process, which may use it for any purpose, e.g. loading of programs, storing data etc.

Utility core item:     The item is automatically allocated to the owner process during a load, but the item cannot be used explicitly.

All processes except for the processes in the basic system are contained in exactly one evt. composite core item. In a evt. composite core item may reside several processes. Thus two relations exists between a process p and a core item C.

1)  $\left. \begin{array}{l} p \text{ in C \\ C \text{ contains } p: \end{array} \right\} =$  P lies inside the core item C


2)  $\left. \begin{array}{l} p \text{ owns } C \\ C \text{ owned by } p: \end{array} \right\} =$  C's owner is p

### 1.5.4 Process Hierachy

The above mentioned two relations between core items and processes introduce a relation between processes:

$p_1$  parent to  $p_2$  = there exists a core item C so that  
 $p_2$  child of  $p_1$ :  $p_2$  in C and C owned by  $p_1$

All processes except for the processes in the basic system are children of other processes and all these processes are organized in a structure with respect to the relation parent to.



## 2. WORKING CYCLE OF S.

2.

### 2.1 The S mode.

2.1

After system bootstrap the process S goes into its idle state waiting for an event. The S-process will always be in one of two modes called external and internal mode respectively. With each mode a unique set of the variables subcatalog, drive is defined, and the commands 'CONNECT', 'RELEASE' and 'DRIVE' may change the value of the current subcatalog or drive associated with current mode only.

After system bootstrap current mode is defined as external, and the default value  $(cat, 0) = (main\ catalog, master\ drive)$  is used for the two modesets:

$$(sub, drive)_I := (sub, drive)_E := (cat, 0);$$

As the operating system runs in external mode, the mode set  $(sub, drive)_I$  equals the default value.

As the operating system runs in internal mode, the mode set  $(sub, drive)_E$  is saved.

### 2.2 Mode shifts:

2.2

If a command covers the S-function 'BEGIN' or 'INT' and current mode is defined as external, then current mode is changed to internal and  $(sub, drive)_I := (sub, drive)_E$  as initialization value.

If a command covers the S-function 'END', current mode set is reset and current mode is then defined as external, that is:

Current mode was external:  $(sub, drive)_I := (sub, drive)_E = (cat, 0);$

Current mode was internal:  $(sub, drive)_I := (cat, 0)$  and  
 $(sub, drive)_E := (sub, drive)_E$  saved.



## 2.3 Events:

2.3

An event may be classified as given below.

If mode is set to internal, the 'END' command must be included in the command sequence to force S into its idle state (mode = external) waiting for a new command.

If an error occurs, current mode set is reset and S returns to its idle state (mode = external).

### 2.3.1 Console Command

2.3.1

A human operator has keyed in a command to be executed.  
Mode := external. The command may cause a mode shift.

### 2.3.2 Internal Command.

2.3.2

A process in the system has sent a message to S containing a sequence of commands to be executed. Mode := internal.  
The command sequence is automatically augmented with an 'END' command.

### 2.3.3 Internal Request.

2.3.3

A process in the system has sent a message to S, wanting S to kill itself and execute a sequence of commands. Mode := internal. The command sequence is automatically augmented with an 'END' command.

S starts to execute the first command. The command may force S to read more commands from the operator device or to read more commands from a file on current subcatalog/drive. All commands are executed in a strict sequential manner and some commands may be treated differently depending on whether the execution was initiated via the console or not.

As the S-functions only take "a short time" to execute, you may always expect S to be ready to accept a console command, i.e. ready to perform a quick operator intervention.

If an error occurs while executing a console command S will print an error message on the operator device. If an error occurs while S is executing an internal command or request, S will send an appropriate answer containing information about the error. When S receives an internal request containing no commands it will just kill the process and print the message: FINIS <process name> on the operator device.

#### 2.4 The Operating Process.

2.4

When executing console commands, the operating process is defined as S itself. When executing internal commands the operating process is the sender of the message. Internal requests are only accepted if the sender of the message is a child of S, and the operating process is then defined as S itself.

Generally S accepts to operate only on core items owned by the operating process. So the only processes S would kill is the children of the operating process. Some special function, however, violates this rule.

### 3. THE S COMMAND LANGUAGE.

3.

The following metalinguistic symbols are used, in the description of the S command language:

Sequences of characters enclosed in < and > represent metalinguistic variables whose values are sequences of symbols. The mark ::= means "may be composed of" and the mark | means "or". The production (rule): <sign> ::= + | - means that any occurrence of the variable <sign> may be replaced by a + or a -. The braces {and} signifies that the contents should be regarded as a single metalinguistic variable. The superscription \* means zero or more occurrences of the preceding variable, whereas the superscription + means one or more occurrences. The brackets [and] indicates an optional string.

#### 3.1 Basic elements.

3.1

Syntax:

<letter> ::= A|B|C|D|E|F|G|H|I|J|K|L|M|N|  
O|P|Q|R|S|T|U|V|W|X|Y|Z|Æ|Ø|Å|§  
a|b|c|d|e|f|g|h|i|j|k|l|m|n|  
o|p|q|r|s|t|u|v|w|x|y|z|æ|ø|å|

<digit> ::= 0|1|2|3|4|5|6|7|8|9

<nl> ::= ascii characters LF, VT, FF or CR

#### 3.2 Numbers.

3.2

Syntax:

<integer> ::= <digit>+  
<sign> ::= +|-  
<radix> ::= <integer>'  
<numbers> ::= [<sign>] [ <radix> ] <integer>

**Semantics:**

A number represents a 16 bit integer quantum. If no sign is present the number is regarded as positive.

If - is present the two's complement of the number is used.

If no radix is present the integer is interpreted as a decimal number. The radix denotes that the following integer should be converted digit by digit as follows:

Number:=number\*radix+digit. All numbers are treated modulo  $2^{16}$ .

A number is terminated by the first non digit following the number.

3.3 Texts

3.3

**Syntax:**

<text> ::= '<any character except>'

**Semantics:**

A text represents a sequence of characters of any length.

3.4 Names

3.4

**Syntax:**

<name> ::= <letter> { <letter> | <digit> }\*

**Semantics:**

A name is used to identify a file, a process, a program an S-function or it has a special meaning depending on the S-function or utility program using the name.

Only the first 5 characters in the name are significant. The name is terminated by the first non letter or digit following the name.

3.5 Items

3.5

## Syntax:

```

<item> ::= <name> | <number> | <text> |
         <dummy item> | <composite item>
<composite item> ::= (<item> { [<sep>] <item> } *)
<dummy item> ::= *
<sep> ::= . | / | : | = | ,

```

## Semantics:

Items are the fundamental entities forming S-commands. Each item is treated as a unit by the command interpreter of S, and any separators appearing in front of an item are related to that item. Items and the preceding separator (if any) are packed into an internal form by S. Consult ref 2 for further information on the representation of items.

The dummy item denotes the absence of a parameter. The composite item denotes a record of parameters considered as one parameter.

3.6 S-Commands.

3.6

## Syntax:

```

<command> ::= <S-function> { [<sep>] <item> } * <nl> |
             <filename> { [<sep>] <item> } * <nl> |
             <nl>
<S-function> ::= <name>
<filename> ::= <name>

```

## Semantics:

If the first item is the name of an S-function, that function is executed with the remaining items considered as parameters to the S-function. If this is not the case the actual name is treated as a filename and a look-up of the name is made. If a look-up is successfully done and the entry forms a program, this program is loaded to core. If the actual command was divided into more items all items of the command are treated as parameter items for the program. The format for the representation of items is given in ref. 2.

3.7 Comments, Blanks, Blind characters.

3.7

The NULL character is totally blind.

The ascii characters: SP and HT and the sequence

! <any characters except !>! are blind outside texts, except for being terminators of names and numbers.

4. S-FUNCTIONS.

4.

S-functions are executed by S itself. If it is impossible to execute the function properly, an error message is printed on the operator device if the S-function was executed as a console command. If the execution was initiated via an internal command or request an answer containing the error cause is returned. See ref. 2 for further information. When an error occurs, the function is aborted and S skips remaining commands in a command sequence and goes into the idle state.

Error messages consist of 3 components:

1. An error cause
2. Possibly a name
3. Possibly a number

When printing error messages on the operator device the messages has the format:

```
***<text> [<name>] [<number in octal>]
```

where the text explains the error cause. A list of error messages are presented in appendix C.

In the following each S-function is listed using this scheme:

S-FUNCTION:	name of S-function.
FORMAT:	format of commands activating the function.
FUNCTION:	explanation of the function when executed as console command.
EXAMPLES:	one or more examples of the use.

ERRORS: list of error messages that may appear and an equivalent error number. The following error messages may appear in all contexts:

***SYNTAX	(1)
***TOO MANY PARENTHESIS	(2)
***END MEDIUM FILE <filename or operator device>	(4)
***TOO MANY COMMANDS	(5)
***SYSTEM ERROR <number>	(22)

INTERNAL

EXECUTION: modifications - if any - to the above explanation of the function when the command is executed as an internal command or request.



4.1 S-FUNCTION: BEGIN

4.1

FORMAT: BEGIN

FUNCTION: S is forced to read a sequence of commands from the operator device continuously until and END-command is read. Then the commands are executed in the order as given up to and including the first END, INT or BEGIN command.

No internal commands and/or internal requests will interrupt this sequence.

If current mode is external then mode is changed to internal and  $(\text{sub}, \text{drive})_I := (\text{sub}, \text{drive})_E$ . If current mode is internal neither the mode nor the mode set is changed.

The internal mode set will be redefined anytime a DRIVE or CONNECT/RELEASE - command is interpreted in the command sequence, whereas the external mode set is left unchanged.

EXAMPLES:

```

CONNECT SUBC0
DRIVE 0           ! Ext mode set: SUBC0,0!
BEGIN
  LOAD PTR       ! Int mode set: SUBC0,0!
  LIST PTR
  CONNECT SUBC1
  DRIVE 1       ! Int mode set: SUBC1,1!
  LOAD PTP
END             ! Ext mode set: SUBC0,0!
RELEASE       ! Ext mode set: CAT,0!
LOAD LPT

```

The PTR-program is loaded from the subctalog SUBC0 described on the master drive, or if no file is present, from the main catalog on the master drive.

The PTP-program is loaded from the subcatalog SUBC1 on the master drive, or if no file is present, from the main catalog on drive no.1.

The LPT-program is loaded from the main catalog on the master drive.

ERRORS:

\*\*\* PARAM

(3)

INTERNAL

EXECUTION:

The command is dummy. It should be kept in mind that the internal command request itself defines a internal mode state of S. In that the BEGIN-command is dummy, the internal set of mode variables is not redefined at entrance:

$$(\text{sub, drive})_I := (\text{cat}, 0).$$

Of course the internal mode set will be redefined during the command sequence if called for.

4.2

S-FUNCTION: BOOT

4.2

FORMAT: BOOT &lt;filename&gt;

FUNCTION: The function loads an absolute binary program from the file specified. The file should reside on current subcat described on the master drive or on the main catalog on current drive. The command terminates the normal execution of the DOMUS system and replaces it with a stand alone program, perhaps being another MUS system or the like.

EXAMPLES: BOOT BACRES !terminate the DOMUS system and  
bootstrap the program BACRES!

ERRORS:

- \*\*\*PARAM (3)
- \*\*\*STATUS, FILE <filename> <status> (6)
- \*\*\*UNKNOWN, FILE <filename> (7)
- \*\*\*RESERVATION, FILE <filename> (8)
- \*\*\*ILLEGAL PROGRAM, FILE <filename> (17)

The file does not contain a absolute binary program.

- \*\*\*SIZE ERROR, FILE <filename> (18)

No more core available during the creation of the absolute core image of the program.

- \*\*\*CHECKSUM ERROR, FILE<filename> (19)

INTERNAL

EXECUTION: As described above.

4.3

S-FUNCTION: BREAK

4.3

FORMAT: BREAK &lt;process name&gt;

FUNCTION: The function performs a break on the process given by <process name>. The processes in the basic system including S itself are not allowed to be broken. The process is started in its break address with errornumber = 2.

EXAMPLES: BREAK MAIN

ERRORS: \*\*\*PARAM (3)  
\*\*\*NOT ALLOWED (15)  
\*\*\*PROCESS DOES NOT EXIST, PROCESS (21)  
<process name>

INTERNAL

EXECUTION: As described above.

4.4

S-FUNCTION: CLEAN

4.4

FORMAT: CLEAN &lt;process name&gt;

FUNCTION: The function performs a stopprocess and a clean-process on the process given by <process name>. The processes in the basic system including S itself are not allowed be cleaned. The function should not be used unless you know the consequences of cleaning processes, and should only be used during program debugging.

EXAMPLES: CLEAN MAIN

ERRORS: \*\*\*PARAM (3)  
\*\*\*NOT ALLOWED (15)  
\*\*\*PROCESS DOES NOT EXIST, PROCESS  
<process name> (21)

INTERNAL

EXECUTION: As described above.

4.5

S-FUNCTION: CLEAR

4.5

FORMAT: CLEAR [&lt;core item name&gt;]

FUNCTION: The function clears either the specified core item or if no core item name is present, all utility core items owned by the operating process. The actual item could be a composite item as well.

Clear specified core item:

CLEAR <core item name> clears the core item specified in the following way: First all processes inside the core item are killed (see KILL), causing the load address to be adjusted to the lowest possible address. If the core item is a utility core item, the core item is returned to the pool of free items. It is not allowed to clear a core item not owned by the operating process.

Clear all utility items:

CLEAR acts as a sequence of clears on all utility core items owned by the operating process.

EXAMPLES: CLEAR A

ERRORS: \*\*\*PAPAM (3)  
 \*\*\*COREITEM DOES NOT EXIST, ITEM (11)  
     <core item name>  
 \*\*\*NOT ALLOWED (15)

INTERNAL

EXECUTION: As described above.

4.6 S-FUNCTION: CONNECT

4.6

FORMAT: CONNECT <subcatalog name>

FUNCTION: Current subcatalog is released and <subcatalog name> is connected as current subcatalog. The main catalog could be specified as current subcatalog together with existing subcatalogs described in the system file 'SSYSC', refer to app. G.

If no subcatalog of the name described on the master drive, an error is returned and the main catalog is inserted as current subcatalog. Notice: mode is then changed to external.

EXAMPLES: CONNECT SUBC1

ERRORS: \*\*\*PARAM (3)  
\*\*\*UNKNOWN, SUBCATALOG <subcatalog name> (24)

INTERNAL

EXECUTION: As described above.

4.7

S-FUNCTION: DRIVE

4.7

FORMAT: DRIVE &lt;driveno&gt;

FUNCTION: The function selects the drive specified by driveno as the current drive, and the current mode set value of drive is updated according here to. This drive remains the current drive for all succeeding executions of commands until the END command or another DRIVE command is executed.

As indicated earlier the current value of DRIVE is suppressed if a subcatalog is specified. This is due to the fact that only subcatalogs described on the master drive are accessible, ref. 4. If however the actual file does not exist on current subcatalog in use, the main catalog on the current drive is examined.

This strategy is used accessing files executing the 'INT', 'LOAD', 'BOOT' and 'Utility load' commands.

The connection between drives and the physical environment on an installation is fixed at system generation time. The DRIVE command does not check if the selected drive is operable.

EXAMPLES: Let file 'scom' on drive 2 have the following contents:

```
LOAD A B C
END
```

Then the files A,B and C on that drive could be loaded using one of the two set of commands given below:



```

.
.
.
RELEASE          ! Ext mode set: (CAT,2)!
DRIVE 2
INT 'scom'
.
.
.
BEGIN
  RELEASE
  DRIVE 2        ! Int mode set: (CAT,2)!
  INT 'scom'
END

```

If the ext mode set defines no subcatalog the release command is dummy

ERRORS: \*\*\*PARAM (3)

#### INTERNAL

EXECUTION: As described above apart from the fact that no release command is required.

```

                                ! Int mode set: (CAT,0)!
DRIVE 2                        ! Int mode set: (CAT,2)!
INT 'scom'
END

```

4.8

S-FUNCTION: END

4.8

FORMAT: END

FUNCTION: The command acts as terminator for a sequence of commands, when S is reading, either from operator device caused by the BEGIN command, or from a disc file caused by the INT command. When the command is executed S returns to its idle state. The internal command/request is automatically augmented with a END command.

Current mode is defined to external. If the command was given in external mode, (sub, drive)<sub>I</sub> is reset to (CAT,0) else the external mode set is reset to (CAT,0).

## EXAMPLES:

```
CONNECT SUBC0 ! Ext mode set: (SUBC0, 1)!
DRIVE 1
BEGIN
:           ! Int mode set: (SUBC0, 1)!
:           Evt. changed
:
:
END         ! Int mode set: (CAT, 0)!
LOAD PTR   ! Ext mode set: (SUBC0, 1)!
CONNECT SUBC1
LOAD LPT   ! Ext mode set: (SUBC1, 1)!
LIST LPT
:
END         ! Ext mode set: (CAT, 0)!
:
CONNECT CAT ! Ext mode set: (CAT, 0)!
DRIVE 0
```

ERRORS:           None

INTERNAL

EXECUTION:        As described above apart from the fact that the  
                  BEGIN command is a dummy command. Notice that  
                  current mode is internal always.

4.9

S-FUNCTION: FREE

4.9

FORMAT: FREE <core item name>

FUNCTION: The function returns the evt. composite core item specified to the pool of free core. The core item should be owned by the operating process, and it may not contain any process.

EXAMPLE: FREE A

ERRORS: \*\*\*PARAM (3)

\*\*\*COREITEM DOES NOT EXIST, ITEM  
           <core item name> (11)

\*\*\*COREITEM NOT CLEARED, ITEM  
           <core item name> (12)

          The item contains a process descriptor.  
           Clear the item, using the CLEAR command.

\*\*\*NOT ALLOWED (15)

          The owner of the item is not the operating process.

INTERNAL

EXECUTION: As described above.

4.10 S-FUNCTION: GET

4.10

FORMAT: GET <core item name> [`<size>` | `<size><size>`]

FUNCTION: The function allocates a evt. composite core item with the specified name. If size is specified the function allocates a core item with size equal to the number of words specified, or larger using the strategy given in section 1.8. The owner of the core item is set to the operating process and the current load address is set to the first word after the core item head. After a successful allocation, the core item is a used core item owned by the operating process. Notice: The last 4 words of the core area is reserved and can not be allocated. The item may be composite or not depending on the `<size>`-part.

No `<size>` specification:

A nitem of maximal size is created covering the rest of low core part.

1 `<size>`-parameter specified:

A nitem of the specified size is created. If a '\*' is specified a maximum nitem is created.

2 `<size>`-parameters specified:

A nitem and a xitem are created according to the specified value of the first and the second size parameter respectively. The parameters are interpreted as mentioned above. If two items are created they are referred to as a composite item. To generate a xitem only, the first `<size>`-parameter should be of zero value.

The <size>-parameter:

The size asked for should include the head area of the item wanted except for the ident field. The size-field of the allocated item will equal the parameter value except for the three cases mentioned below:

<size>:= 0:

No item is allocated.

This mode is included to allow for a pure xitem allocation using the command:

GET COREX 0 X.

<size>: = \*:

A maximum item is allocated.

If a xitem is asked for high core storage area should be available. If this is not the case a size-error is returned.

0<'<size>'<7:

A size-error is returned.

EXAMPLES:

1) GET CORE0 512

GET CORE1 512

LIST/CORE CORE0 CORE1

Result of list command:

CORE0 16334 1000 16343 S

CORE1 17335 1000 17344 S

2) GET CORE0 512 512

LIST/CORE

Result of list command:

: !High core available!

:

CORE0 16334 1000 16343 S 176774 !nitem!

17335 157436 17344

CORE0 176774 1000 177003 S !xitem!

3) GET CORE0 \* 512

LIST/CORE

Result of list command:

! High core available!

:

:

CORE0 16334 61445 16343 S 176774

100001 76772 100010

CORE0 176774 1000 177003 S

:

! Low core available only!

:

CORE0 16334 60437 16343 S 76774

CORE0 76774 1000 77003 S

ERRORS:

\*\*\*PARAM (3)

\*\*\*COREITEM EXISTS, ITEM

<core item name> (9)

it is impossible to get an item with the  
name of an already existing core item name.

\*\*\*SIZE (10)

It is impossible to get an item of  
the specified size.

INTERNAL

EXECUTION:

As described above.

4.11 S-FUNCTION: INIT

4.11

FORMAT: INIT <drive no>

FUNCTION: The function sends an init catalog message to the file handler containing the specified driverno, see ref 4 . The master drive is always operable, but the other drives in the system cannot be used before the INIT command has been executed for that drive.

EXAMPLES: INIT 1 ! Initialize drive 1!

ERRORS: \*\*\*PARAM (3)  
\*\*\*STATUS, DEVICE <device name> (14)  
Drive not operable

INTERNAL

EXECUTION: As described above.



4.12 S-FUNCTION: INT

4.12

FORMAT: INT &lt;filename&gt;

FUNCTION: The function causes S to read a sequence of commands from the file specified. The file should reside on current subcat described on the master drive or on the main catalog on current drive. The reading continues until an END command has been read. Then S starts to execute the commands one by one up to and including the first END, INT or BEGIN command. Note that no other commands can interrupt the above sequence before an END command has been executed. By putting INT commands in a command file you can chain a number of command files. If you do this make sure that the chain is finite.

## EXAMPLES:

```

:
:                               ! MODE = EXT OR INT!
CONNECT SUBC1
DRIVE 1
INT 'scom1'                     ! scom1 is interpreted in
                                current mode!
:
:                               ! MODE is changed to EXT
                                caused by the END command!

```

Contents of file 'scom1':

```

LOAD A B
INT 'scom2'

```

END

Contents of file 'scom2':

```

! As mode is internal the
  BEGIN command is dummy!

```

```

BEGIN

```

```

LOAD C

```

```

END

```

RESULT: A, B and C will be loaded.

ERRORS:	***PARAM	(3)
	***STATUS, FILE <filename>	(6)
	***UNKNOWN, FILE <filename>	(7)
	***RESERVATION, FILE <filename>	(8)
	***ENTRY NOT A FILE, ENTRY <filename>	(13)

## INTERNAL

EXECUTION: As described above.

4.13

S-FUNCTION: KILL

4.13

FORMAT: KILL &lt;process name&gt;

FUNCTION: The function kills the specified process in the following way. All core items owned by the process are cleared (see CLEAR function) and are returned to the pool of free items. Then the process itself is removed, and if the surrounding core item is a utility item, the item is also returned to the pool of free items, otherwise the load address of the surrounding core item is adjusted. The adjustment of the load address is done if there are no processes in the core item with a process description address higher than the process description address of the process to be removed, and the load address is reset to the value used when the process was originally loaded. It is only allowed to remove a process being a child of the operating process.

EXAMPLES: KILL MAIN

ERRORS: \*\*\*PARAM (3)  
 \*\*\*NOT ALLOWED (15)  
 \*\*\*PROCESS DOES NOT EXIST, PROCESS  
 <process> (21)

INTERNAL

EXECUTION: As described above.

4.14 S-FUNCTION: LIST

4.14

FORMAT: LIST [/PROGRAM|/CORE] <name>\*

FUNCTION: The function lists items in one of three chains, the process chain, the program chain or the core item chain. The items are listed on the operator device. The function lists selected items or, if no <name> is present, all items in the chain. All numbers are printed in octal.

Process list:

LIST <name>\* selects the process chain, and the output has the following format:

<name> <address> [@] [<core item name>]

<name> is the name of the process, augmented with the subcatalog no., if the process is a subcatalog process

<address> is the process description address of the process.

(a) indicates that the process is a driver process and that no process has reserved the driver.

<core item name> is the name of the surrounding core item, blank if the process reside in the basic system. If the core item was allocated because of a utility load, core item name is augmented with the subcatalog/drive no. used at load time, blank if zero.

Program list:

LIST/PROGRAM <name>\* selects the program chain and the output has the following format:

<name> <address>

<name> is the name of the program.

<address> is the address of the program head, equal to the relocatable base of the program when it was loaded.

Core item list:

LIST/CORE <name>\* selects the core item chain, and the output has the following format:

[<name>]<address><size><current load address>  
                   <owner process name>[<corresponding xitem address>]

<name> is the name of the core item, blank if the core item is free. If the core item was allocated because of a utility load, name is augmented with the subcatalog/drive no. used at load time, blank if zero.

<address> is the address of the core item head.

<size> is the size of the core item.

<current load address> is the relocatable base for the next load into this core item, or it is printed as ..... if the item is a utility item.

<owner process name> is the name of the process owning the core item, blank if the item is free.

<corresponding xitem address> is the address of an evt. xitem part of a composite item, blank if the item is free.

Generally:

If a name appears in the name list: <name>\* and it does not exist in the selected chain, no output is generated for that name.

EXAMPLES:

```
LIST LPT SPT :
LPT 40377
!NOTE THE PROCESS SPT DID NOT EXIST!
```

```
LIST/CORE SPT :
SPT      40370  276 ..... S
```

```
LIST/CORE      :
:
CAP8      16374  1136 ..... CAT
:
SFILE<020> 50370   400 ..... S   60772
          50771 10000 51000
SFILE<020> 60772   200 ..... S
:          ! The file SFILE is loaded from
:          current subcatalog SUBC0!
```

```
ERRORS:      ***PARAM      (3)
```

INTERNAL

```
EXECUTION:   The command is dummy.
```

4.15

S-FUNCTION: LOAD

4.15

FORMAT: LOAD [/`<core item name>`[/`<size>`|/`<size>`/`<size>`]]  
 {`<filename>`| (`<filename>` `<params>`)}  
 [/`<process name>`]}<sup>+</sup>

FUNCTION: The basic function of S, making it possible to load programs from files. The function loads a list of files specified by `<file name>` or (`<file name>` `<params>`). If the program accept parameters, the first form results in `<filename>` being the only parameter, and the second form results in `<filename>` `<params>` being the parameters. If the file contains a process descriptor the address of the parameters are delivered to the process through an accumulator, see ref. 2 for further information. Each process loaded can be renamed by adding the `/<process name>` to the filename. Otherwise the process name in the process descriptor is used.

Load into free core:

LOAD {`<filename>`|(`<filename>``<params>`)}  
 [/`<process name>`]}<sup>+</sup>

The core allocation strategy is given in section 1.5.2. When each file has been loaded and the parameters are appended to the program, the core item is cut to the minimal size still containing the program. The name of the evt. composite core item is set to the name of the file from where the program was loaded. The name is augmented with the subcatalog/drive-no. used at load time, blank if zero. The load address is set to zero and the owner to the operating process. Thus a utility item is created.

Load into a specific core item:

```
LOAD / <core item name>[/<size>|/<size>/<size>]
    { {<file name>|(<file name><params>)}
      [/<process name>]}+
```

When using this format, each file is loaded into the specified core item, starting at the current load address of the core item. When each file has been loaded and the parameters are appended to the program, the current load address is adjusted.

The load can never exceed the core storage occupied by the core item. The size parameter forces S to check that the load does not overwrite the core storage behind the first <size> locations of the evt. composite core item. The first size-parameter specifies a nrel size and the second size-parameter specifies a xrel size. The format is not the same as the one used for a 'GET' command.

<size> not specified:

No restriction on load size.

<size>=\*: Not allowed.

It should be noticed that load into a pure xitem is not allowed.

It is only allowed to load into a core item owned by the operating process.

EXAMPLES:

```
LOAD PTR           !load of a paper tape reader driver!
LOAD SPT/LPT      !load of a serial printer driver and
                  renaming the process to LPT!
LOAD PTP (PIP 1 2 3)
                  !load of a paper tape punch driver
                  and a utility program with parameters!
LOAD/A PPP        !load the program PPP into the
                  core item A!
```



- ERRORS:
- \*\*\*PARAM (3)  
Errors in the format. Note that the format is checked before any load.
  - \*\*\*STATUS, FILE <file name> <status> (6)
  - \*\*\*UNKNOWN, FILE <file name> (7)
  - \*\*\*RESERVATION, FILE <file name> (8)
  - \*\*\*CORE ITEM DOES NOT EXIST, ITEM  
<core item name> (11)
  - \*\*\*ENTRY NOT A FILE, ENTRY <catalog  
entry> (13)
  - \*\*\*NOT ALLOWED (15)
  - \*\*\*NO SPACE FOR PAGES, FILE <file name> (16)  
The disc file used for saving the pages of paged programs is filled during the load of the program on file <file name>. Usually a system generation error.
  - \*\*\*ILLEGAL PROGRAM, FILE <file name> (17)  
The file <file name> does not contain a relocatable binary program.
  - \*\*\*SIZE ERROR, FILE <file name> (18)  
No more core available for the load of the program on file <file name>.
  - \*\*\*CHECKSUM ERROR, FILE <file name> (19)  
Checksum error during load of the program on file <file name>
  - \*\*\*VIRTUAL ADDRESS ERROR, FILE <file  
name> (20)  
The program contains an illegal virtual address or an erroneous page map.
  - \*\*\*PROCESS EXISTS, PROCESS <filename> (23)  
The file cannot be loaded because a process exists with the same name as the filename.

INTERNAL

EXECUTION:

As described above.

4.16      S-FUNCTION:      RELEASE      4.16

            FORMAT:      RELEASE

            FUNCTION:      Current subcatalog is released and the main catalog is inserted as current subcatalog. If an error return mode is changed to external.

            ERRORS:      \*\*\*PARAM      (3)

            INTERNAL

            EXECUTION:      As described above.

4.17 S-FUNCTION: START 4.17

FORMAT: START <process name>

FUNCTION: The function performs a startprocess on the process given by <process name>. The processes in the basic system including S itself are not allowed to be started.

EXAMPLES: START MAIN

ERRORS: \*\*\*PARAM (3)  
\*\*\*NOT ALLOWED (15)  
\*\*\*PROCESS DOES NOT EXIST, PROCESS  
<process name> (21)

INTERNAL

EXECUTION: As described above.

4.18 S-FUNCTION: STOP 4.18

FORMAT: STOP <process name>

FUNCTION: The function performs a stopprocess on the process given by <process name>. The processes in the basic system including S itself are not allowed to be stopped.

EXAMPLES: STOP MAIN

ERRORS: \*\*\*PARAM (3)  
\*\*\*NOT ALLOWED (15)  
\*\*\*PROCESS DOES NOT EXIST, PROCESS  
<process name> (21)

INTERNAL

EXECUTION: As described above.

4.19 S-FUNCTION: Utility program load

4.19

FORMAT: <file name> [<params>]

FUNCTION: if <file name> is not identical to any other S-function, the command works as the command: LOAD (<file name> [<params>]). See LOAD for further information

EXAMPLES: PRINT PIP

ERRORS:

- \*\*\*PARAM (3)
- \*\*\*STATUS, FILE <file name><status> (6)
- \*\*\*UNKNOWN, FILE <file name> (7)
- \*\*\*RESERVATION, FILE <file name> (8)
- \*\*\*ENTRY NOT A FILE, ENTRY <file name> (13)
- \*\*\*NO SPACE FOR PAGES (16)
 

The disc file used for saving the pages of paged program is filled during load of the program on file <file name>. Usually a system generation error.
- \*\*\*ILLEGAL PROGRAM, FILE <file name> (17)
 

The file <file name> does not contain a relocatable binary program.
- \*\*\*SIZE ERROR, FILE <file name> (18)
 

No more core available for the load of the program on file <file name>
- \*\*\*CHECKSUM ERROR, FILE <file name> (19)
 

Checksum error during load of the program on file <file name>
- \*\*\*VIRTUAL ADDRESS ERROR, FILE <file name> (21)
 

The program contains an illegal virtual address or an erroneous page map.

\*\*\*PROCESS EXISTS, PROCESS filename (23)

The file cannot be loaded because a  
process exists with the same name as  
the filename.

INTERNAL

EXECUTION:

As described above.

4.20 S-FUNCTION: WAIT 4.20

FORMAT: WAIT <Timer-value>

FUNCTION: The operating system is forced into its idle state and S will not be ready to execute any command in the specified time periode.

EXAMPLES: WAIT 3 !Wait 3 seconds!

ERRORS: \*\*\*PARAM (3)

INTERNAL

PRESCRIPTION: As described above. It should be noticed that a WAIT-Command not keyed in from the operator console will delay the operating system invisibly to other users.





APPENDIX A, CHARACTER SET USED BY DOMUS

V	N	C	V	N	C	V	N	C	V	N	C
0	NUL	blind	32	SP	blank	64	@	ill.	96	\	ill.
1	SOH	ill.	33			65	A		97	a	
2	STX	ill.	34	"	ill.	66	B		98	b	
3	ETX	ill.	35	#	ill.	67	C		99	c	
4	EOT	ill.	36	§		68	D		100	d	
5	ENQ	ill.	37	%	ill.	69	E		101	e	
6	ACK	ill.	38	&	ill.	70	F		102	f	
7	BEL	ill.	39	'		71	G		103	g	
8	BS	ill.	40	(		72	H		104	h	
9	HT	blank	41	)		73	I		105	i	
10	LF	nl.	42	*		74	J		106	j	
11	VT	nl.	43	+		75	K		107	k	
12	FF	nl.	44	,		76	L		108	l	
13	CR	nl.	45	-		77	M		109	m	
14	SO	ill.	46	.		78	N		110	n	
15	SI	ill.	47	/		79	O		111	o	
16	DLE	ill.	48	0		80	P		112	p	
17	DC1	ill.	49	1		81	Q		113	q	
18	DC2	ill.	50	2		82	R		114	r	
19	DC3	ill.	51	3		83	S		115	s	
20	DC4	ill.	52	4		84	T		116	t	
21	NAK	ill.	53	5		85	U		117	u	
22	SYN	ill.	54	6		86	V		118	v	
23	ETB	ill.	55	7		87	W		119	w	
24	CAN	ill.	56	8		88	X		120	x	
25	EM	em.	57	9		89	Y		121	y	
26	SUB	ill.	58	:		90	Z		122	z	
27	ESC	ill.	59	;	ill.	91	Æ		123	æ	
28	FS	ill.	60	<	ill.	92	Ø		124	ø	
29	GS	ill.	61	=		93	Å		125	å	
30	RS	ill.	62	>	ill.	94	↑	ill.	126	~	ill.
31	US	ill.	63	?	ill.	95	←	ill.	127	DEL	ill.

V = 7 bit value of character

N = name of character


C = comments

If no comments the characters are recognized by DOMUS according to the syntas of S commands.

ill. means that the character is illegal outside texts and comments.

em. means that the character signifies end of medium.

nl. means that the character is regarded as the terminator of a command line.



APPENDIX B, SURVEY OF S-COMMANDS

BEGIN	Read a sequence of command lines from the operator device. Terminate at an END command.
BOOT <file name>	Load an absolute binary program.
BREAK <process name>	Break the specified process.
CLEAN <process name>	Stop and clean the specified process.
CLEAR <core item name>	Clear specified core item, or all utility items.
CONNECT <subcatalog name>	Connect the specified subcatalog.
DRIVE <driveno>	Select the specified drive as the current drive.
END	Terminate a sequence of commands and execute these commands.
FREE <core item name>	Free the specified core item.
GET <core item name> [<size> <size><size>]	Get the specified core item.
INIT <driveno>	Initialise the catalog on the specified drive.
INT <file name>	Read a sequence of command lines from the specified file. Terminate at an END command.
KILL <process name>	Kill the specified process.

LIST [/PROGRAM|/CORE] List all or selected processes, programs  
<name>\* or core items.

LOAD [/<core item name>[/<size>|/<size>/<size>]  
{<file name>|(<file name><params>)} [/<process name>]}<sup>+</sup>  
Load the specified file(s).

RELEASE Release current subcatalog.

START <process name> Start the specified process.

STOP <process name> Stop the specified process.

<filename> [<params>] Load the specified file.

WAIT <timer-value> Wait specified no. of seconds.

APPENDIX C, SURVEY OF ERROR MESSAGES AND NUMBERS

- 1       \*\*\*SYNTAX  
          The command to S does not fulfill the syntax described in appendix A (all functions).
  
- 2       \*\*\*TOO MANY PARENTHESES  
          The command to S contains too many parentheses. Implementation restriction (all functions).
  
- 3       \*\*\*PARAM  
          The selected S-functions cannot interpret the parameters in a meaningful way (BEGIN, BOOT, BREAK, CLEAN, CLEAR, FREE, GET, INIT, INT, KILL, LIST, LOAD, START, STOP, Utility program load).
  
- 4       \*\*\*END MEDIUM FIL <filename>  
          The reading from a file is terminated due to physical end of medium on a file, or an end medium character during command reading (all functions).
  
- 5       \*\*\*TOO MANY COMMANDS  
          The command (sequence) too long, because there is not enough free core storage available, or because of an implementation restriction (all functions).
  
- 6       \*\*\*STATUS, FILE <filename> <status>  
          The reading from a file is terminated due to a status error from the file management system. The octal status is shown (BOOT, INT, LOAD, Utility program load).
  
- 7       \*\*\*UNKNOWN, FILE <filename>  
          The filename does not exist in the directory on the current drive (BOOT, INT, LOAD, Utility program load).

- 8       \*\*\*RESERVATION, FILE <filename>  
          The file is reserved for exclusive use by  
          another process in the system (BOOT, INT,  
          LOAD, Utility program load).
- 9       \*\*\*COREITEM EXISTS, ITEM <core item name>  
          The core item should not exist in order to  
          execute an S-function (GET).
- 10       \*\*\*SIZE  
          Not enough core storage available to execute  
          an S-function (GET).
- 11       \*\*\*COREITEM DOES NOT EXIST, ITEM <core item name>  
          The core item should exist in order to execute  
          an S-function (CLEAR, FREE, LOAD).
- 12       \*\*\*COREITEM NOT CLEARED, ITEM <core item name>  
          The core item contains some processes, when  
          it should not (FREE).
- 13       \*\*\*ENTRY NOT A FILE, ENTRY <filename>  
          The filename does exist in the directory on the  
          curent drive, but it is not a disc file (BOOT,  
          INT, LOAD, Utility program load).
- 14       \*\*\*STATUS, DEVICE <device name> <status>  
          Communication trouble with a process. The octal  
          status is shown (INIT).
- 15       \*\*\*NOT ALLOWED  
          The execution violates some restrictions. Check  
          with description of S-functions (BREAK, CLEAN,  
          CLEAR, FREE, KILL, LOAD, START, STOP).

- 16       \*\*\*NO SPACE FOR PAGES, FILE <filename>  
          (LOAD, Utility program load).
- 17       \*\*\*ILLEGAL PROGRAM, FILE <filename>  
          A relocatable or absolute binary program does  
          not fulfil the conventions for these type of  
          files (BOOT, LOAD, Utility program load).
- 18       \*\*\*SIZE ERROR, FILE <filename>  
          A program is too big to be loaded at the moment.  
          Try to FREE more core (BOOT, LOAD, Utility program  
          load).
- 19       \*\*\*CHECKSUM ERROR, FILE <filename>  
          Checksum error in a relocatable or absolute  
          binary file (BOOT, LOAD, Utility program load).
- 20       \*\*\*VIRTUAL ADDRESS ERROR, FILE <filename>  
          Illegal coding in paged programs (LOAD, Utility  
          program load).
- 21       \*\*\*PROCESS DOES NOT EXIST, PROCESS <process>  
          The process should exist in order to execute  
          an S-function (BREAK, CLEAN, KILL, START, STOP).
- 22       \*\*\*SYSTEM ERROR <number>  
          The S process cannot execute the command. See the  
          list of system errors in appendix D (all functions).
- 23       \*\*\*PROCESS EXISTS, PROCESS <process>  
          The process should not exist in order to execute an  
          S-function (LOAD, Utility program load).
- 24       \*\*\*UNKNOWN, SUBCATALOG <filename>  
          The subcatalog does not exist.

\*\*\*BREAK <cause> <ac1>

The S process has been broken. Malfunction of the system. The message appears on the teletype. The system may fail to operate properly.



APPENDIX D, SYSTEM ERROR MESSAGES

The format of a system error message is:

\*\*\*SYSTEM ERROR <number> where the number refers to the following list:

Bootstrap errors

The error occurs during the bootstrap of the DOMUS system

1	Operator device malfunction
2	Master drive undefined
3	Master device malfunction
4	File management system malfunction
5	Paging file error
6	System configuration error
7	Error message file error
10-16	System malfunction

Runtime errors

21	Internal request error. An error occurs after the sending process is removed. Non fatal error.
22	DOMUS stack overflow. An implementation restriction has been violated. Fatal error, the system may fail to operate properly.
24	Error message file error. Fatal error, the system may fail to operate properly.
25	Core storage structure destroyed. Fatal error, the system may fail to operate properly.



APPENDIX E, SURVEY OF CORE ADMINISTRATION

Fig. 1, coreitem and program relationship:





Fig. 2, storage allocation scheme:



APPENDIX F, SYSTEM BOOTSTRAP

The DOMUS system is usually bootstrapped using the master drive of the system. The disc should be initialized using the program SYSGEN, and should be mounted on the master drive. If you use the RC3652 2.4 Mb disc drive as master drive, mount the discpack in unit 0, set the frontpanel switches on the CPU to bit0 = 1, device selection switches = 73 (octal), and press the autoload-bottom. In case of other disc types set the device selection switches as specified by RC.

The bootstrap is then placed in core and outputs the query "SYSTEM:". Input must be a bootstrap commandfile containing a list of discfiles, which are linked together generating the DOMUS-system. The normal commandfile supplied is S3600, and can be selected by typing CR or NL immediately. During input "rubout" can be used to erase last character(s) input, and any control character (CR, NL, ESC) will terminate input.

If bootstrap is successful the message:

```
DOMUS REV nn.nn
```

will be output on the operator device.

If there exists a file on the master drive named SSYSI, the commands in this file will be executed as if you had entered the command INT SSYSI on the operator device. Otherwise the system will invite you to enter commands by printing a

```
>S
```

on the operator device.

In case bootstrap is unsuccessful an error message is output on the operator device, and the query "SYSTEM:" is output again.

Possible errors are:

- \* \* \* NOT FOUND, FILE:<filename>  
File given by <filename> is not present on the master drive.
- \* \* \* ILLEGAL BLOCK TYPE, FILE:<filename>  
A relocatable block other than start, title or data is found on file <filename>.
- \* \* \* ILLEGAL FILETYPE, FILE:<filename>  
File <filename> is not a bootstrap commandfile as the first name found <>"BASIS", or the file is not a datafile (Attribute entry only).
- \* \* \* CHECKSUM ERROR, FILE:<filename>  
One of the relocatable blocks on file <filename> has an checksum error.
- \* \* \* SIZE ERROR <octalnumber>  
Not enough space in core to load the system, <octal number> is the maximal number of words that can be used by the bootstrap program.
- \* \* \* END MEDIUM, FILE:<filename>  
Physical end of medium on file <filename> has been found before logical end of file. I.e. "END" name in commandfile or relocatable start block missing in file.
- \* \* \* HARD ERROR ON DISC <octal number>  
The disc is malfunctioning. <octal number> is the hardware status without modifications. Please consult hardware manual for further information.

Generation of bootstrap commandfile.

The bootstrap command file is a number of ASCII filenames describing relocatable files on the master disc. This way of describing the DOMUS-system makes it flexible and eases change of modules in the system in case of new releases or new hardware configuration.

The commandfiles are made as normal text files by the RC3600 Text Editor, but they must however obey following rules:

- 1) First filename has to be "BASIS", in this way telling the bootstrapprogram that the file is a bootstrap command file. The name is checked but skipped.
- 2) The following names should be the names of relocatable modules or drivers, which are going to be present in the DOMUS-system. Each name is describing a catalog file in the catalog on the master disc, and
- 3) The last name in the file must be "END" terminating the file list.
- 4) Filenames to generate a well functioning DOMUS-system following modules must be present:

- MUS - Monitor
- MUS - Utility Procedure Module
- MUS - Basic I/O Module
- MUS - Record I/O Module
- MUS - Character I/O Module
- MUSIL Interpreter

Operator Console Driver (TTY)  
Master Disc Driver  
MUS - Catalog System  
Catalog System Description Process (CATW)  
DOMUS Operating System Process  
MUS - Initialization Module

It is recommended that the MUS-Monitor is taken as the first module followed by all non-process modules, and then all driver processes. The last two modules must be the DOMUS Operating System and the MUS-Initialization Module in the given order, as the Initialization Module is removed after system start, and the Operating System expects rest of free memory above own code.

The presence of the above mentioned modules is checked by the Operating System after start, and if one is missing it results in a system-error output on the operator device, and the system will halt.



APPENDIX G, SYSTEM GENERATION

A DOMUS system is installed on a disc using the program RC36-00422. The program generates a DOMUS disc using magtape, flexible disc or paper tapes.

If the disc is going to be created from scratch (NEW command) and the input device is flexible disc, the autoloading disc contains the first part of the systemfiles. (This disc is labeled DOMUS OPERATING SYSTEM No. 1). When loaded the program prints:

INPUT DEVICE (MT/PT/FD):

When this question is answered with MT (magtape) FD (flexible disc) or PT (paper tape) the next question is:

INITIALIZE CATALOG (NEW/OLD):

If the answer is NEW the disc is formatted and an empty catalog will be written on the disc. Then the necessary files will be created in order to use the disc as a DOMUS master disc. If the answer is OLD the disc is already a DOMUS disc, i.e. it has been used before as a DOMUS disc and the program uses the old catalog on the disc.

Now the standard device descriptors, that not already exists, will be created. Each descriptor created is verified on the operator device.

If the input device is magtape a number of files will be copied to the disc and the names are verified on the operator device.

If the input device is flexible disc a number of files will be copied to the catalog and the names are verified on the operator device.

When a flexible disc has been copied the text

```
MOUNT NEXT DISCETTE
IF CONTINUE THEN NL ELSE STOP
```

is output on the operator device, and the next discette can be mounted. If all flexible discs are copied STOP must be typed, and the program terminates, else NL must be typed and the system generation will go on.

If the input device is paper tape each tape loaded is copied to a disc file with the name specified by the operator when the question

```
FILE NAME
```

is printed. When the bootstrap program is loaded the file name specified must be BOOT.

Already existing but not writeprotected files are overwritten. If a file is writeprotected a message is printed on the operator device and the program continues with the next file.

When the program has finished the message:

```
END SYSGEN
```

is printed and the program stops.

Now the disc is formatted in the following way:

sector 0 - 31: used by the bootstrap system and the file management system.

sector 32 - N: used as file space, N depends on the disc types.

file: SYS the catalog file, see ref. 4.  
 MAP the sector allocation map file, see ref. 4  
 SSYSP used by S for saving pages of paged programs.  
 QSYSP used in processor expansion systems.  
 SSYSE the error message file.  
 SSYSC contains links to accessible subcatalogs,  
 administrated by the DOMUS Utility Pro-  
 gram 'SUBCA'. A link is a fully descrip-  
 tion and as such contains to example the  
 unit number for the subcatalog described.

Below is shown a run of a sysgen program.

>S

INT SYSG

>SYSG

DOMUS SYSGEN PROGRAM

INPUT DEVICE (MT/PT): MT

INITIALIZE CATALOG (NEW/OLD): NEW

THIS IMPLIES THAT ALL EXISTING FILES ARE DELETED.

CONFIRM (YES/NO): YES

§LPT

§SP

§CPT

§PTPN

§PTP

§PTRN

§PTR

§TTY

§CIV

§MIV

§CDRN

§CDR

MUM  
MUH  
MUB  
MUC  
MUR  
INT  
TTC05  
CAP8  
MIØXX  
:  
:  
:  
:  
END SYSGEN

BREAK 3

APPENDIX H, REFERENCES

- [1] MUS-SYSTEM INTRODUCTION (I) and  
MUS PROGRAMMER'S GUIDE (II).
- Keywords: Multiprogramming, monitor, device handling, i/o-utility, record i/o, operator communication, operating system.
- Abstract: (I) This manual is intended as an introduction guide to the Multi-programming Utility System.
- (II) The manual is mainly intended for readers who are going to use the system. The user is assumed to be familiar with the general principles of the system as well as with the assembler language.
- [2] DOMUS System Programmer's Guide.
- Keywords: MUS, Operating System, Loader, disc.
- Abstract: This manual describes the interface between assembly programs and DOMUS.
- [3] RC 3600 PAGING SYSTEM  
SYSTEM PROGRAMMER'S GUIDE
- Keywords: MUS, Paging System, Virtual Memory, Address Mapping.
- Abstract: This manual describes how to use the RC 3600 paging system from assembly programs under the MUS-system.

[4]

RC 3600 CATALOG SYSTEM  
SYSTEM PROGRAMMER'S GUIDE

Keywords: Catalog system, file system, area process,  
subcatalog.

Abstract: This Manual describes how to use the  
RC 3600 file system from Assembler  
programs. The user must be familiar  
with the MUS system.

[5]

MUSIL

Keywords: RC 3600 MUS System Software,  
Programming Language.

Abstract: Syntax Rules for MUSIL language.  
Description of standard procedures.  
Explanation of I/O handling.

[6]

MUSIL COMPILER

Keywords: RC 3600 MUS, MUSIL, Compiler  
Operators guide.

Abstract: This manual describes the parameters  
to the MUSIL compiler.

[7]

DOMUS User's Guide PART II

Keywords: DOMUS, MUS, Operating System, Loader,  
disc.

Abstract: This manual describes the utility system  
for the disc operating system DOMUS for  
the RC 3600 line of computers.

[8]

TEXT EDITOR

[9]

Introduction to DOMAC Assembler.

Keywords: Beginners guide, DOMUS, DOMAC, RC3600, assembler.

Abstract: This manual contains a short introduction to the RC3600 assembler language, a description of how to involve the DOMAC assembler, and a list of possible error messages from the DOMAC assembler.

[10]

DOMUS Linkage Editor.

Keywords: DOMUS, MACRO Assembler, Linkage Editor.

Abstract: This manual describes the linkage editor for the disc operating system DOMUS for RC3600 line of computers.

