

---

**RCSL No:** 99001059  
**Edition:** July, 1988  
**Author:** Bo Bagger

---

**Title:**

RC3502-2 Operating Guide

---

---

**Keywords:**

RC3502, OPSYS Commands, DEBUG Commands, Autoloading.

---

**Abstract:**

This manual describes how to operate the RC3502 Model 2: Power-on, power-off, commands to the operating system OPSYS, operation of the DEBUG console, autoloading.

(This manual substitutes RCSL No.: 99 0 00771).

(72 printed pages).

---

**Copyright © 1985, A/S Regnecentralen af 1979**

**RC Computer A/S**

**Printed by A/S Regnecentralen af 1979, Copenhagen**

Users of this manual are cautioned that the specifications contained herein are subject to change by RC at any time without prior notice. RC is not responsible for typographical or arithmetic errors which may appear in this manual and shall not be responsible for any damages caused by reliance on any of the materials presented.

TABLE OF CONTENTS	PAGE
1. SWITCHES AND INDICATORS .....	2
1.1 Operator's Control Panel .....	2
1.2 Processor Front Panel .....	3
1.2.1 Switches .....	4
1.2.1.1 Bus Switches .....	4
1.2.1.2 Mode Switch .....	4
1.2.2 Indicators .....	5
1.3 Power Supply .....	9
2. CONSOLE OPERATION .....	10
2.1 Terminal Mode .....	10
2.1.1 Operator Process .....	10
2.1.2 OPSYS Commands .....	11
2.1.3 Messages from OPSYS .....	18
2.1.4 Messages from LOADER .....	20
2.2 Debug Mode .....	22
2.2.1 Activation .....	22
2.2.2 Display Commands .....	22
2.2.3 Control Commands .....	24
2.2.4 Command Parameters .....	25
3. AUTOLOADING .....	27
3.1 Autoload Switch Format .....	28
3.2 Autoload Messages .....	35
3.3 Generating Autoload Files .....	40
3.3.1 Generating an FTS Autoloadfile .....	41
3.3.2 Generating an FPA Autoload .....	41
3.3.3 Generating TES202 Eproms .....	41
4. ERROR PROCEDURES .....	42
4.1 Monitor Testoutput .....	42
4.2 Boot Testoutput .....	42

APPENDICES:

A. REFERENCES .....	43
B. OPSYS COMMANDS .....	44
C. AUTOLOAD SWITCH LAYOUT .....	46
D. SECRET VECTOR LAYOUT .....	47
E. INSTRUCTION CODES .....	48
F. INSTRUCTION MNEMONICS .....	49
G. PROCESS DESCRIPTOR LAYOUT .....	50
H. MESSAGE HEADER LAYOUT .....	51
I. EXCEPTION CODES .....	52
J. WORKING REGISTER LAYOUT .....	54

<u>TABLE OF CONTENTS (continued)</u>	<u>PAGE</u>
K. CONTROL MICROPROCESSOR RAM LAYOUT .....	56
L. INSTALLATION STANDARDS AND RECOMMENDATIONS .....	60
L.1 Input/Output Modules .....	60
L.2 Memory Modules .....	60
L.3 Controllers .....	61
L.4 Summary .....	61
M. INDICES .....	63
M.1 Survey of Figures .....	63
M.2 Catchword Index .....	63

**FOREWORD.**

This edition of the RC3502-2 Operating Guide is based on components of the following versions:

SW2001,    RC3502-2 Operating System release 3.2 87.03.20  
RC3502-2,    DEBUG Firmware ROB584 87.09.23  
F505A,    RC3516, RC3517, RC3519 Autoload PROM  
              ROB607,608 version 9.6 88.05.27

Autoload and load from Papertape and GCI are removed.  
LAN and X.25/3 autoload are included.

The process and incarnation concepts are changed to the concept of a process as an incarnation of a program. This reflects the language changes in RTP3502 and RTP86.

The changes are marked in the left margin.

June, 1988

**1. SWITCHES AND INDICATORS****1.1 Operator's Control Panel**

1.

1.1




Fig. 1. OCP for Rack with up to Three RC3502

Power off of the RC3502(s) is done by turning the power key to the OFF position.

Power on of the RC3502(s) is done by turning the key to the ON position (or further on to the LOCK position).

The AUTOLOAD button(s) is (are) enabled when the key is in the ON position, and disabled, when in the LOCK position.

The AUTOLOAD button initiates autoloading of the RC3502 in question.

The POWER OK indicator is illuminated during power OK condition on the RC3502.

The OPERATING lamp indicates that the RC3502 is running normally.

The TEST MODE lamp indicates that the RC3502 is executing the built-in test programs.

1.2 Processor Front Panel

1.2

The front panel of the processor boards contain five switches, five indicators, and a jack.




Fig. 2. Processor Front Panel, Switches and Indicators

1.2.1 Switches

1.2.1

All of the switches are rotary switches with 16 positions, indicated by the hexadecimal numbers 0 to F. The switches are set by means of a screwdriver.

1.2.1.1 Bus Switches

1.2.1.

The four switches marked BUS are used to supply the processor with data. There is a switch for bits 0 to 3, 4 to 7, 8 to 11, and 12 to 15.

1.2.1.2 Mode Switch

1.2.1.

The switch marked MODE is used to control the baud rate for the console and the execution of the built-in test programs (sect. 1.2.2).

If the mode switch is equal to, or greater than 8, the console is locked to Terminal-mode (T-mode), i.e. the console will not switch to Debug-mode (D-mode) by activating the BELL key (CTRL G). The mode switch is read continuously, so the baud rate may be changed on a running machine. The current value may be examined by the display command Y3F (see 2.2.2).

<u>Settings</u>		<u>Baud Rate</u>	<u>Execution Mode</u>
0	(8)	300 bps	run test, loop
1	(9)	1200 bps	run test, loop
2	(A)	300 bps	skip test
3	(B)	1200 bps	skip test
4	(C)	300 bps	run test, no loop
5	(D)	1200 bps	run test, no loop
6	(E)	300 bps	skip test
7	(F)	1200 bps	skip test

Test Program Execution Modes

**run test**      The test programs are executed whenever the autoload button is pressed.

**skip test**      The test programs are not executed.

loop            The test programs are executed in an endless loop.

no loop        The test programs are executed once.

### 1.2.2 Indicators

### 1.2.2

DI    Disabled Interrupt

This lamp, when lit, indicates that the processor is running in the disabled interrupt mode.

OP    Operating

This lamp, when lit, indicates that the processor is running normally; when it is extinguished, the processor has stopped.

LP    Left Parity Error

This lamp, when lit, indicates that a parity error has been detected during a memory read in the left byte. The lamp can be extinguished only by autoloading.

RP    Right Parity Error

This lamp, when lit, indicates that a parity error has been detected during a memory read in the right byte. The lamp can be extinguished only by autoloading.

TM    Test Mode

This lamp, when lit, indicates that the processor is executing the built-in test programs. The current program is indicated by the DI, OP, LP, RP, and TM lamps, TM representing the least significant bit of the program number.

If an error is detected by a test program, one of the following messages is displayed on the console. The number in front of the following text is the number shown by the indicators DI through TM:

1    8085 Communication Test

Message: ERR00 <dummy><dummy><dummy>

Y68 gives 6 bytes of transmitted data.

Y70 gives 6 bytes of received data.

Y8B is zero after debug/microprogram communications timeout.

3    Interrupt Test

Message: No message.

Test microprogrammed interrupt of control microprocessor. RP and TM are lit.

5 Working Register Address Test

Message: ERR02 <address><errdata><04>  
OK data = address.

7 Working Register Data Test

Message: ERR03 <address><errdata><sub>sub = 01: if lsb.addr = 0 then OK data = AAAA  
else OK data = 5555  
sub = 02: if lsb.addr = 0 then OK data = 5555  
else OK data = AAAA

7 8085 EPROM Sum Test

Message: ERR0B <expected sum><computed sum><dummy>

9 Memory Address Test

Message: ERR04 <address><errdata><sub>Y40 gives the module number under test.

The test will read both by means of word and by byte read. In the latter case OK data is the byte contents of the address read by byte read.

sub = 02: right parity error = R  
04: left parity error = L  
06: left and right parity error = LR  
41: dataerror  
43: dataerror + R  
45: dataerror + L  
47: dataerror + LR

B Memory Data Test

Message: ERR05 <address><errdata><sub>Y40 gives the module number under test.

sub = 02: right parity error = R  
04: left parity error = L  
06: left and right parity error = LR  
40: dataerror, okdata = AAAA  
in addr 0000  
41: dataerror, okdata = 5555  
42: dataerror + R, okdata = AAAA  
43: dataerror + R, okdata = 5555  
44: dataerror + L, okdata = AAAA  
45: dataerror + L, okdata = 5555

46: dataerror + LR, okdata = AAAA  
47: dataerror + LR, okdata = 5555

The test will write alternating AAAA,5555.

D Internal Interrupt Test

Message: ERR06 <low,high><errdata><04>

low = byte with lowest interrupt  
high = byte with highest interrupt

OK data = high.

**F Schedule Test**

Message: ERR07 <param1><errdata><sub>

sub = 01: no external interrupt  
02: maperror, okdata = 07FF  
03: external interrupt or missing  
    "interrupt chain end plug"  
04: maperror, okdata = 0007  
05: coroutine error, okdata = 0007  
06: coroutine error, okdata = param1  
07: medium priority error,  
        okdata = param1  
08: low priority error,  
        okdata = param1  
09: high FF,                       okdata = 000F  
0A: medium FF,                     okdata = 0017  
0B: low FF,                       okdata = 001F

**11 Interrupt Map Test**

Message: ERR08 <address><errdata><04>  
okdata = address.

**13 Prefetch Test**

Message: ERR09 <address><errdata><sub>

sub = 01: load of ICD,          okdata = 5555  
02: load of ICD,              okdata = AAAA  
03: nxtbyte read ICD,okdata = AAAB  
04: nxtword read ICD,okdata = AAAD  
05: nxtbyte read ICD,okdata = address  
06: read of nxtbyte, okdata = address and OFF  
07: ICD,                      okdata = address  
08: nxtword even ICD,okdata = address  
09: nxtword,                  okdata = address  
0A: odd addr,               okdata = address

**15 Register Stack Test**

Message: ERR0A <param1><errdata><sub>

sub = 01: not stack limit  
02: stack limit  
03: size error, okdata = 0016  
04: stack limit  
05: stack limit  
06: data error, okdata = param1+7  
08: stack limit  
09: stack limit  
0A: data error, okdata = param1+7

1.3 Power Supply

1.3

The power supply POW207 is supplied with the following controls:

POWER: Circuit breaker, lit when power on.

POWER OK: Indicator which is illuminated during power ok condition.

POWER FAILURE:

OVER-TEMPERATURE:

OVER-VOLTAGE: Error indicators which are illuminated after an error condition. These indicators are reset after activating the circuit-breaker, or after activating the RESET push-button.

RESET: Push-button for manual generation of an autoload signal and a reset of the error indicators. When this control is activated, the voltage to the crate will be turned off. Use the Autoload button on the OCP to generate an autoload signal without turning off the power.

## 2. CONSOLE OPERATION

2.

The console may be in one of two possible modes: Debug-mode (D-mode) or Terminal-mode (T-mode). A switch between the two modes takes place when the BELL key (**CTRL G**) is activated.

### 2.1 Terminal Mode

2.1

The console may work as terminal for the RC3502 software system, while in T-mode.

An operator process coordinates the communication between the software system and the operator.

#### 2.1.1 Operator Process

2.1.1

Input and output messages to the operator are identified by a name. The operator process holds a variable 'current name', which identifies the current process for input or output.

'current name' is updated in the following situations:

1. **ESC** <name> **NL**

The input line contains a name which is assigned to 'current name'. The operator searches its queue of pending input messages for a message with <name> as identification. If at least one message is found, it is activated. If it is a reactivation, the old input is repeated.

If no message is found, BELL is echoed.

Note:

**ESC** **NL** is attention to 'current name'.

2. By output.

If the output message has name = 'current name', the output message is printed on the console.

If the output message has name <> 'current name', 'current name' is updated and



> "current name"

is printed followed by the text from the output message.

3.  ? 

Prints the identifications of all pending input messages. 'current name' is updated to the last name in the printout.

The operator has a number of facilities for controlling output and for editing purposes:

- |   |   |   |
|---|---|---|
|    | E | - deletes the whole line  |
|    |   | - deletes the last character  |
|   |   | - repeats the whole line  |
|    |   | - deletes the last character.<br>'<-' is echoed.  |
|    | S | - stops output.<br>May be reset by  .  |
|    | Q | - starts output.  |
|    | O | - skips output. The function is alternating between skip and noskip, and is reset to 'no skip' by  . |

Note:

 may be Carriage Return or Line Feed.

### 2.1.2 OPSYS Commands

### 2.1.2

OPSYS interprets the following commands. The underscored characters are sufficient for the interpretation.

More than one command may be typed on one line, unless the syntax is terminated by <nl>.

Whenever <process> or <program> is listed - unless otherwise stated - we refer to incarnations of two program families declared in ADAM with one of the following headings:

```
PROGRAM pip (VAR sv: system_vector);
PROGRAM pop;
```

In the following all numbers are decimal, unless otherwise stated.

BREAK <process>

The child <process> is broken with the current value of excode as exception code.

The child may be any process in the process tree.

E.g.:      BREAK S

CHECK <module>

performs a CRC16 check of the memory module <module>. <module> is the hexadecimal base address. If an error is detected, the word address interval, the expected, and computed checksum are printed.

E.g.:      CHECK F2

CREATE <process> { AS <program> }<sup>1</sup><sub>0</sub>

creates an incarnation of the program <program>. If AS <program> is omitted the program is supposed to have the same name as the process. The size of the stack is the current value of SIZE (see the SIZE command).

E.g.:      CREATE T1 AS TEST CREATE T2 AS TEST

DATE { <year>.<month>.<day> <hour>.<minute>.<seconds> }<sup>1</sup><sub>0</sub>

If the parameters are included the date is initialized. The command always responds with the current date.

E.g.:      DATE 88.06.14 15.30.20

EXCODE <integer>

initializes the current value of excode to <integer>.

Default: excode = -1.

E.g.: EXCODE 47

FREE {<module>}<sup>1</sup><sub>0</sub> <nl>

lists the free interruption levels and memory bytes. If <module> is specified, the free memory areas in the RAM module <module> are listed. The start displacement and size in bytes of the holes are listed, besides the number of holes, the minimum hole, the maximum hole and the sum of the holes.

#### FROM FPA

initializes the current value for load kind to FPA. Load kind controls the kind of driver used for dynamic load (see LOAD). Default load kind is taken from the hexadecimal switches.

E.g.: FROM FPA

HELP lists the available OPSYS commands.

#### IN <inchannel>

initializes the current value of the I/O channel used for load. Default <inchannel> is taken from the hexadecimal switches.

E.g.: IN 81

#### KILL <process>

works as the REMOVE command.

#### LINK <program>

links a program with name <program> to a program declaration in ADAM.

E.g.: LINK CPUSE

LIST {<process>}<sup>n</sup><sub>0</sub> <nl>

lists the process tree with root <process>. If <process> is missing 'adam' is taken as root. The wildcard character '\*' may be used in <process> to specify zero or more occurrences of "I don't care" characters. If wildcard characters occur, only processes

fulfilling the wild compare operation are listed.

The process state 'fault' means that the process has entered the 'exit' state via an exception.

The 'size' and 'used' columns denote the size of the process stack and the used part hereof in bytes.

E.g.:

```
LIST *FS*
process      depth prio state    size    used   stack  regset father
fs           1      -       exit     1000    772 c0.f834  07  adam
bfs          2      -2      wait     764     684 c4.c914  0d  fs
lfs          2      -2      wait    2030    974 c4.c124  0c  fs
fsevent       2      -2      wait     800     306 c4.bcbc  0b  fs
LIST OPSYS
process      depth prio state    size    used   stack  regset father
opsys        0      -1      run      744     642 c0.f28c  06  adam
```

LOAD {<program>}<sup>n</sup><sub>0</sub><n1>

loads the programs from an external device of kind 'current load kind' (see the FROM command) in the I/O channel 'current inchannel' (see the IN command). If no programs are specified, all appearing programs are loaded.

E.g.: FROM FPA IN 81 LOAD PRINTCHAR PRINTNL

A binary relocatable file is loaded from RC8000 via FPA by e.g.:

MAIN35001 = CRC16 {Bxxxx}<sup>n</sup><sub>1</sub>

LOG <module>

prints the contents of the MEM205 or MEM206 errorlog, if not empty.

E.g.: LOG C8

LOOKUP {<program>}<sup>n</sup><sub>0</sub> <n1>

makes a lookup in the LINKER catalog for the listed programs.

If <program> is empty, the whole LINKER catalog is listed. 'LOOKUP PROGRAM' lists all the programs, 'LOOKUP FUNCTION' lists all the functions, 'LOOKUP PROCEDURE' all the procedures, and 'LOOKUP DATA' all the data programs.

Note: The wildcard character '\*' may be used in <program> to specify zero or more occurrences of "I don't care" characters.

E.g.:

```
LOOK *LINK*
>linker
PROGRAM linker      1988.06.09:09.09  1988.06.09:09.12  4020   3.3
PROCEDURE fs_link   1986.11.05:02.05  1987.08.25:22.16  272    0.0
PROCEDURE lf_link   1988.05.16:08.03  1988.05.16:08.10  190    2.14
FUNCTION link       1988.06.09:08.32  1988.06.09:10.16  224    3.20
FUNCTION pi3_link   1988.06.09:08.32  1988.06.09:10.16  224    3.20
PROCEDURE sendlinker 1988.06.09:08.32  1988.06.09:10.16  110    3.20
FUNCTION unlink     1988.06.09:08.32  1988.06.09:10.16  254    3.20
>opsys
```

The output has the interpretation:

1. program kind
2. program name
3. date of source
4. date of compilation
5. size of object code in bytes
6. version

PRINT {<base> {<first disp> {<last disp>
 {<no of words per line> {<delta> } } } } } <n1>

outputs the specified memory area with a fixed

format (see the example): <base>, <first disp>, and <last disp> are hexadecimal.

<delta> defines the default increase of <first disp> if <last disp> is not specified. After the PRINT command <first disp> := <last disp> + 2.

E.g.:

```
PRINT C0 F28C F2AC
      address
c0.f28c  0000      0      0      0
c0.f28e  8201 -32255  130     1
c0.f290  0000      0      0      0
c0.f292  ffff      -1    255   255
c0.f294  0001      1      0      1
c0.f296  0000      0      0      0
c0.f298  00c0     192      0   192
c0.f29a  8eb5 -29003  142   181
c0.f29c  f573 -2701  245   115      s
c0.f29e  4037 16439   64   55      $ 7
c0.f2a0  8064 -32668  128   100      d
c0.f2a2  0003      3      0      3
c0.f2a4  c0f2 -16142  192   242
c0.f2a6  70c0 28864  112   192      p
c0.f2a8  f344 -3260   243   68      D
c0.f2aa  c0f3 -16141  192   243
c0.f2ac  34c1 13505   52   193      4
```

PRIORITY <integer>

initializes the current value for priority used by the START or RUN command.

Default: priority = -2.

E.g.: PRIORITY -1

REMOVE <process>

removes the child <process> of ADAM and the associated subtree.

E.g.: REMOVE S

RENAME <old program> <new program>

changes the name of <old program> to <new program>. Only loaded programs (as opposed to autoloaded), which are not accessed by other programs in the system, may be renamed.

E.g.: RENAME MYPROG XMYPROG

RESTART

removes ADAM and the whole application tree, whereafter a link, create and start of ADAM is executed.

RUN <process> { AS <program> }<sup>1</sup>

links, creates, and starts an process with name <process> of the program <program>.

If <program> is omitted, the program is supposed to have the same name as the process.

E.g.: RUN T1 AS TEST RUN MIRROR

SIZE <integer>

initializes the current value of SIZE in bytes used when creating ADAM children.

Default: SIZE = 0.

(Note: SIZE = 0 will trigger the use of the default create size for the program).

E.g.: SIZE 1526

START <process>

starts the ADAM child <process> with the current value of PRIORITY as priority.

E.g.: START S

STOP <process>

stops the ADAM child <process>.

E.g.: STOP S

UNLINK <program>

unlinks a program with name <program> from a program declaration in ADAM.

E.g.: UNLINK CPUSE

UNLOAD{<program>}<sub>n</sub><sup>1</sup><n1>

deletes the programs from the LINKER catalog, if the programs are not referenced by other programs. If other programs become not referenced after the delete, these programs are also deleted.

E.g.: UNLOAD CPUSE TEST

### 2.1.3 Messages from OPSYS

### 2.1.3

The rest of the command line is skipped if any of the following messages appear:

**\*\*\* loader not ready**

- the LOADER is not included in the system or is unable to run owing to lack of memory.

**\*\*\* command not implemented**

- the command is not available in this version of OPSYS

**\*\*\* syntax error**

- misspelling of a command

**\*\*\* programname missing**

**\*\*\* unknown process**

**\*\*\* unknown program**

**\*\*\* programname busy**

- incarnations of this program still exist

**\*\*\* processname missing**

**\*\*\* name in use**

**\*\*\* no free programdeclarations**

- you must release a program declaration in ADAM by the command UNLINK

**\*\*\* program not loaded**

- the LINKER catalog does not contain the stated program

**\*\*\* program parameters not equal**

- a program with the stated name exists in the LINKER catalog, but the parameter list does not fulfil the declaration

PROCESS pip (VAR sv : system\_vector);

**\*\*\* size too small or too large**

- use the SIZE command to adjust the SIZE parameter

**\*\*\* program not linked**

- use the LINK command

\*\*\* unknown program

- the program is not in the LINKER catalog. The program may be loaded by the LOAD command

\*\*\* program busy

- the program is still accessed by other programs in the system

#### 2.1.4 Messages from LOADER

#### 2.1.4

\*\*\* install more ram memory

- the LOADER cannot get enough memory to run

\*\*\* loaddriver no stack

- the driver cannot be created due to lack of memory

\*\*\* level reservation trouble

- the interrupt level requested for load is occupied by another program incarnation in the system

scan no: x from fpa in xxxx

- initialize load from RC8000 when the first scan is announced (Note: xxxx is decimal). Later scans are performed by the loader itself with no need for operator assistance.

expected: xxxx

received: xxxx

- the crc16 data check reports an error. The programs should be reloaded

end loader

- normal finis message from the LOADER. A list of the loaded programs is printed with name and compilation date. The list may be extended with the information

**\*\*\* warning: versionerror**

- the program should be recompiled, but loading continues

**\*\*\* loadfile unintelligible**

- the loadfile has the wrong format or is garbage.

**\*\*\* overlap**

- the program is already in the LINKER catalog. The program in the catalog is used instead and the loaded program deleted

**\*\*\* not defined**

- the program was not in the LINKER catalog or amongst the loaded programs.

## 2.2 Debug Mode

2.2

### 2.2.1 Activation

2.2.1

If the MODE switch is set in the range 0 to 7, the console may be put in Debug-mode (D-mode) at any time by pressing the BELL key (CTRL and G keys) without stopping instruction execution in the processor. A number of display and control commands become available for technical purposes.

NOTE: In D-mode the commands must be typed with capital letters (e.g. with alpha lock activated).

An illegal command will be displayed as an asterix.

### 2.2.2 Display Commands

2.2.2

Display commands cause the display of eight words of data. The following display commands are available:

M <addr>      Modify Memory  
                    Displays the contents of the 8 memory words starting at <addr>.

W <regset>      Modify Working Registers  
                    Displays the contents of the 8 working registers comprising registerset <regset>.

P <regset>      Modify Register Stack  
                    Displays the contents of the register stack associated registerset <regset>. At most 8 register stack elements are displayed.

L <level>      Modify Working Registers  
                    Displays the level number, the registerset, and the contents of the 8 working registers comprising the register-set connected to <level>.

**Y <yaddr>**      Modify Control Microprocessor RAM  
                  Displays the contents of the 8 control  
                  microprocessor RAM bytes starting at  
                  <yaddr>.

Display commands are executed, when a display command is entered.

One can now modify the displayed data by entering new data in the same positions on the following line. Pressing the space bar will move the cursor one position to the right. All updates are byte per byte.

When a P command is terminated (by CR, +, or -) the cursor position defines the number of register stack elements. If the number has been changed, a # is displayed. Note, that a cursor on the first position does not empty the register stack. This is done by the # key (see later).

A display command is terminated by pressing one of the following keys:

- #      The # key terminates the P command with an empty register stack. Otherwise # is blind.
- CR     The CR key terminates the current display command. The console will await the next command.
- +      The + key terminates the current display command and executes a display command for the succeeding 8 words (M), 8 bytes (Y), up to 8 elements (P), or the 8 registers on the succeeding level (W,L).
- The - key terminates the current display command and executes a display command for the preceding 8 words (M), 8 bytes (Y), up to 8 elements (P), or the 8 registers on the preceding level (W,L).
- .      The . key terminates the current display command and executes a display command for the same 8 words (M), 8 bytes (Y), up to 8 elements (P), or the 8 registers on the same level (W,L).

ESC The ESC key terminates the current display command, but no data modification takes place in the M, W, P, and L commands. The text <ESC> is displayed. The console will await the next command.

### 2.2.3 Control Commands

### 2.2.3

The following control commands are available:

- R            Run  
The processor will start instruction execution.
- S            Instruction Step  
The processor will execute one instruction, stop, and display the current levelno, the registerset, and the contents of the 8 working registers, and reactivate the console. Modification of the displayed data is not possible. The watchdog timer will stop, if started.
- S <steps>    Multi-Instruction Step  
The processor will execute <steps> instructions, stop and reactivate the console.
- Z            Instruction Step  
The command works as the S command. The P display command is performed implicitly, so the contents of the current register stack is also displayed.
- Z <steps>    Multi-Instruction Step  
The command works as the S <steps> command, but a P display command is performed implicitly for each instruction step.
- T <testno>    Single Selftest  
The processor will execute a single selftest, in a loop mode, according to the following table. If testno is chosen as C1-D5, then there will be no error message, and the test will continue even if an error occurs. The memory test is performed on 64K bytes blocks according to the RAM configuration bit map. See app K.

The test can be terminated by use of the ESC key. Errorno + info are explained in 1.2.2.

A 16 bits pass counter can be used in single test execution. It will be set to zero, when the T command is used, and is incremented by one before each pass. The value may be examined, when the T command has terminated after ESC or after an error. Y65 gives the LSB, and Y66 gives the MSB of the pass counter.

testno	testno		
without	with	err	
mess	mess	no	test
00C1	0081	00	fifo test
00C3	0083	-	7.5 interrupt test
00C5	0085	02	W-register address test
00C7	0087	03	W-register data test
00C9	0089	04	memory address test
00CB	008B	05	memory data test
00CD	008D	06	internal intr. test
00CF	008F	07	schedule test
00D1	0091	08	intmap test
00D3	0093	09	prefetch test
00D5	0095	0A	register stack test
00D7	0097	0B	8085 EPROM sum test
00DF	009F	-	'power' restart, but no reset of controllers

#### 2.2.4 Command Parameters

#### 2.2.4

All numbers entered or displayed are hexadecimal.

At any time the entering of an empty command (i.e. pressing the CR key) will cause the previous command to be repeated.

An address (<addr>) is entered using one of the following formats:

<base> : <disp>

or

: <disp>

<base> is the leftmost 8 bits of the 24-bit address.

<disp> is the displacement within the selected memory module, i.e. the rightmost 16 bits of the address.

If the second format (: <disp>) is used, the last entered address base will be echoed and used.

### **3. AUTOLOADING**

3.

The autoload function may be initiated by:

- Power Restart
- Watchdog Restart

#### Power Restart

Power Restart happens:

- when power ON is performed manually on the OCP or on the power supply,
- by temporary power failure,
- by manual activation of the autoload button on the OCP or the AUTO push button on the power supply.

The built-in test programs are activated controlled by the 'MODE' switch, the CPU initializes the registers, whereafter control is passed to the autoload program residing on the first memory module.

#### Watchdog Restart

Watchdog Restart may be activated both manually by means of the 'Y' debug console command and from the software. See app. K.

The CPU initializes the registers, whereafter control is given to the autoload program. No built-in test programs are activated.

3.1 Autoload Switch Format

3.1

The autoload program interprets the four BUS switches on the Processor Front Panel according to the format:

0	1-3	4-7
-----		
! D !	! ! !	! ! ! !
! / !	K I N D	M O D U L E f
! E !	! ! !	! ! ! !
-----		
8-15		
-----		
->! ! !	A D D R E S S	! ! ! !
->! ! !	! ! !	! ! !
-----		

D/EAutoload Disabled/Enabled

is intended for drivers controlling external devices, which may autoload RC3502. A driver may activate the watchdog function if autoload enabled.

0 ~ enabled

1 ~ disabled

KINDAutoload Kind

defines which algorithm the autoload program executes.

0 LAN + X.25/3

Autoload is from RCLAN. If the autoload fails, an X.25/3 autoload via COM204 is initiated. After autoload the software in EPROMs is included.

1 WD

Autoload is from Winchester Disc, and the software in EPROMs is included.

2 FPA

Autoload is from FPA, and the software in EPROMs is included.

3 WD + COM204

Autoload is from Winchester Disc. If the autoload fails, a COM204 autoload is initiated. After autoload the software in

EPROMs is included.

**4 LAN**

Autoload is from RCLAN, and the software in EPROMs is included.

**5 COM204**

Autoload is from COM204 (Intelligent HDLC Controller), and the software in EPROMs is included.

**6 EPROM**

No autoload from external device. Only software in EPROMs is included.

**7 X.25/3**

Autoload is X.25/3 via COM204, and the software in EPROMs is included.

**MODULE #      Module Number**

This switch has different interpretations as a function of KIND.

**KIND = LAN + X.25/3 (0)**

Module# controls the USER name, when the RC3502 tries to LOGON to an FTSSERVER.

KIND   FTSUSER NAME	
0	rc3502<ID register>
1-E	rc35021..rc350214
F	rc3502

The ID register postfix is four hexadecimal digits.

The FTSSERVER's are requested for autoload of the file 'boot3502' N times in a cyclic way. When this limit is reached, the basic FTSUSER name is changed from rc3502 to rr3502 and the cyclic file requesting is continued N times. If no success, a permanent fall back to X.25/3 autoload is performed.

**KIND = WD (1)**

The field has the interpretation:

4-7

```
-----  
! L ! ! ! !  
! U ! C U !  
! N ! ! ! !  
-----
```

CU - defines the Control Unit number of the Disc Controller on the SCSI bus.

LUN - defines the Logical Unit Number of the Winchester Disc at the Disc Controller.

KIND = WD + COM204 (3)

Interpretation as KIND = COM204 (5).

KIND = LAN (4)

Module# controls the USER name, when the RC3502 tries to LOGON to an FTSSERVER.

KIND   FTSUSER NAME	
0	rc3502<ID register>
1-E	rc35021..rc350214
F	rc3502

The ID register postfix is four hexadecimal digits.

The FTSSERVER's are requested for autoload of the file 'boot3502' indefinitely in a cyclic way.

KIND = COM204 (5)

The field has the interpretation:

4-7

```
-----  
! ! ! ! !  
! F ! F A N !  
! ! ! ! !  
-----
```

F - defines the type of load request transmitted on the HDLC line:

- 0 PAXNET loadrequest
- 1 X.25/3 loadrequest

FAN - defines the maximum relative channel no. used for autoload in a cyclic way if a channel fails. Channels 0,1,...FAN relative to the start channel (see later) are used.

KIND = X.25/3 (7)

Module controls the X.25/3 calling algorithm. If the switch is zero, the possible X.121 addresses are tried in a cyclic way. If the switch differs from zero, the X.121 address with the internal index equal to the switch value is used permanently for repeated calls.

ADDRESS specifies the interruption level (input/output channel) depending on the value of KIND.

KIND	ADDRESS
0	CHANNELx128+OFFSETx16+TABLE
1	SAI201 DATA interruption level
2	FPA100 REC interruption level
3	CHANNELx128+COM204 interruption level
4	MFC20X interruption level
5	CHANNELx128+COM204 interruption level
6	'Not used'
7	CHANNELx128+OFFSETx16+TABLE

When kind is 0 or 7 The field has the interpretation:

8-11	12-15
-----	
! A ! ! ! ! ! ! ! !	! / ! O F F S E T ! T A B L E !
! B ! ! ! ! ! ! ! !	-----

A/B - 0 indicates A and 1 indicates channel B.

OFFSET - defines the interruption level offset of the load controller from the reference controller (72 decimal).

TABLE - defines the X.121 address table defined in the current version of the RC3502BOOT prom.

Example 0 Autoload from RclAN via MFC20X with FTSUSER = rc35027 on interruption level 16 (decimal). If the autoload fails after requesting N FTS servers, change FTSUSER to rr35027 and continue with N requests. If the autoload still fails, continue with X.25/3 autoload via COM204, as if the switch settings were 70xx.

-----  
! 07xx ! or ! 87xx !  
-----

#### Conventions:

1. MFC20X interruption level must be 16.

Example 1 Autoload from Winchester Disc with LUN = 1 via disc controller with CU = 2, SAI201 data interruption level 83 (decimal) and SAI201 control interruption level 82 (decimal):

-----  
! 1A53 ! or ! 9A53 !  
-----

Example 2 Autoload from FPA in channel 81 (decimal)

-----  
! 2x51 ! or ! Ax51 !  
-----

Example 3 Autoload from Winchester Disc with LUN = 0 via disc controller with CU = 0, SAI201 data interruption level 87 (decimal) and SAI201 control interruption level 86 (decimal). If the autoload fails, autoload is from COM204 address 92.8000 level 75 (decimal) channel B using PAXNET loadrequest and a fan consisting of 3 channels (see example 5):

-----  
! 3293 ! or ! D293 !  
-----

## Conventions:

1. SAI201 data interruption level must be 87.
2. SAI201 control interruption level must be 86.
3. CU of the disc controller must be 0.
4. LUN of the Winchester Disc must be 0.

Example 4 Autoload from RclAN via MFC20X with FTSUSER = rc3502 on interruption level 16 (decimal).

-----  
! 4F10 ! or ! CF10 !  
-----

Example 5 Autoload from COM204 address 92.8000 level 75 (decimal) channel B using PAXNET loadrequest and a fan consisting of 3 channels:

-----  
! 52CB ! or ! D2CB !  
-----

## Conventions:

1. Start address of the reference controller must be 90.0000.
2. Interruption level of the reference controller must be 72.
3. The controllers must be consecutive and increasing memorywise and according to interruption levels (see the following table).

	! address	! level	! channel	!
Reference Controller	! 90.0000 !	72 !	A !	
	! !	! !	B !	
	! 90.8000 !	73 !	A !	
	! !	! !	B !	
	! 92.0000 !	74 !	A !	
	! !	! !	B !	
First Controller	! 92.8000 !	75 !	A !	
	! !	! !	B !	<- 1)
Last Controller	! 94.0000 !	76 !	A !	
	! !	! !	B !	<- 2)
	! 94.8000 !	77 !	A !	
	! !	! !	B !	
	! 96.0000 !	78 !	A !	
	! !	! !	B !	
	! 96.8000 !	79 !	A !	
	! !	! !	B !	

- 1) first channel in fan  
 2) last channel in fan

Example 6 No autoload, only inclusion of software in EPROMs.

-----  
 ! 6xxx !    or    ! Exxx !  
 -----

Example 7 X.25/3 autoload via COM204 on interruption

level 72 (decimal) channel A using the X.121 address with internal index 2. The X.121 address table is no x.

-----  
! 720x !    or    ! F20x !  
-----

Conventions between controller start address and interruption level are identical as for kind 3 and 5.

### 3.2 Autoload Messages

3.2

boot version x.x

Autoload from mfc level xxH  
user : <FTS User Name>    file : boot3502

- FTS User Name is 'rc3502' appended the contents of the ID Register if the 'module' switch is zero. '1' to '14' is appended if the 'module' switch takes the values 1 to E (hexadecimal). If the 'module' switch is F nothing is appended.

calling : <X.121 address>

calling : cyclic starting at : <X.121 address>

**\*\* end print**

- Announcement of autoload is no longer performed.  
The autoload procedures continue.

Autoload from fpa in xxH

Autoload from com204 addr xx.xxxx level xxH channel xxH

Autoload from eprom

Autoload from wd in xxH (D) xxH (C) CU xx lun xx  
file : /autoloadcat/<entryname>

- <entryname> is taken from the Control Microprocessor RAM. If the first character in this name is zero, the default name 'boot3502' appended the CU of the RC3502 is used.

**\*\*\* undefined switchkind xxH**

.....

- a full stop is printed for every program loaded.

:::

- a colon is printed for every RAM module, which contains programs with a checksum catalog.

;;;

- a semicolon is printed for every PROM module, which contains programs with a checksum catalog.

boot \*\*\* exception: xxxx at: xx.xxxx

- consult appendix I for interpretation of the exception code. The autoload is restarted after one minute.

**\*\*\* level not installed : xx**

- the requested interruption level is not installed. The autoload program is restarted.

**\*\*\* install more memory at : xx**

- more RAM memory must be installed to hold the autoloaded programs. The autoload is restarted.

**\*\*\*\* warning: versionerror at xx.xxxx**

- the program identified by the address must be recompiled to be autoloaded. Consult the output from CROSSLINK for identification. The autoload is restarted.

**\*\*\*\* warning: sumerror module : xx**

- the crc16 data check reports an error in the EPROM module xx. Operation continues.

**\*\*\*\* warning:** <program> not included

- the basic program <program> should be included in the autoloaded programs or in EPROMs. Operation continues.

**\*\*\* sumerror module : xx**

- the crc16 data check reports an error in the RAM module xx. The autoload program will start all over again.

last-block xxxxH  
new-block xxxxH

- block sequence error. The autoload program will start all over again.

**\*\*\* harderror : xx**

- a harderror occurred during autoload from Winchester Disc. The autoload program is restarted.

02 SCSI bus phase error in the selection phase.

09 No connection to the SAI201.

0a Timeout of interrupt from SAI201 control channel in the selection phase.

0b Hard error on SAI201. Reset of SAI201 failed.

12 Parity error on the SCSI bus in the selection phase.

22 SCSI bus phase error in the command phase.

2a Timeout of interrupt from SAI201 control channel in the command phase.

- 32 Parity error on the SCSI bus in the command phase.
- 42 SCSI bus phase error in the data input phase.
- 4a Timeout of interrupt from SAI201 control channel in the data input phase.
- 52 Parity error on the SCSI bus in the data input phase.
- 62 SCSI bus phase error in the data output phase.
- 6a Timeout of interrupt from SAI201 control channel in the data output phase.
- 72 Parity error on the SCSI bus in the data output phase.
- 82 SCSI bus phase error in the status phase.
- 8a Timeout of interrupt from SAI201 control channel in the status phase.
- 92 Parity error on the SCSI bus in the status phase.
- a2 SCSI bus phase error in the message phase.
- aa Timeout of interrupt from SAI201 control channel in the message phase.
- b2 Parity error on the SCSI bus in the message phase.

**\*\*\* filelimit : root xxxx**

- The catalog with name 'autoloadcat' is not found in the root catalog. The autoload program is restarted.

**\*\*\* filelimit : autoloadcat xxxx**

- The announced autoloadfile is not found in the catalog 'autoloadcat'. The autoload program is restarted.

**\*\*\* filelimmit : <autoloadfile> xxxx**

- The announced autoloadfile is unintelligible. The autoload program is restarted.

3.3 Generating Autoload Files

3.3




Fig. 3. Autoload File Generation

3.3.1 Generating an FTS Autoloadfile

3.3.1

If the file 'coreimage' has been produced on RC8000 by the 'CROSSLINK' program, the following call will generate a file with a format for autoload via RcLAN by the FTS protocol. The file 'boot3502' must be placed at the FTS Server under the proper catalog bases or directory. The FTS Username is controlled by the 'module' switch on RC3502.

```
boot3502 = convertplib coreimage
```

3.3.2 Generating an FPA Autoload

3.3.2

If the file 'coreimage' has been produced on RC8000 by the 'CROSSLINK' program, the following call will autoload the RC3502 if connected via the process 'main35001':

```
main35001 = crc16 coreimage
```

3.3.3 Generating TES202 Eproms

3.3.3

Consult ref. 6.

**4. ERROR PROCEDURES**

4.


For use in error situations it might be useful to get testoutput from the autoload program 'BOOT' or from the program MONITOR which starts and stops program incarnations.

**4.1 Monitor Testoutput**

4.1

The monitor stack address is obtained by the LIST MONITOR command to OPSYS or from the testoutput from BOOT (see 4.2).

If a bit is set in the byte, the testoutput associated the bit will be generated.




Initial value = 0.

**4.2 Boot Testoutput**

4.2

The BOOT stack address is xx.F800 where xx is the base address of the last RAM memory module in the RC3502. If testoutput during autoload from FPA is wanted, you must increase the software time out in the FPA xmt driver in RC8000 from 1 sec. to at least 5 sec.



**REFERENCES**

1. PN: 99000484  
PASCAL80, Report
2. PN: 99104398  
PASCAL80, User's Guide
3. PN: 99103509  
PASCAL80, Driver Conventions
4. RCSL No. 52-AA1192  
RC3502-2 Reference Manual
5. PN: 99000994  
RC3502-2 Real-Time Pascal  
Reference Manual
6. PN: 99103221  
RC3502 PROM Blasting Program  
User's Guide
7. RCSL No. 52-AA1177  
CPU212-219 Technical Manual
8. RCSL No. 52-AA1197  
RC3502-2 Microprogram Listing
9. PN: 99000990  
Debugger Listing ROB984

**B.** OPSYS COMMANDS**B.**

break <process>

check <module>

create <process> as <program>

date <year>.<month>.<day> <hour>.<minute>.<seconds>

excode <integer>

free <module> <n1>

from fpa

help

in <inchannel>

kill <process>

link <program>

list <process> <n1>

load <program> <n1>

log <module>

lookup <program> <n1>

print <base> <firstdisp> <lastdisp>  
          <no\_of\_words\_per\_line> <delta>                  <n1>

priority <integer>

remove <process>

rename <oldprogram> <newprogram>

restart

run <process> as <program>

size <integer>

start <process>

stop <process>

unlink <program>

unload <program> <n1>

**C. AUTOLOAD SWITCH LAYOUT**

C.

0	1-3	4-7
! D !	! ! !	! ! ! !
! / !	K I N D	M O D U L E & !->
! E !	! ! !	! ! ! !

8-15							
! ! !	! ! !	! ! !	! ! !				
->! !	A D D R E S S						
! ! !	! ! !	! ! !	! ! !				

D/E - Autoload Disabled/Enabled

```

disabled = 1
enabled = 0

```

Intended for drivers controlling External Devices, which may autoload RC3502. The drivers may activate the watchdog function, if D/E = 0. BOOT ignores this switch.

KIND

```

0 LAN + X.25/3
1 WD
2 FPA
3 WD + COM204
4 LAN
5 COM204
6 EPROM
7 X.25/3

```

ADDRESS

```

SAI201 DATA interruption level if WD
  (CONTROL = DATA -1)
  Interruption level if FPA or LAN
  Channelx128+interruption level if COM204 or WD+COM204
  Channelx128+offsetx16+table if X.25/3 or LAN+X.25/3

```

MODULE #


```

LUN x 8 + CU if WD
Load request x 8 + fan if COM204 or WD+COM204
Cyclic or specific call if X.25/3
FTS User Name if LAN or LAN+X.25/3

```

**D. SECRET VECTOR LAYOUT**

D.



**E. INSTRUCTION CODES**

E.

001: except	2b1: 401bx	551: not	801: mwt	601: revl8	1
011: rec1	2c1: mtrh	1 1	611: setcr	621: moveb	?
022: rec2	2d1: forsc	571: settm	631: findhp	641: stvst	?
033: rec3	2e1: mtrs	581: settlm	651: rvsb2	661: revat	?
044: rec4	2f1: mnood	591: seteq	671: svsh4	681: rvlbs	?
055: rec5	301: usdhw1	5a1: setsb	684: revnk	691: ready	?
066: rec6	306: readsl *	5b1: seted	695: rvsb4	6b1: rvlws	?
077: rec7	311: ult	5c1: getun	696: svsh6	6c1: rvlans	?
088: rec8	321: eq	5d1: settin	697: rvsb6	6d1: rvlndns	?
099: rec9	331: ne	5e1: setd1	698: rec0	6e1: current	?
0a0: rec10	341: lt	5f1: setad	699: reseed	6f1: curram	?
0b1: rec11	351: ot	601: mw1s	701: hrt	711: mult	?
0c2: rec12	361: ls	611: mc1s	702: stvhb	721: mc1st	?
0d3: rec13	371: oe	621: jmrzea	703: b71: revly	722: readid	1
0e4: rec14	381: indh0	631: jmrze	704: b71: revsh	731: rvg12	2
0f5: rec15	391: indh1	641: jmr1t	705: b71: rvsb1	741: read1d	?
100: csion	3a1: toden	651: jmrqt	706: b71: revsw	751: rvg4	2
111: crele	3b1: tlock	661: jmz1e	707: bb1: rvsb3	761: uathw	?
122: moves	3c1: tqad	671: jmzde	708: bc1: revge	771: read3	?
133: clnwa	3d1: cn111	681: jmprv	709: bd1: rvsb5	781: rvg16	?
144: coutwa	3e1: mmu1	691: lmdhc	710: be1: revsd	791: read4	?
155: csens	3f1: madd	6a1: jmdqo	711: b71: rvg7	7e1: read5	?
166: irele	401: cwait	6b1: jmch1	712: bb1: rvsb4	7f1: read6	?
177: mtme	411: msub	6c1: intro	713: b71: revb	811: svsh2	2
188: mhalt	421: usdd	6d1: index	714: b71: rvsb2	821: rvgm2	?
199: except	431: usub	6e1: intpe	991: svsh1	931: mwt	1
1a0: csel1	441: add	6f1: inpdv	941: stvsh	951: stvds	1
1b1: cstod	451: sub	701: forbb	951: svgh3	961: rvd1s	1
1c1: cstart	461: umul	711: forbb	961: stvgs	971: revds	1
1d1: locc1	471: ud1y	721: lowbbc	971: rvsb5	981: setst	1
1e1: cslev	481: umod	731: lowth	981: stvsd	991: fndh12	?
1f1: cgreq	491: mul	741: forbw	991: svsh7	1011: svsh8	?
202: mw1	4b1: div	751: forbw	601: mw1t	611: mc1t	?
211: lowc	4b1: mod	761: lowbw	621: svsh2	631: stcpe	?
222: fors	4c1: and	771: lowbw	641: rvsb4	651: revod	?
233: forw	4d1: or	781: pce190	651: rvsb2	661: rev1d	2
244: loww	4e1: xor	791: pce191	661: rvsb1	671: stv1d	?
255: loao	4f1: crc16	7a1: pce18	671: rvsb6	681: rvsb2	?
266: looi	501: neg	7b1: pex1c	681: rvsb6	691: rvsb2	?
277: fonc1	511: abs	7c1: lpush	691: rvsb6	701: rvsb2	?
288: mrest	521: comp1	7d1: lpop	701: rechw	711: read2	2
299: mstat	531: shc	7e1: lrese	711: rvsb8	721: read3	?
2a0: locda	541: shcb	7f1: llock	731: static	741: cexch	1
			751: rvsb9	761: rpsic	except

**F. INSTRUCTION MNEMONICS**

abs	51	101bx	2b	moveb	12	rec4	74	rvsa6	c7	stv18q	16
edd	44	1one1	27	moveq	66	rec5	75	rvsb	68	stv18q	ca
end	4c	1orbb	71	mrecha	81	rec6	76	rvsb0	69	stv18q	cc
cexch	1e	1orbbc	70	mrest	78	rec7	77	rvsh1	69	stv18q	6n
cgreg	14	1orbw	75	matst	29	rec8	78	rvsh2	83	stv1d	78
cinwa	13	1orbwC	74	msub	41	rec9	79	rvsh3	66	stv1d	66
compl	52	1or9	22	mtine	17	rec10	79	rvsh4	85	stv1w	66
cputw	14	1orc	2d	mtrh	2c	rec11	79	rvsh5	67	stv1w	66
cputwq	14	1orw	23	mtrs	28	rec12	79	rvsh6	67	stv1w	66
crc16	44	1owbb	73	mu1	49	rec13	79	rvsh7	67	stv1w	66
crele	11	1owbbC	72	mw1	29	rec14	79	revad	6e	stv1w	62
creat	91	1owbw	77	mw19	66	rec15	79	rvsd0	76	stv1w	64
crput	b1	1owbwC	76	mw1st	69	rec16	79	rvsd1	73	stv1w	66
crputb	de	1owc	21	mw1t	69	rec17	79	rvsd2	73	stv1w	66
crram	18	1oww	24	mwst	69	rec18	79	rvsd3	75	stv1w	66
csell	15	jmcnt	6b	mw1t	69	rec19	79	rvsd4	75	stv1w	66
csens	16	jmcnt	6b	ne	33	rec20	79	rvsd5	77	stv1w	66
cs1un	1e	jmoge	66	neg	58	rec21	79	rvsw0	72	stv1w	66
cslev	1c	jmpnc	69	not	55	rec22	79	rvsw1	72	stv1w	66
castart	1b	jmprw	68	or	4d	rec23	79	rvsw2	65	stv1w	66
castop	4b	jmsa	62	pcals	78	rec24	79	rvsw4	75	stv1w	66
cwait	4b	jmgje	67	pcals0	78	rec25	79	rvsw6	77	stv1w	66
cwram	d1	jmgjt	65	pcals1	79	rec26	79	rvsw7	77	stv1w	66
div	48	jmz1e	66	pexit	7b	rec27	79	setdm	68	stv1w	66
eq	32	jmz1t	64	read	1b	rec28	79	setcr	68	stv1w	66
exception	60	jmzone	63	readb	95	rec29	79	setdi	56	stv1w	66
exception	19	je	36	readw	78	rec30	79	setdp	54	stv1w	66
ge	37	lock	74	readw	78	rec31	79	seteo	59	stv1w	62
gt	35	1pop	7d	readd	64	rec32	79	setin	5d	stv1w	64
index	6d	1push	7c	readgs	60	rec33	79	setre	64	stv1w	66
irel1	38	irel1e	16	read1	62	rvldns	68	setgb	58	stv1w	45
irelse	6d	irelse	7e	read1d	65	revlba	8b	setgb	5b	stv1w	45
it	34	reald	64	read1d	64	revld	77	setst	ec	stv1w	3b
madd	31	realds	c1	rvldns	6d	settm	57	settm	57	stv1w	3d
mbset	db	reald	fc	revlds	eb	setun	5c	topen	58	stv1w	3d
1ndh11	cd	reasd	6c	revlw	b7	setdd	53	uedd	42	stv1w	3d
1ndh12	ed	reasd1	61	rvlwns	fb	shc8	54	uaddr	66	stv1w	3d
1ndhv	6f	mc1g	61	revlw	fb	stcen	66	uaddr	66	stv1w	3d
1nth9	c1	mc1st	e1	revxd	fd	stnh	67	udiv	47	stv1w	3d
intp0	6e	mc1st	e1	rechd	68	sttc	64	ult	31	stv1w	3d
intrs	6c	mhalt	19	rechw	68	revpw	67	umod	44	stv1w	3d
loc1	1d	mm1	3e	rec0	68	revs	62	umod	46	stvab	92
locda	28	mmod	21	rec1	71	rvsa0	14	umod	46	stvab	92
log1	26	mod	4b	rec2	72	rvsa2	c3	uguh	43	stvab	92
				rec3	c5	rvsa4	c5	xor	49		

G. PROCESS DESCRIPTOR LAYOUT

G.

Dec	Hex
0	0
2	2
4	4
6	6
8	8
10	A
2	C
4	E
6	10
8	2
20	4
2	6
4	8
6	A
8	C
30	E
2	20
4	2
6	4
8	6
40	8
2	A
4	C
6	E
8	30
50	2
2	4
4	6
6	8
8	A
60	C
2	E
4	40
6	2
8	4
70	6
2	8
4	A
6	C
8	E

**H. MESSAGE HEADER LAYOUT**

H.

Dec	Hex
0	0
2	2
4	4
6	6
8	8
10	A
12	C
14	E
16	10
18	12
20	14
22	16
24	18
26	1A

I. EXCEPTION CODES

I.

<u>Code (Hex)</u>	<u>Meaning</u>
1	- parity error
2	- registerstack error
3	- undefined opcode
4	- odd number of bytes
5	- stack overflow
6	- pointer = nil
7	- signal: reference = nil - push: first param = nil - pop: second param = nil - lock: reference = nil - reference = nil
8	- wait: reference <> nil - pop: first param <> nil
9	- push: param locked - pop: second param locked - signal: reference locked - reference locked
A	- lock overflow
B	- arithmetic overflow
C	- index out of bounds
D	- subrange out of bounds
E	- illegal zonestate
F	- field overflow
10	- move wraparound
11	- push: identical arguments
12	- push: first param not empty - lock: size error - size too small
13	- lock: not data message
14	- top <= offset - not data message
15	- not channel message
16	- word block i/o: odd number of bytes
17	- block i/o at level 0
18	- setcr: first limit negative
19	- setad: truncation error
1A	- no resources
1B	- file does not exist
1C	- position outside file
1D	- wrong answer
1E	- setpriority: illegal priority
1F	- pool: no core
20	- process = nil
21	- arithmetic overflow
22	- system error
23	- system error

24            - illegal switch in case construction  
25            - upper limit in call of succ  
26            - lower limit in call of pred  
27            - with: size error  
28            - lockdata: top < computed top  
29            - local reference variable not nil at routine exit  
2A            - local process variable not nil at routine exit  
2B-2E        - system error  
2F            - break by father

**J. WORKING REGISTER LAYOUT**

J.

Description of the working registers:  
(for a more detailed description, refer to the  
reference manual, ref. 4)

**W: Index:**

00	000-007	regset 0
01	008-00F	regset 1
-	-	-
79	3C8-3CF	regset 121
7A	3D0-3D7	work regset for multiplications
7B	3D8-3DF	masks0
7C	3E0-3E7	masks1
7D	3E8-3EF	breakpointset
7E	3F0-3F7	monitorset
7F	3F8-3FF	com8085

## regset 0 thru regset 121:

1st	reg.	ps
2nd	reg.	sb
3rd	reg.	gf
4th	reg.	lf
5th	reg.	lu
6th	reg.	lm
7th	reg.	ib
8th	reg.	ic

## breakpointset:

1st	reg.	breakpointmode (8000 means breakpoint active)
2nd	reg.	breakpointbase
3rd	reg.	breakpointdisp
4th	reg.	unused
5th	reg.	unused
6th	reg.	unused
7th	reg.	unused
8th	reg.	unused

## monitorset:


1st	reg.	memregsetbase
2nd	reg.	memregsetdisp
3rd	reg.	waitqueuelast
4th	reg.	waitqueuefirst
5th	reg.	monitorlevel
6th	reg.	unused
7th	reg.	unused
8th	reg.	unused

com8085:

1st reg.	parityerrorregset
2nd reg.	fifo0, fifo1
3rd reg.	fifo2, fifo3
4th reg.	fifo4, fifo5
5th reg.	cow (value, disp)
6th reg.	message.errorcode
7th reg.	parityerrorbase
8th reg.	parityerrordisp

**K. CONTROL MICROPROCESSOR RAM LAYOUT**

K.



RTC level:

Real Time Clock interruption level.

TTO level:

Console output interruption level.

TTI level:

Console input interruption level

Timer:

-----  
! Low ! High !  
-----  
3        4

RC3502 is interrupted on level "RTC level" every  
(256 x High + Low) x 2.5 mS.

Watchdog:

-----  
! Low ! High !  
-----  
5        6

Count down is performed every 2.5 mS. RC3502 is  
reset, when (if) watchdog.high is decremented  
from 1 to 0.

TTI input:

When an input character from the console is  
ready, the character is delivered here and  
RC3502 interrupted on level "TTI level".

TTO output:

RC3502 delivers an output character for the con-  
sole here, and is interrupted on level "TTO  
output", when the character is printed.

Version:

-----  
! Model ! Micro !  
-----  
9

Model is 1 for RC3502-1 and 2 for RC3502-2.  
Micro is the micro program version number.

Switches:

10	11
-----	
! 0-3 ! 4-7 ! 8-11 ! 12-15 !	
-----	
A	B

Contains the current value of the four switches marked BUS on the Processor Front Panel.

Interruption Levels:

Describes the 128 interruption level configuration. Level i exists if bit no i is set in the Interruption Level bitmask. Levels 0-7 are described in byte 12, Levels 8-15 in byte 13, etc.

RAM Modules:

Is a bitmask, describing the RAM module configuration. A module is 64Kb. A module exists, if the corresponding bit is set in the bitmap.

Modules A0, A2, ..., AE are described in byte 28, modules B0, B2, ..., BE in byte 29, etc.

EPROM Modules:

Is a bitmask, describing the EPROM module configuration. A module is at most 64Kb. A module exists, if the corresponding bit is set in the bitmap. Modules A0, A2, ..., AE are described in byte 34, modules B0, B2, ..., BE in byte 35, etc.

ID register:

40	41
-----	
! 0-7 ! 8-15 !	
-----	
28	29

The contents of the IDR201 register may be examined here.

COM204 mask:

Controls the COM204 channels during down line load. If bit i is set the channel is skipped, otherwise a load request frame is transmitted on the channel.

Result:

If a down line load is successful, this byte contains the resultant relative channel plus 8, where  $0 \leq \text{channel} \leq 7$ .

If autoload is from Winchester Disc, the CU address of the RC3502 on the SCSI bus is passed here.

Entryname:

Controls autoload from Winchester Disc.

If the first character in Entryname is zero, the default name 'boot3502x' is used, where x is the CU address of the RC3502 on the SCSI bus.

Otherwise Entryname is used for lookup in the catalog 'Autoloadcat'.

Cswitches:

Contains a copy of the field switches.

The contents of switches is transferred to Cswitches, whenever the autoload program is started, and the first byte of Cswitches equals zero. The contents of Cswitches controls the autoload program.

Printcount:

Controls the number of times autoload announcements is performed.

L.**INSTALLATION STANDARDS AND RECOMMENDATIONS**L.

This is a recommendation concerning installation of hardware modules in the RC3502. The guidelines concern interruption levels, input/output priorities, module number selections, DMA priority.

L.1**Input/Output Modules**L.1

The priorities and interruption levels in the following table should be followed according to input/output channels and priority. The first module in a group should be the lowest channel number.

L.2**Memory Modules**L.

Memory modules are strapped to cover one or more module addresses in the memory address space. They must not overlap. There must exist at least one RAM memory module with address C0 and at least one PROM memory module containing the BOOT program in module address E0. If the autoloaded programs occupy more than one module, there must be RAM memory modules with address C2, C4, etc. MEM204 RAM memory modules can be placed in the address space C0-DE. MEM205, MEM206, MEM207, and MEM209 RAM memory modules can use 80-FE. A special action can be taken on MEM204 to disable the PROM area, which is always equal to RAM module address + 20 (hex). The PROM memory module address on MEM205 and MEM206 may be set completely free in the whole address space, or may be disabled. The PROM areas E0 or E2 may be disabled on MEM207 and MEM209.

TES201 and TES202 can be strapped in the address space C0-FE. (Note, that C0 must always be used as RAM memory).

L.3 Controllers

L.3

COM204 occupies 2 positions. The one position connects to the Back Plane Bus. In the second position a CBL714 must be placed.

By convention the first COM204 must be strapped to dual port memory module address 90 (hex) and interruption level 72 (decimal). See page 29.

IMS208 through IMS212 occupies one position.

By convention the first IMS2XX must be strapped to dual port memory module address 80 (hex) and interruption level 8. The succeeding IMS2XX controllers must be set to 80.4000 and level 9, i.e. memory module addresses increase by 4000 (hex) and interruption levels by 1.

L.4 Summary

L.4

!	!	!	!	!	2.	1.	!	2.	1.	!	2.	1.	!
!	!	!	!	!	!	!	!	!	!	!	!	!	!
! C	! C	! C	! I	! I	!	C	! C	V	! V	!	!	!	!
! P	! P	! P	! O	! O	!	O	! O	C	! C	!	!	!	!
! U	! U	! U	! M	! M	!	M	! M	O	! O	!	!	!	->
! 2	! 2	! 2	! 2	! 2	!	2	! 2	2	! 2	!	2	!	!
! 1	! 1	! 1	! 0	! 0	!	0	! 0	0	! 0	!	0	!	!
! 5	! 6	! 7	! 2	! 2	!	4	! 4	1	! 1	!	1	!	!
!	!	!	!	!	!	!	!	!	!	!	!	!	!

!	!	!	!	!	!	!	!	!	!	!	!	!	!
!	2.	1.	!	2.	!	1.	!	2.	!	1.	!	2.	!
!	!	!	!	!	!	!	!	!	!	!	!	!	!
! C	! C	! M	! M	! I	! I	I	! M	M	! M	T	! T	!	!
! O	! O	! F	! F	! M	! M	M	! E	E	! E	E	! E	!	!
->!	M	! M	! C	! C	! S	S	! M	M	! M	S	! S	!	!
! 2	! 2	! 2	! 2	! 2	!	2	! 2	2	! 2	! 2	!	2	!
! 0	! 0	! 0	! 0	! 0	X	X	! 0	0	! 0	0	! 0	!	0
! 5	! 5	! X	! X	! X	X	X	! X	X	! X	X	! X	!	!
!	!	!	!	!	!	!	!	!	!	!	!	!	!

The following three points should be observed:

1. The interruption level priority chain starts at the CPU and must not be broken by empty positions until the last module, which uses interruption level priority. At the end of the chain, there must be an "interrupt chain end plug" (CBL735).
2. The DMA priority chain starts at the CPU and must not be broken by empty positions until the last module, which uses DMA priority.
3. The module, which is closest to the CPU, has highest priority, both according to interrupt level and DMA.

!	!	!	Dual Port	!	No. of	!	!
!	!	Interrupt	Memory	!	interrupt	!	!
!	Module	level	Base	!	levels	!	No. x
!	name	(Hex)	(Hex)	!	(Decimal)	!	salesnumber
!		Lowest	!	!		!	!
!		priority	!	!		!	!
!	CPU	00-04	!	-	!	5	!
!	SPARE	05-07	!	-	!	3	!
!	IMS2XX	08-0F	!	80-8E	!	8	! 8 x RC3542 !
!	MFC20X	10-1F	!	-	!	16	! 16 x RC3532 !
!	COM205	20-2F	!	-	!	16	! 16 x RC3547 !
!	VCO201	30-37	!	-	!	8	! 8 x RC3583 !
!	COM204	48-4F	!	90-96	!	8	! 8 x RC3546 !
!	IOM202	50-6F	!	-	!	32	! 4 x RC3521 !
!	SPARE	78-7E	!	-	!	4	!
!		Highest	!	!		!	!
!		priority	!	!		!	!

M. INDICESM.1 Survey of Figures

1. OCP for Rack with up to Three RC3502 .....	2
2. Processor Front Panel, Switches and Indicators ...	3
3. Autoload File Generation .....	40

M.2 Catchword Index

address.....	31
as.....	12, 17
AUTOLOAD.....	2, 27, 41
break.....	12
CBL714.....	61
CBL735.....	62
check.....	12
COM204.....	29, 33, 61, 62
COM204 mask.....	59
COM205.....	62
create.....	12
cswitches.....	59
D-mode.....	10, 22
date.....	12
Debug-mode.....	10
entryname.....	59
EPROM.....	29
EPROM Modules.....	58
ERR00.....	5
ERR02.....	6
ERR03.....	6
ERR04.....	6
ERR05.....	6
ERR06.....	7
ERR07.....	8
ERR08.....	8
ERR09.....	8
ERR0A.....	8

ERROR.....	6
exode.....	12
f.....	31
fan.....	31
FPA.....	13, 28, 33
free.....	13
from.....	13
help.....	13
ID register.....	58
IMS208.....	61
IMS212.....	61
IMS2XX.....	62
in.....	13
indicators.....	3, 5
installation.....	60
Interruption Levels.....	58
IOM202.....	62
jack.....	3
kill.....	13
kind.....	28
L.....	22
LAN.....	28, 29
link.....	13
list.....	13
load.....	14
log.....	14
lookup.....	15
M.....	22
MEM204.....	60
MEM205.....	60
MEM206.....	60
MEM207.....	60
MEM209.....	60
MFC20X.....	62
module.....	29
OCP.....	2
offset.....	32
P.....	22
POW207.....	9
power restart.....	27

print.....	15
printcount.....	59
priority.....	17
R.....	24
RAM Modules.....	58
RC3521.....	62
RC3532.....	62
RC3542.....	62
RC3546.....	62
RC3547.....	62
RC3583.....	62
remove.....	17
rename.....	17
restart.....	17
result.....	59
RTC level.....	57
run.....	17
S.....	24
size.....	17
standards.....	60
start.....	18
stop.....	18
switches.....	3, 4, 58
T.....	24
T-mode.....	10
table.....	32
Terminal-mode.....	10
TES201.....	60
TES202.....	60
testoutput.....	42
timer.....	57
TTI input.....	57
TTI level.....	57
TTO level.....	57
TTO output.....	57
unlink.....	18
unload.....	18
VCO201.....	62
version.....	57
W.....	22
watchdog.....	57
watchdog restart.....	27
WD.....	28

x.25/3.....	29
Y.....	23

## **RETURN LETTER**

**Title:** RC3502-2 Operating Guide

**RCSL No.:** 99001059

**A/S Regnecentralen af 1979/RC Computer A/S maintains a continual effort to improve the quality and usefulness of its publications. To do this effectively we need user feedback, your critical evaluation of this manual.**

**Please comment on this manual's completeness, accuracy, organization, usability, and readability:**

---

---

---

---

**Do you find errors in this manual? If so, specify by page.**

---

---

---

---

**How can this manual be improved?**

---

---

---

---

**Other comments?**

---

---

---

---

**Name:** \_\_\_\_\_ **Title:** \_\_\_\_\_

**Company:** \_\_\_\_\_

**Address:** \_\_\_\_\_

**Date:** \_\_\_\_\_

**Thank you**

..... **Fold here** .....

..... **Do not tear - Fold here and staple** .....

Affix  
postage  
here



**Information Department  
Lautrupbjerg 1  
DK-2750 Ballerup  
Denmark**