
Title:

RC 36-00240.02
LINE RELIABILITY (Synchron)
OPERATING INSTRUCTION

 **REGNECENTRALEN**

RC SYSTEM LIBRARY: FALKONERALLE 1 DK-2000 COPENHAGEN F

RCSL No: 44-RT 1642
Edition: 77.03.10
Author: Ole Sylvest

Keywords:

Musil, Device Reliability, Synchronous Line, Test

Abstract:

The following pages present the first, general pages of the reliability program listing.

These pages form an operating guide to the program

LOAD After autoloading of

RC 3600 SYSTEM MAINTENANCE

Tape/Disc, or while running RC 3600 MUS/DOMUS software (only for RC 3600 systems), this device reliability program can be loaded and executed the following way:

After contact with operative system = S
(refer to previous chapters or the system operating guide) type:

LOAD TIME < 1 > < 2 > < 3 > < 4 > P240

RETURN

1: R40R = RC 3680C Sync. Comm. Control
R4MR = RC 3681 Sync. Comm. Multiplexer
2: R40X = RC 3680C Sync. Comm. Control
R4MX = RC 3681 Sync. Comm. Multiplexer

EVENTUAL Log Device, - if not TTY:

3: LPT	=	Line Printer	4: Empty	=	ASCII
CPT	=	Charaband Printer	TAB1	=	ASCII
SP	=	Serial Printer	TAB2	=	RC Standard
			TAB3	=	PL 1
			TAB4	=	Hungarian
			TAB5	=	Cyrillic

0064
0065
0066
0067
0068
0069
0070
0071
0072
0073
0074
0075
0076
0077
0078
0079
0080
0081
0082
0083
0084
0085
0086
0087
0088
0089
0090
0091
0092
0093
0094
0095
0096
0097
0098
0099
0100
0101
0102
0103
0104
0105

TITLE: LINE RELIABILITY TESTER,

ABSTRACT: THIS PROGRAM TESTS TRANSMISSION LINES,
EITHER USING THE SCC702 OR THE SMX701
CONTROLLER, IN LOOPBACK MODE.

SIZE: 17770 BYTLS, MAX BUFFERSIZE = 2350 BYTES.

DATE: APRIL 4TH 77.

GENERAL INFORMATION:

THIS PROGRAM ACTS IN FOLLOWING WAY: AFTER ALL
PARAMETERS HAS BEEN ANSWERED AND A START COMMAND
HAS BEEN GIVEN. A BLOCK WILL BE SEND WITH SPECIFIED
SIZE AND RECEIVED AGAIN USING THE LOOP BACK FUNCTION.
IF ERROR OCCURS THE ERRORS WILL BE ACCUMOLATED. IF ITS
TIME FOR MEANWHILE LOGGING IT WILL BE DONE. THE BLOCKS
WILL BE SEND JUST AS MANY TIMES AS THE RUNTIME HAVE
BEEN SPECIFIED.

NOTE:

IF PARAMETERS ARE ANSWERED WRONG THEN THE RELEVANT
QUESTION WILL BE DISPLAYED AGAIN.

DRIVER FOR PROGRAM:

INTERPRETER, R40X, R40R, IF SCC702, TIME,
INTERPRETER, R4MX, R4MR, IF SMX701, TIME,
IF OTHER LOGDLVICES IS USED THEN
THEIR DRIVERS HAVE TO BE LOADED.

SPECIAL REQUIREMENTS:

CODEPROCEDURE P0001 (TIME)	RCSL: 43-GL182
CODEPROCEDURE P0023 (DELAY)	RCSL: 43-GL1409
CODEPROCEDURE P0035 (CHANGTABLE)	RCSL: 43-GL1519

0106
0107
0108
0109
0110
0111
0112
0113
0114
0115
0116
0117
0118
0119
0120
0121
0122
0123
0124
0125
0126
0127
0128
0129
0130
0131
0132
0133
0134
0135
0136
0137
0138
0139
0140
0141
0142

CALULATIONS:

EFFECTIVE TIME:= TIME USED - (PROCESS OWERHEAD FOR DISPLAYS AND CALCULATIONS).

WHEN USING COMMAND "STAT" EFFECTIVE BIT PR SECOND IS: ;

BPS:=(NUMBER OF GOOD BLOCKS * BLOCKSIZE * 8)/ EFFECTIVE TIME

WHEN USING COMMAND "DISP" EFFECTIVE BIT PR SECOND IS:

BPS:=(NUMBER OF GOOD BLOCKS SINCE LAST LOG * BLOCKSIZE * 8) / EFFEC- TIVE TIME SINCE LAST LOG.

ERRORRATE:= (FAILED BLOCK * 100) / RECEIVED BLOCKS,

BIT RATE PR SECOND CALCULATED AS:

TIMER2:= BLOCKSIZE / (BIT RATE/8) + 1

RUNTIME PARAMETERS:

NOTE THAT NOT ALL RUNTIME PARAMETERS WILL BE DISPLAYED, ONLY PARAMETERS MARKED WITH STARS, THE OTHERS WILL ALL HAVE DEFAULT VALUES, TO CHANGE DEFAULT PARAMETERS LOOK AT PAGE 08.

0143
0144
0145
0146
0147
0148
0149
0150
0151
0152
0153
0154
0155
0156
0157
0158
0159
0160
0161
0162
0163
0164
0165
0166
0167
0168
0169
0170
0171
0172
0173
0174
0175
0176
0177
0178
0179
0180
0181
0182
0183
0184
0185
0186
0187
0188
0189
0190
0191
0192
0193
0194
0195
0196
0197
0198
0199
0200
0201
0202
0203
0204
0205
0206
0207
0208
0209
0210

****TYPE (SCC) IF TEST OF SCC702 ELSE (SMX) FOR THE SMX701
 TO TELL WHICH CONTROLLER IS WANTED,
 IF SMX701 IS WANTED THEN OCCURS:

XMT CHANNEL NUMBER (0-31)
 THE CHANNEL TO TRANSMIT FROM,
 REC CHANNEL NUMBER (0-31)
 THE CHANNEL TO RECEIVE IN,
 NOTE: ITS ALLOWED TO USE THE SAME
 CHANNEL FOR INPUT AND OUTPUT.

****DATA BLOCKS TO BE TRANSMITTED (1-2350)
 NUMBER OF CHARACTER IN THE BLOCK
 WHICH ARE GOING TO BE TRANSMITTED.
 SIZE:=DATA + 5 SYN + STX + 2 CRC + PAD.

TYPE (PTR) FOR PTR INPUT ELSE (NO)
 IF TESTINPUT IS FROM PAPER TAPE
 THEN (PTR), ELSE (NO) FOR AUTO-
 Matic GENERATED CYCLIC CHARACTERS,
 NOTE: IF PTR ERROR 31 OCCURS THEN
 IF CHARS READ > 0 THEN SIZE:= READ CHARACTERS,

****BIT RATE PR SECOND NUMBER OF BIT PR SECOND (MODEM/BAUD)
 LOOK AT CALCULATIONS,

SYNC CHARACTER (DECIMAL: 1-255)
 THE SYNCHRONISATION CHARACTER FOR
 THE CONTROLLER, (DEFAULT = 50)

FIRST CHARACTER (DECIMAL: 1-255)
 START CHARACTER FOR DATA, (DEAFULT = 2),

****LOG: PR BAD BLOCK (+) PR MINUTES (-)
 IF ANSWER = + THEN OCCURS:
 NUMBER OF BAD BLOCKS BEFORE LOG
 ANSWER SHOULD BE BETWEEN (1-65000)
 MEANING EVERY TIME THE RECEIVER
 HAS GOT THE SPECIFIED NUMBER OF
 ERRORBLOCKS AN ERROR STATISTIC WILL
 BE DISPLAYED ON LOGDEVICE, AFTER
 LOG ERRORCOUNTER IS 0,
 IF ANSWER = - THEN OCCURS:
 NUMBER OF MINUTES BETWEEN LOG (1-59)
 MEANING: EVERY TIME THE EFFECTIVE
 MINUTE IS A MULTIPLUM OF WANTED
 LOG MINUTES THEN A STATISTIC WILL
 BL DISPLAYED ON LOGDEVICE.

```

0211
0212 TYPE THE SECONDS TO WAIT FOR NEXT BLOCK
0213
0214 THE MAXIMUM OF TIME (TIMER1)
0215 UNTIL THE FIRST BYTE OF BLOCK
0216 ARRIVES.
0217 DEFAULT IS ONE SECOND, MAX SECOND = 25.
0218
0219 TYPE THE SECONDS TO WAIT FOR WHOLE BLOCK
0220
0221 THE MAXIMUM OF TIME (TIMER2) OF
0222 RECEPTION ALL BYTES IN ONE BLOCK,
0223 DEFAULT DEPENDS ON BIT RATE, MAX SECONDS = 25.
0224
0225
0226
0227 ****LOG: NO LOG (1) BIT STAT (2) ALL (3)
0228
0229 IF ANSWER = 1 THEN NO LOG OF
0230 ONE BAD BLOCK WILL BE DISPLAYED.
0231
0232 IF ANSWER = 2 THEN CHECK OF DIF-
0233 FERENT BYTES IN A BLOCK WILL BE
0234 DONE AND A BIT STATISTIC OF DIFFERENT
0235 BITS IN DIFFERENT BYTES WILL BE
0236 DISPLAYED ON LOGDEVICE.
0237
0238 (USED TO CHECK LINE FOR LOOSING SPECIAL BITS)
0239
0240 IF ANSWER = 3 THEN A LOGGING OF ALL BAD
0241 CHARACTERS WILL BE DONE, WITH ITS
0242 BYTE NUMBER (COUNTING FROM ONE) WHAT IT
0243 SHOULD BE AND WHAT IT WAS RECEIVED AS.
0244 AT LAST THE BIT STATISTIC WILL OCCUR AS
0245 IF ANSWER HAD BEEN 2.
0246
0247 ****OUTPUT LOGDEVICE, (TTY/LPT/CPT/SP)
0248
0249 THE DEVICE WHERE STATISTIC ARE GOING
0250 TO BE LOGGED ON,
0251 TTY = TELETYPE
0252 LPT = LINEPRINTER
0253 CPT = CHARABAND PRINTER
0254 SP = SENTRONIX PRINTER.
0255
0256 ****TESTPERIOD, (HOURS.MINUTES)
0257
0258 EFFECTIVE TIME THE TEST SHOULD RUN,
0259
0260 ****STOP ON ERROR (YES) OR WAIT UNTIL STATISTIC (NO)
0261
0262 IF ANSWER = YES THEN TEST
0263 WILL STOP ON THE FIRST OCCURED ERROR,
0264
0265 IF ANSWER = NO THEN TEST
0266 WILL STOP WHEN RUNTIME HAS REACHED,
0267 OR HARD ERROR ON LOG DEVICE.
0268
0269
0270 ****ATYPE (HELP) TO SEE COMMANDS / ELSE (NL)
0271
0272 IF WRITING HELP ALL POSSIBLE COMMANDS
0273 WILL BE DISPLAYED, WITH THE MEANING
0274 OF THE COMMANDS.
0275

```

0276
0277 OUTPUT MESSAGES:
0278
0279 EXECUTION STARTED HH,MM,SS
0280
0281 WRITTEN AS ACCEPT OF COMMAND START
0282
0283 EXECUTION STOPPED HH,MM,SS
0284
0285 WRITTEN AS ACCEPT OF COMMAND STOP
0286
0287 EXECUTION CONTINUED HH,MM,SS
0288
0289 WRITTEN AS ACCEPT OF COMMAND CONT
0290
0291 LOG DEVICE ERROR NNNNN
0292
0293 CONSULT THE RC3600 OPERATORS MANUAL
0294
0295 PTR ERROR NNNNN CONSULT THE RC3600 OPERATORS MANUAL
0296
0297
0298
0299 TESTSTATISTIC: USER INFORMATION TO SEE THE RESULT
0300 ERROR STATISTIC: OF THE TEST
0301
0302
0303
0304

0305 DURING RUN FOLLOWING OUTPUT MESSAGES CAN OCCUR:

0307
0308
0309 *** HH,MM,SS LINE RELIABILITY TEST ***
0310

0311 *** HH,MM,SS STATUS:

0312
0313 BLOCKS: REC: XXXXXXXX FAILED: XXXXX ERRORRATE: XXXX
0314 TOTAL: REC: XXXXXXXX FAILED: XXXXX BPS: XXXXX
0315

0316
0317
0318 BLOCKS REC MEANS NUMBER OF BLOCK RECEIVED
0319 SINCE LAST LOG,

0320
0321 BLOCKS FAILED MEANS NUMBER OF BLOCKS
0322 WITH EITHER BLOCK CHECK ERROR OR
0323 TIMEOUT,

0324
0325 ERRORRATE MEANS NUMBER OF ERRORBLOCKS
0326 IN PERCENT OF SEND BLOCKS SINCE LAST
0327 LOG,

0328
0329 BLOCKS TOTAL MEANS NUMBER OF BLOCKS
0330 RECEIVED SINCE PROGRAM START,

0331
0332 TOTAL FAILED MEANS NUMBER OF BLOCKS
0333 FAILED SINCE PROGRAM START,

0334
0335 BPS MEANS THE EFFECTIVE HIT RATE
0336 SINCE LAST LOG OR SINCE START,
0337

0338
0339
0340
0341 *** HH,MM,SS LINE RELIABILITY TEST ***

0342
0343 BLOCK CHECK ERROR

0344
0345 NO. XMT REC
0346 XXXX XXX XXX

0347
0348 ERROR BIT STATISTICS BIT(0-7)

0349
0350 BIT0 BIT1 BIT2 BIT3 BIT4 BIT5 BIT6 BIT7

0351
0352 IN CASE OF BADBLOCK = 3
0353 THEN OCCURS EVERY TIME IF BLOCKCHECK ERROR
0354 THIS LOG,

0355
0356 NO. MEANS DATA BYTE NUMBER WHICH WAS
0357 WRONG, (START COUNTING FROM ONE),

0358
0359 XMT MEANS THE TRANSMITTED BYTE,

0360
0361 REC MEANS THE RECEIVED BYTE,

0362
0363 THE ERROR BIT STATISTIC
0364 IS AN ACCUMOLATION OF ALL DIFFERENT
0365 BITS IN THE DIFFERENTS BYTES,
0366

0367
0368 IF ANSWER WAS 2 THEN ONLY
0369 BIT STATISTIC WILL OCCUR,
0370

0371
0372
0373
0374

0375
0376 INPUT MESSAGES;

0377		
0378	START	START EXECUTION, UNLESS LOG ERROR HAD OCCURRED THEN IT MEANS REPEAT THE OPERATION,
0379		
0380		
0381		
0382	CONT	EXECUTION IS CONTINUED WITHOUT CHANGING STATUS,
0383		
0384		
0385	STOP	EXECUTION STOPS AND STATISTICS WILL BE DISPLAYED AND PROGRAM IS SET NEUTRAL;
0386		
0387		
0388	STAT	WILL GIVE A DISPLAY OF CURRENT STATUS FROM TEST START TO NOW,
0389		
0390		
0391	DISP	WILL GIVE A DISPLAY OF THE DIFFERENT STATUS BETWEEN THE WANTED LOG DISPLAYS,
0392		
0393		
0394		
0395	HELP	WILL DIPLAY ALL COMMANDS AND THEIR MEANING,
0396		
0397		

0398
0399 TO MODIFIE SINGLE PARAMETERS:
0400
0401 TESTDEVICE <NAME> (XMT) OR (REC) <CHANNEL NUMBER>
0402
0403 EXAMPLES: IF TESTDEVICE SMX701 CHANNEL 1
0404 IN TRANSMITTER IS WANTED TO BE CHANNEL 2 THEN
0405
0406 WRITE: TESTDEVICE SMX XMT 2
0407
0408 SAME WITH INPUT PROGRAM
0409
0410 WRITE: TESTDEVICE SMX REC 2
0411
0412 SIZE <COUNT> IF NEW BLOCK SIZE IS WANTED
0413 THE NEW TEST CHARACTER FROM
0414 PTR WILL BE READ AUTOMATICALLY
0415 ELSE THE AUTOMATIC CYCLIC CHARAC-
0416 TER WILL BE GENERATED IF NOT FROM
0417 PTR,
0418
0419 INPUT (PTR) OR (NO) IF CHANGING TESTINPUT DEVICE,
0420 NOTE THAT THE CHARACTER WILL BE
0421 READ AUTOMATICALLY IF INPUT
0422 FROM PTR WITH SIZE,
0423
0424 SYNCHAR <VALUE> INSERT A NEW SYNCHAR,
0425
0426 FIRSTCHAR <VALUE> INSERTS A NEW START CHARACTER FOR DATA,
0427
0428 TESTTIME (+) OR (-) <VALUE>
0429 PLUS: FOR PR BAD BLOCK
0430 MINUS: FOR PR MINUTES
0431 THE TESTIME FOR PR LOG,
0432
0433 BPS <VALUES> CHANGE THE BIT RATE,
0434
0435 TIMER1 <VALUE> NEW TIMER FOR WAIT FOR NEXT BLOCK,
0436
0437 TIMER2 <VALUE> NEW TIMER FOR WHOLE BLOCK,
0438
0439 BADBLOCK <VALUES> LOG PR BAD BLOCK,
0440 1 => NO LOG
0441 2 => BIT STAT
0442 3 => ALL
0443
0444 LOGDEVICE <DRIVERNAME>
0445
0446 TO CHANGE TO NEW LOGDEVICE,
0447
0448 RUNTIME <HH,MM,SS> CHANGE THE EFFECTIVE RUNTIME,
0449 NOTE THAT IF COMMAND START HAS
0450 BEEN GIVEN IT WILL BE THE NEW
0451 STOP TIME, IF CAMMAND CONT HAS BEEN
0452 GIVEN THE PROGRAM WILL CONTINUE
0453 AS IF THIS HAS BEEN THE STOP TIME
0454 ALL THE TIME,
0455
0456 HOLD <ANSWER> IF ANSWER = YES THEN IT WILL STOP
0457 ON THE FIRST OCCURRED ERROR
0458 IF ANSWER = NO THEN IT WILL STOP
0459 ON RUNTIME OR HARD ERROR ON LOG
0460 DEVICE,
0461
0462 !

0463 I
0464
0465
0466
0467
0468
0469 01
0470
0471
0472
0473
0474 02
0475
0476
0477
0478
0479
0480
0481
0482 I

VERSION AUTHOR DATE

CHANGE

CAMS 77.01.16

MAKE TIME COUNTING MORE GENERAL
COUNT THE EFFECTIVE BIT RATE
FROM START AND BETWEEN LOGS.
MAKE CYCLIC BUFRING.

CAMS 77.04.20

CORRECT ERROR RATE CALCULATION.
CORRECT ERROR USING THE CYCLIC
BUFRING, IT ONLY OCCURRED IN
ONE MINUT FOR EVERY HOUR IF
THE ERROR RATE WAS ABOUT 100 %.



