
Title:

RC 36-00444.00
CASSETTE TAPE RELIABILITY
OPERATING INSTRUCTION

 **REGNECENTRALEN**

RC SYSTEM LIBRARY: FALKONERALLE 1 DK-2000 COPENHAGEN F

RCSL No: 44 - RT1644
Edition: 77.11.19
Author: Ella Christensen

Keywords: Musil, Device Reliability, Cassette Tape, Test

Abstract:

The following pages present the first, general pages of the reliability program listing.

These pages form an operating guide to the program

LOAD

After autoloading of

RC 3600 SYSTEM MAINTENANCE

Tape/Disc, or while running RC 3600 MUS/DOMUS software (only for RC 3600 systems), this device reliability program can be loaded and executed the following way:

After contact with operative system = S
(refer to previous chapters or the system
operating guide) type:

LOAD TIME <1> <2> <3> P444

RETURN

1: CT = Cassette Tape Unit
CT1 = Second Cassette Tape Unit

EVENTUAL Log Device, - if not TTY:

2: LPT	= Line Printer	3: Empty	= ASCII
CPT	= Charaband Printer	TAB1	= ASCII
SP	= Serial Printer	TAB2	= RC Standard
		TAB3	= PL1
		TAB4	= Hungarian
		TAB5	= Cyrillic

0065 ! RC36-00444 PAGE 01
0066
0067 TITLE: CASSETTE TAPE RELIABILITY PROGRAM
0068
0069 ABSTRACT: THIS PROGRAM TESTS CASSETTE TAPE UNITS BY WRITTING
0070 AND CHECK-READING DATA.
0071
0072
0073 SIZE: 8722 BYTES
0074
0075 DATE: 77.04.05
0076
0077
0078 SPECIAL REQUIREMENTS:
0079 (AT COMPILE-TIME)
0080
0081 CODEPROCEDURE P0001 (TIME) RCSL: 43-GL182
0082 CODEPROCEDURE P0023 (DELAY) RCSL: 43-GL1409
0083 CODEPROCEDURE CHANGETABLE RCSL: 43-GL1519
0084
0085
0086 GENERAL INFORMATION:
0087
0088 THIS PROGRAM ACTS IN THE FOLLOWING WAY:
0089 AFTER ALL PARAMETERS HAS BEEN INITIALIZED AND A START
0090 COMMAND HAS BEEN GIVEN THE PROGRAM STARTS WRITTING
0091 AND READING FROM THE CASSETTE TAPE UNIT (FOR MORE
0092 DETAILED DESCRIPTION SEE SPECIFICATION PAGE 05).
0093 IF STATUS ERRORS OCCURS THEY ARE ACCUMULATED. IF ERRORS
0094 IN THE DATA OCCURS THEY ARE LOGGED IMMEDIATLY. WHEN THE
0095 PROGRAM HAS BEEN RUNNING FOR SPECIFIED TIME OR A HARD
0096 ERROR OCCURS, THE PROGRAM IS STOPPED, AND A STATISTIIC
0097 IS LOGGED ON THE SELECTED LOG-DEVICE.
0098
0099
0100 DRIVERS FOR THE PROGRAM:
0101
0102 INTERPRETER, DRIVER FOR THE SELECTED LOG-DEVICE,
0103 (CONVERSION TABLE IF LOG DEVICE IS PRINTER),
0104 THE PROGRAM TIME AND LATEST VERSION OF CASSETTE TAPE DRIVER
0105 (FOR UNIT U CT009).
0106
0107 !
0108

0109 !
0110
0111 RUNTIME PARAMETERS:
0112
0113
0114 UNITNO
0115
0116 TYPE THE UNIT-NUMBER THAT IS GOING TO BE
0117 TESTED.
0118
0119 OUTPUT LOGDEVICE, (TTY), (LPT), (CPT), (SP)
0120
0121 TYPE THE DEVICE WHERE STATISTICS ARE GOING
0122 TO BE LOGGED.
0123
0124 TTY = TELETYPE
0125 LPT = LINEPRINTER
0126 CPT = CHARABAND PRINTER
0127 SP = SERIAL PRINTER
0128
0129 TESTPERIOD, (HOURS,MINUTES)
0130
0131 EFFECTIVE TIME THE TEST SHOULD RUN.
0132
0133 STOP ON ERROR (YES) OR WAIT UNTIL STATISTIC (NO)
0134
0135 IF ANSWER = YES THEN TEST WILL STOP ON THE
0136 FIRST OCCURRED ERROR
0137
0138 IF ANSWER = NO THEN TEST WILL STOP WHEN RUNTIME
0139 IS REACHED OR HARD ERROR OCCURS.
0140
0141 NUMBER OF BLOCKS/FILES (MAX 20)
0142
0143 TYPE THE NUMBER OF DATA BLOCKS TO BE WRITTEN
0144 IN EACH FILE.
0145
0146 BLOCKLENGTH (MAX 2000)
0147
0148 TYPE THE NUMBER OF CHARACTERS TO BE WRITTEN
0149 IN EACH DATA BLOCK.
0150
0151
0152 TO SEE THE COMMANDS TYPE HELP ELSE NL
0153
0154 IF ANSWER = HELP THEN ALL POSSIBLE COMMANDS
0155 AND THE MEANING OF THEM WILL BE DISPLAYED.
0156 !
0157

0158
0159
0160 !
0161
0162
0163 INPUT MESSAGES:
0164
0165 START : STARTS EXECUTION WRITTING:
0166 EXECUTION STARTED HH.MM.SS
0167 AFTER LOG DEVICE ERROR START MEANS
0168 REPEAT THE LOG-OUTPUT.
0169
0170 STOP : STOPS EXECUTION WRITTING:
0171 EXECUTION STOPPED HH.MM.SS
0172 AFTER LOG DEVICE ERROR STOP MEANS
0173 SKIP THE LOG-OUTPUT, AND RESTART THE
0174 PROGRAM AT INIT-PHASE.
0175
0176 CONT : EXECUTION IS CONTINUED WITHOUT CHANGING
0177 STATUS, WRITTING:
0178 EXECUTION CONTINUED HH.MM.SS
0179
0180 INIT : DISPLAY RUNTIME PARAMETERS.
0181
0182 RELEASE: ONLY WHEN EXECUTION IS STOPPED.
0183 FORCES THE PROGRAM IN END JOB AND
0184 RELEASES DRIVERS AS IF HOURS.MINUTES
0185 HAS GONE.
0186
0187
0188 OUTPUT MESSAGES:
0189
0190 EXECUTION STARTED HH.MM.SS
0191
0192 WRITTEN AS ACCEPT OF COMMAND START
0193
0194 EXECUTION STOPPED HH.MM.SS
0195
0196 WRITTEN AS ACCEPT OF COMMAND STOP
0197
0198 EXECUTION CONTINUED HH.MM.SS
0199
0200 WRITTEN AS ACCEPT OF COMMAND CONT
0201
0202 LOG DEVICE ERROR NNNNN
0203
0204 CONSULT THE RC3600 OPERATING GUIDE
0205
0206 TEST STATISTIC AND ERROR STATISTIC
0207
0208 USER INFORMATION TO SEE THE RESULT OF
0209 THE TEST (SEE NEXT PAGE).
0210 !
0211
0212

0213
0214 !
0215
0216
0217
0218
0219
0220
0221
0222
0223
0224
0225
0226
0227
0228
0229
0230
0231
0232
0233
0234
0235
0236
0237
0238
0239
0240
0241
0242
0243
0244
0245
0246
0247
0248
0249
0250
0251
0252
0253
0254
0255
0256
0257
0258
0259
0260
0261
0262
0263
0264
0265
0266 !
0267

WHEN AN ERROR OCCURS THE FOLLOWING IS OUTPUT:

UNIT: N FILE: XXXXX BLOCK: YYYYY <STATE>

WHERE N = UNIT NUMBER
 XXXXX = FILE NUMBER IN WHICH THE ERROR OCCURRED.
 YYYYY = BLOCK NUMBER IN WHICH THE ERROR OCCURRED.

<STATE> IS ONE OF THE FOLLOWING 4 TEXTS

WRITE : THE UNIT WAS WRITTING DATA
 WHEN THE ERROR OCCURRED.
READ : THE UNIT WAS READING AND CHECKING
 DATA WHEN THE ERROR OCCURRED.
READ CONT : THE UNIT WAS READING CONTINUOUS AND CHECKING
 DATA WHEN THE ERROR OCCURRED.
POSITIONING : THE UNIT WAS POSITIONING TO FILE
 XXXXX BLOCK YYYYY WHEN THE ERROR
 OCCURRED.

DEPENDING ON THE ERROR THE NEXT LINE WILL BE:

PARITY ERROR
POSITION ERROR
EOF STATUS MISSING
LENGTH ERROR GOOD: XXXXX BAD: YYYYY
DATA ERROR GOOD: 8'NNN BAD: 8'MMM CHARACTERNO: VVVVV

PARITY AND POSITION ERROR NEED NO EXPLANATION.

EOF STATUS MISSING MEANS THAT FILE XXXXX BLOCK YYYYY SHOULD
 HAVE BEEN A TAPE-MARK, BUT WHEN IT WAS
 READ NO EOF-STATUS WAS RETURNED.
 NOTE: AFTER THIS THE RELIABILITY WILL REWIND
 THE CASSETTE AND START AT FILE 1 BLOCK 1.

LENGTH ERROR MEANS THAT THE BLOCKSIZE WHEN READING IS
 NOT EQUAL TO THE EXPECTED ONE.
 XXXXX = CORRECT BLOCKSIZE, YYYYY = READ
 BLOCKSIZE.

DATA ERROR MEANS THAT THE READING AND CHECKING DATA,
 FILE XXXXX BLOCK YYYYY BYTE VVVVV DOES
 NOT CORRESPOND TO WHAT THERE SHOULD BE
 WRITTEN IN IT. NNN IS THE CORRECT VALUE
 IN OCTAL, AND MMM IS THE READ VALUE IN OCTAL.
 IF 3 DATA ERRORS HAVE OCCURRED IN 1 BLOCK,
 IT IS REGARDED AS A BAD BLOCK, AND THE
 REST OF IT IS NOT CHECKED.

0268
0269 !
0270
0271
0272
0273
0274
0275
0276
0277
0278
0279
0280
0281
0282
0283
0284
0285
0286
0287
0288
0289
0290
0291
0292
0293
0294 SPECIFICATION:
0295
0296
0297
0298
0299
0300
0301
0302
0303
0304
0305
0306
0307
0308
0309
0310
0311
0312
0313
0314
0315
0316
0317
0318 !
0319
0320

RC36-00444 PAGE 05

TEST STATISTIC AND ERROR STATISTIC:

THE TEST STATISTIC AND ERROR STATISTIC IS LOGGED ON THE SELECTED LOG-DEVICE WHEN THE TEST HAS BEEN RUNNING FOR THE SPECIFIED TIME OR WHEN THE COMMAND STOP IS GIVEN.

THE TEST STATISTIC SHOWS THE TIME FOR START, STOP AND THE EFFECTIVE RUN-TIME. FURTHERMORE IT SHOWS THE UNIT-NUMBER, HOW MANY FILES THAT HAS BEEN WRITTEN AND READ AND HOW MANY ERRORS THAT HAVE OCCURRED.

THE ERROR STATISTIC SHOWS THE STATUS-ERRORS THAT HAVE OCCURRED.

ERROR NN: NNNNN EXPLANATION.
NN IS THE ERRORNUMBER
NNNNN IS THE NUMBER OF TIMES THE ERROR OCCURRED.
EXPLANATION IS AN EXPLANATION OF THE STATUS-ERROR.

SPECIFICATION:

IN THE FOLLOWING

X = RUNTIME PARAMETER BLOCKS/FILE.
L = RUNTIME PARAMETER BLOCKSIZE.

THE FUNCTION OF THE CASSETTE TAPE UNIT RELIABILITY IS:

1. POSITION TO FILE 1 BLOCK 1.
2. WRITE A FILE OF X BLOCKS OF THE LENGTH L
3. EACH 5. TIME POSITION TO FILE 1 BLOCK 1 (REWIND)
4. READ AND CHECK X+1 BLOCKS
(THE LAST BLOCK SHOULD GIVE EOF-STATUS).
5. IF EOT IS REACHED THEN GOTO 1.

THIS WILL CONTINUE UNTIL IT HAS RUN HOURS.MINUTES
UNLESS IT IS INTERRUPTED BY OPERATOR OR HARD ERROR.