
Title:

RC36-00822.00

DISC RELIABILITY

OPERATING INSTRUCTION

 **REGNECENTRALEN**

RC SYSTEM LIBRARY: FALKONERALLE 1 DK-2000 COPENHAGEN F

RCSL No: 44 - RT 1849

Edition: 79 02 02

Author: OS

0065 !
0066
0067 TITLE: DISC RELIABILITY PROGRAM
0068
0069 ABSTRACT: THIS PROGRAM TESTS DISC UNITS BY WRITING
0070 AND CHECK-READING DATA WITHIN A DISCFIELD.
0071
0072
0073 SIZE: 10666 BYTES
0074
0075 DATE: 78.03.29
0076
0077
0078 SPECIAL REQUIREMENTS:
0079 (AT COMPILE-TIME)
0080
0081 CODEPROCEDURE P0001 (TIME) RCSL: 43-GL182
0082 CODEPROCEDURE P0023 (DELAY) RCSL: 43-GL1409
0083 CODEPROCEDURE P0061 (RANDOM) RCSL: 43-GL2763
0084 CODEPROCEDURE CHANGETABLE RCSL: 43-GL1519
0085
0086
0087 GENERAL INFORMATION:
0088
0089 THIS PROGRAM ACTS IN THE FOLLOWING WAY:
0090 AFTER ALL PARAMETERS HAVE BEEN INITIALIZED AND A START
0091 COMMAND HAS BEEN GIVEN THE PROGRAM STARTS WRITING
0092 AND READING A FILE ON A DISC (FOR MORE
0093 DETAILED DESCRIPTION SEE SPECIFICATION PAGE 06).
0094 IF STATUS ERRORS OCCUR THEY ARE ACCUMULATED. IF ERRORS
0095 IN THE DATA OCCUR THEY ARE LOGGED IMMEDIATELY. WHEN THE
0096 PROGRAM HAS BEEN RUNNING FOR A SPECIFIED TIME OR A HARD
0097 ERROR OCCURS, THE PROGRAM IS STOPPED, AND A STATISTIC
0098 IS LOGGED ON THE SELECTED LOG-DEVICE.
0099
0100
0101 DRIVERS FOR THE PROGRAM:
0102
0103 INTERPRETER, DRIVER FOR THE SELECTED LOG-DEVICE,
0104 (CONVERSION TABLE IF LOG DEVICE IS PRINTER),
0105 THE PROGRAM TIME, CAT76 AND DRIVERS FOR THE SPECIFIED
0106 DRIVE.
0107
0108 !
0109

0110 1

0111

0112 RUNTIME PARAMETERS:

0113

0114

0115

DRIVENO

0116

0117

TYPE THE DRIVE-NUMBER THAT IS GOING TO BE
TESTED.

0118

0119

0120

USE EXISTING FILE (OLD) OR CREATE A NEW FILE (NEW)

0121

0122

0123

TYPE OLD OR NEW. IF NEW SPECIFIED TYPE THE
SIZE (IN SECTORS) AND THE EXTENSION (BIG OR
SMALL) OF THE FILE.

0124

0125

0126

FILENAME

0127

0128

TYPE THE FILENAME TO BE USED FOR THE TEST.
(AT!! ALL EXISTING DATA IN THE FILE ARE LOST).

0129

0130

0131

CUTPUT LOGDEVICE, (TTY), (LPT), (CPT), (SP)

0132

0133

TYPE THE DEVICE WHERE STATISTICS ARE GOING
TO BE LOGGED.

0134

0135

0136

TTY = TELETYPE

0137

LPT = LINEPRINTER

0138

CPT = CHARABAND PRINTER

0139

SP = SERIAL PRINTER

0140

0141

TESTPERIOD, (HOURS,MINUTES)

0142

0143

EFFECTIVE TIME THE TEST SHOULD RUN.

0144

0145

STOP ON ERROR (YES) OR WAIT UNTIL STATISTIC (NO)

0146

0147

IF ANSWER = YES THEN TEST WILL STOP AT THE
FIRST OCCURRED ERROR

0148

0149

IF ANSWER = NO THEN TEST WILL STOP WHEN RUNTIME
IS REACHED OR HARD ERROR OCCURS.

0150

0151

0152

AUTOMATIC DATAGENERATING (AUTO) OR SPECIAL DATA (SPEC).

0153

0154

IF ANSWER = AUTO THEN RANDOM AND SKEWPATTERN
DATA IS AUTOMATICALLY GENERATED BY THE PROGRAM.

0155

0156

0157

IF ANSWER = SPEC THEN DATA IS SELECTED BY
THE OPERATOR.

0158

0159

0160

0161

DATA BYTE NN

0162

0163

ONLY WHEN SPECIAL DATA. GIVE THE DECIMAL
VALUE (0-225) FOR BYTE NN. IT IS POSSIBLE
TO SPECIFY MAX 25 BYTES. IF 16 DATA BYTES
ARE SPECIFIED THEN EACH BLOCK WILL CONTAIN
THE 16 DATA BYTES 32 TIMES.

0164

0165

0166

0167

0168

0169

TO SEE THE COMMANDS TYPE HELP ELSE NL

0170

0171

IF ANSWER = HELP THEN ALL POSSIBLE COMMANDS
AND THE MEANING OF THEM WILL BE DISPLAYED.

0172

0173 1

0174

0175 !

0176

0177

0178 INPUT MESSAGES:

0179

0180

START :

STARTS EXECUTION WRITING:

0181

EXECUTION STARTED HH.MM.SS

0182

AFTER LOG DEVICE ERROR START MEANS

0183

REPEAT THE LOG-OUTPUT.

0184

0185

STOP :

STOPS EXECUTION WRITING:

0186

EXECUTION STOPPED HH.MM.SS

0187

AFTER LOG DEVICE ERROR STOP MEANS

0188

SKIP THE LOG-OUTPUT, AND RESTART THE

0189

PROGRAM AT INIT-PHASE.

0190

0191

CONT :

EXECUTION IS CONTINUED WITHOUT CHANGING

0192

STATUS, WRITING:

0193

EXECUTION CONTINUED HH.MM.SS

0194

0195

INIT :

DISPLAY RUNTIME PARAMETERS.

0196

0197

RELEASE:

ONLY WHEN EXECUTION IS STOPPED.

0198

FORCES THE PROGRAM IN END JOB ,

0199

RELEASES DRIVERS AND REMOVES THE FILE-

0200

AREAPROCESS AS IF HOURS.MINUTES HAS GONE.

0201

0202

0203 OUTPUT MESSAGES:

0204

EXECUTION STARTED HH.MM.SS

0205

0206

WRITTEN AS ACCEPT OF COMMAND START

0207

0208

EXECUTION STOPPED HH.MM.SS .

0209

0210

WRITTEN AS ACCEPT OF COMMAND STOP

0211

0212

EXECUTION CONTINUED HH.MM.SS

0213

0214

WRITTEN AS ACCEPT OF COMMAND CONT

0215

0216

LOG DEVICE ERROR NNNNN

0217

0218

CONSULT THE RC3600 OPERATING GUIDE

0219

0220

TEST STATISTIC AND ERROR STATISTIC

0221

0222

USER INFORMATION TO SEE THE RESULT OF

0223

0224

THE TEST (SEE NEXT PAGE).

0225 !

0226

0227

WHEN AN ERROR OCCURS THE FOLLOWING IS OUTPUT:

DRIVE: NNN FILE: XXXXX BLOCK: YYYYY MODE: AAAAAAAAAA <STATE

WHERE NNN = DRIVE NUMBER

XXXXX = FILE IN WHICH THE ERROR OCCURRED.

YYYYY = BLOCK NUMBER IN WHICH THE ERROR OCCURRED.

AAAAAAAAA = SEQUENTIAL OR RANDOM POSITIONING.

<STATE> IS ONE OF THE FOLLOWING TEXTS

WRITE RANDOM : THE UNIT WAS WRITING RANDOM DATA
WHEN THE ERROR OCCURRED.

WRITE FLOAT1 : THE UNIT WAS WRITING FLOATING ONE DATA
WHEN THE ERROR OCCURRED.

WRITE 1'S : THE UNIT WAS WRITING ALL 1'S
WHEN THE ERROR OCCURRED.

WRITE 0'S : THE UNIT WAS WRITING ALL 0'S
WHEN THE ERROR OCCURRED.

WRITE 8'333 : THE UNIT WAS WRITING 8'333
WHEN THE ERROR OCCURRED.

WRITE SPECIAL: THE UNIT WAS WRITING OPERATOR-
SPECIFIED DATA WHEN THE ERROR OCCURRED.

READ RANDOM : THE UNIT WAS READING AND CHECKING
RANDOM DATA WHEN THE ERROR OCCURRED.

READ FLOAT1 : THE UNIT WAS READING AND CHECKING
FLOATING ONE DATA WHEN THE ERROR OCCURRED.

READ 1'S : THE UNIT WAS READING AND CHECKING
ALL 1'S DATA WHEN THE ERROR OCCURRED.

READ 0'S : THE UNIT WAS READING AND CHECKING
ALL 0'S DATA WHEN THE ERROR OCCURRED.

READ 8'333 : THE UNIT WAS READING AND CHECKING
8'333 DATA WHEN THE ERROR OCCURRED.

READ SPECIAL : THE UNIT WAS READING AND CHECKING
OPERATOR-SPECIFIED DATA WHEN THE
ERROR OCCURRED.

DEPENDING ON THE ERROR THE NEXT LINE WILL BE:

PARITY ERROR

SEEK ERROR

POSITION ERROR

READ BLOCK: ZZZZ

LENGTH ERROR GOOD: XXXXX BAD: YYYYY

DATA ERROR GOOD: 8'NNN BAD: 8'MMM CHARACTERNO: VVVVV

PARITY AND SEEK ERROR NEED NO EXPLANATION.

LENGTH ERROR MEANS THAT THE BLOCKSIZE WHEN READING IS
NOT EQUAL TO THE EXPECTED ONE.
XXXXX = CORRECT BLOCKSIZE, YYYYY = READ
BLOCKSIZE.

DATA ERROR MEANS THAT THE READING AND CHECKING DATA,
FILE XXXXX BLOCK YYYYY BYTE VVVVV DOES
NOT CORRESPOND TO WHAT IT SHOULD BE
WRITTEN IN IT. NNN IS THE CORRECT VALUE
IN OCTAL, AND MMM IS THE READ VALUE IN OCTAL.
IF 3 DATA ERRORS HAVE OCCURRED IN 1 BLOCK,
IT IS REGARDED AS A BAD BLOCK, AND THE
REST OF IT IS NOT CHECKED.

POSITION ERROR MEANS THAT A WRONG BLOCK WAS READ.
THE READ BLOCK WAS ZZZZ.

0297
0298 1
0299
0300
0301
0302
0303
0304
0305
0306
0307
0308
0309
0310
0311
0312
0313
0314
0315
0316
0317
0318
0319
0320
0321
0322 1

RC36-00822 PAGE 05

TEST STATISTIC AND ERROR STATISTIC:

THE TEST STATISTIC AND ERROR STATISTIC IS LOGGED
ON THE SELECTED LOG-DEVICE WHEN THE TEST HAS BEEN
RUNNING FOR THE SPECIFIED TIME OR WHEN THE COMMAND
STOP IS GIVEN.

THE TEST STATISTIC SHOWS THE TIME FOR START, STOP
AND THE EFFECTIVE RUN-TIME. FURTHERMORE IT SHOWS
THE DRIVE-NUMBER, THE FILE NAME, HOW MANY BLOCKS
THAT HAVE BEEN WRITTEN AND READ AND HOW MANY ERRORS
THAT HAVE OCCURRED.

THE ERROR STATISTIC SHOWS THE STATUS-ERRORS THAT
HAVE OCCURRED.

ERROR NN: NNNNN EXPLANATION.
NN IS THE ERRORNUMBER
NNNNN IS THE NUMBER OF TIMES THE ERROR OCCURRED.
EXPLANATION IS AN EXPLANATION OF THE STATUS-ERROR.

0323

0324 1

0325

0326 SPECIFICATION:

0327

0328

0329

0330

0331

0332

0333

0334

0335

0336

0337

0338

0339

0340

0341

0342

0343

0344

0345

0346

0347

0348

0349

0350

0351

0352

0353

0354

0355

0356

0357

0358

0359

0360

0361

0362

0363

0364

0365

0366

0367

0368

0369

0370

0371

0372 1

0373

THE FUNCTION OF THE DISC RELIABILITY PROGRAM IS:

NOTE: ALL BLOCKS (SECTORS) CONTAIN THE BLOCKNUMBER IN THE FIRST 5 BYTES OF THE BLOCK.

1. POSITION TO BLOCKNO 0 WITHIN THE SPECIFIED FILE.
2. IF SPECIAL DATA SPECIFIED GOTO 12.
3. SET MODE TO SEQUENTIAL MODE.
4. WRITE A BLOCK OF RANDOM DATA.
5. WRITE A BLOCK OF FLOATING ONE DATA:
8'200 8'100 8'040 8'020 8'010 8'004 8'002 8'001 8'200 ETC.
6. WRITE A BLOCK OF ALL 1'S.
7. WRITE A BLOCK OF ALL 0'S.
8. WRITE A BLOCK WHERE ALL THE BYTES ARE 8'333.
9. POSITION TO LAST BLOCK OF RANDOM DATA. READ AND CHECK THE NEXT 5 BLOCKS OF DATA (RANDOM DATA, FLOATING ONE DATA, ALL 1'S, ALL 0'S, ALL 8'33).
10. SET MODE TO OPPOSITE OF CURRENT MODE (SEQUENTIAL/RANDOM).
11. GO TO 4.
12. SET MODE TO SEQUENTIAL MODE.
13. WRITE 5 BLOCKS WITH THE SPECIFIED DATA.
14. POSITION TO THE FIRST BLOCK WITHIN THE 5 BLOCKS.
READ AND CHECK THE 5 BLOCKS.
14. SET MODE TO OPPOSITE OF CURRENT MODE (SEQUENTIAL/RANDOM).
16. GO TO 13.

THIS WILL CONTINUE UNTIL THE PROGRAM HAS RUN HOURS.MINLTES
UNLESS IT IS INTERRUPTED BY THE OPERATOR OR HARD ERROR OCCURS