

---

**RC5040/RC5050**

---

**Central Processing Unit**

---

**Operating Guide**

---

---

**PN: 99001343**

---

**Keywords:**

RC5000, RC5040, RC5050, Operation.

**Abstract:**

This document contains information necessary for daily operation of the RC5040 and RC5050 Central Processing Units including a description of front panel switches and indicators, console commands, tests, error messages and autoload procedures. In addition key information is found in the 17 appendices.

**Date:**

January 1991

**Author:**

Harald Villemoes

**Copyright**

Copyright ©1991 RC International (Regnecentralen a/s) A/S Reg.no. 62 420

All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise without the prior written permission of RC International, Lautrupbjerg 1, DK-2750 Ballerup, Denmark.

**Disclaimer**

RC International makes no representations or warranties with respect to the contents of this publication and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Furthermore, RC International reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of RC International to notify any person of such revision or changes.

## TABLE OF CONTENTS

	Page
1. FOREWORD .....	3
2. SWITCHES AND INDICATORS .....	4
2.1 Operator's Control Panel .....	4
2.2 RC5040 Processor Front Panel .....	5
2.2.1 RC5040 Switches .....	6
2.2.1.1 RC5040 Bus Switches .....	6
2.2.1.2 RC5040 Mode Switch .....	6
2.2.2 RC5040 Indicators .....	7
2.3 RC5050 Processor Front Panel .....	11
2.3.1 Hexadecimal LED Display .....	12
2.3.1.1 RC5050 Display Mode .....	12
2.3.1.2 RC5050 Display Data Type .....	13
2.3.1.3 Test Program error display codes .....	16
2.3.1.4 Gate Array Error Codes .....	22
2.3.2 Push Buttons .....	23
2.4 POW207 Power Supply .....	24
2.5 POW240/241 Power Supply .....	24
3. CONSOLE OPERATION.....	26
3.1 Terminal Mode .....	26
3.1.1 Operator Process .....	26
3.1.2 OPSYS Commands .....	27
3.1.3 Messages from OPSYS .....	34
3.1.4 Messages from LOADER .....	36
3.2 Debug Mode .....	37
3.2.1 Activation .....	37
3.2.2 Display Commands .....	38
3.2.3 Control Commands .....	41
3.2.4 Command Parameters .....	44
4. AUTOLOADING .....	45
4.1 Autoload Switch Format .....	45
4.1.1 KIND = 0: LAN + X.25/3 .....	46
4.1.2 KIND = 1: WD .....	47
4.1.3 KIND = 2: FPA (Autoload Enabled) .....	47
4.1.4 KIND = 3: WD + COM204 .....	48
4.1.5 KIND = 4: LAN .....	50
4.1.6 KIND = 5: COM204 .....	51
4.1.7 KIND = 6: EPROM .....	53
4.1.8 KIND = 7: X.25/3 .....	53
4.1.9 KIND = 8: Not used .....	54
4.1.10 KIND = 9: Not used .....	54
4.1.11 KIND = 10 (A hex): FPA (Autoload Disabled) .....	54
4.1.12 KIND = 11 (B hex): WD + MEGA .....	54
4.1.13 KIND = 12 (C hex): Not used .....	56
4.1.14 KIND = 13 (D hex): MEGA .....	56
4.1.15 KIND = 14 (E hex): Not used .....	56
4.1.16 KIND = 15 (F hex): Not used .....	56

4.2 Autoload Message .....	57
4.3 Generating Autoload Files .....	60
4.3.1 Generating an FTS Autoloadfile .....	61
4.3.2 Generating an FPA Autoload .....	61
4.3.3 Generating TES202 Eproms .....	61
5. ERROR PROCEDURES .....	62
5.1 Monitor Testoutput .....	62
5.2 Boot Testoutput .....	63

## Appendices

A. REFERENCES .....	64
B. OPSYS COMMANDS .....	65
C. AUTOLOAD SWITCH LAYOUT .....	67
D. SECRET VECTOR .....	68
E. INSTRUCTION CODES .....	69
F. INSTRUCTION MNEMONICS .....	70
G. PROCESS DESCRIPTOR LAYOUT .....	71
H. MESSAGE HEADER LAYOUT .....	72
I. HEAP LAYOUT .....	73
J. EXCEPTION CODES .....	74
K. RC5040 REGISTER LAYOUT .....	76
L. RC5050 REGISTER LAYOUT .....	78
M. CONTROL MICRO RAM LAYOUT .....	79
N. RC5050 NON-VOLATILE MEMORY LAYOUT .....	82
O. RC5050 WORK MEMORY LAYOUT .....	84
P. SERVICE PROCESSOR INITIATOR .....	85
Q. INSTALLATION STANDARDS AND RECOMMENDATIONS .....	87
Q.1 Input/Output Modules .....	87
Q.2 Memory Modules .....	87
Q.3 Controllers .....	87
Q.4 Summary .....	88
R. ASCII CHARACTER SET .....	90

## 1. FOREWORD

This edition of the RC5040 / RC5050 Central Processing Unit Operating Guide is based on components of the following versions:

SW50020, RC5000 Operating System release 5.0 90.04.01

RC5040, DEBUG Firmware ROB584 87.09.23

RC5050, Microprogram, version 5.09  
Service Processor, version 5.17  
Service Processor Initiator, version 5.16

F505A, Autoload PROM version 11.3 .

RC5000 MegaSwitch autoload is included.

The chapter describing the functionalities of the autoload switches has been rearranged.

January, 1991

## 2. SWITCHES AND INDICATORS

This chapter describes the switches and indicators found on:

- the operators control panel
- the front panel of the RC5040 and RC5050 processor boards
- the power supply

### 2.1 Operator's Control Panel




Fig. 2.1. OCP for Rack with up to Three RC5000

Power off of the RC5000(s) is done by turning the key to the OFF position.

Power on of the RC5000(s) is done by turning the key to the ON position (or further on to the LOCK position).

The AUTOLOAD button(s) is (are) enabled when the key is in the ON position, and disabled, when in the LOCK position.

The AUTOLOAD button initiates autoloading of the RC5000 in question.

The POWER OK indicator is illuminated during power OK condition on the RC5000.

The OPERATING lamp indicates that the RC5000 is running normally.

The TEST MODE lamp indicates that the RC5000 is executing the built-in test programs.

## 2.2 RC5040 Processor Front Panel

The front panel of the RC5040 processor boards contain five switches, five indicators, and a jack.




Fig. 2.2. RC5040 Processor Front Panel

### 2.2.1 RC5040 Switches

All of the switches are rotary switches with 16 positions, indicated by the hexadecimal numbers 0 to F. The switches are set by means of a screwdriver.

#### 2.2.1.1 RC5040 Bus Switches

The four switches marked BUS are used to supply the processor with data. There is a switch for bits 0 to 3, 4 to 7, 8 to 11, and 12 to 15.

#### 2.2.1.2 RC5040 Mode Switch

The switch marked MODE is used to control the baud rate for the console and the execution of the builtin test programs (sect. 3.2.2).

If the mode switch is equal to, or greater than 8, the console is locked to Terminal-mode (T-mode), i.e. the console will not switch to Debug-mode (D-mode) by activating the BELL key (CTRL G). The mode switch is read continuously, so the baud rate may be changed on a running machine. The current value may be examined by the display command Y3F (see 3.2.2).'

Settings	Baud Rate	Execution Mode
0 (8)	300 bps	run test, loop
1 (9)	1200 bps	run test, loop
2 (A)	300 bps	skip test
3 (B)	1200 bps	skip test
4 (C)	300 bps	run test, no loop
5 (D)	1200 bps	run test, no loop
6 (E)	300 bps	skip test
7 (F)	1200 bps	skip test

#### Test Program Execution Modes

run test      The test programs are executed whenever the autoload button is pressed.

skip test      The test programs are not executed.

loop      The test programs are executed in an endless loop.

no loop      The test programs are executed once.

### 2.2.2 RC5040 Indicators

#### DI Disabled Interrupt

This lamp, when lit, indicates that the processor is running in the disabled interrupt mode.

#### OP Operating

This lamp, when lit, indicates that the processor is running normally; when it is extinguished, the processor has stopped.

#### LP Left Parity Error

This lamp, when lit, indicates that a parity error has been detected during a memory read in the left byte. The lamp can be extinguished only by autoloading.

#### RP Right Parity Error

This lamp, when lit, indicates that a parity error has been detected during a memory read in the right byte. The lamp can be extinguished only by autoloading.

#### TM Test Mode

This lamp, when lit, indicates that the processor is executing the built-in test programs. The current program is indicated by the DI, OP, LP, RP, and TM lamps, TM representing the least significant bit of the program number.

If an error is detected by a test program, one of the following messages is displayed on the console. The number in front of the following text is the number shown by the indicators DI through TM:

#### 1 8085 Communication Test

Message: ERR00 <dummy><dummy><dummy>  
Y68 gives 6 bytes of transmitted data.  
Y70 gives 6 bytes of received data.  
Y8B is zero after debug/microprogram communications timeout.

### 3 Interrupt Test

Message: No message.

Test microprogrammed interrupt of control microprocessor. RP and TM are lit.

### 5 Working Register Address Test

Message: ERR02 <address><errdata><04>  
OK data = address.

### 7 Working Register Data Test

Message: ERR03 <address><errdata><sub>

sub = 01: if lsb.addr = 0 then OK data = AAAA  
else OK data = 5555

sub = 02: if lsb.addr = 0 then OK data = 5555  
else OK data = AAAA

### 7 8085 EPROM Sum Test

Message: ERR0B <expected sum><computed sum><dummy>

### 9 Memory Address Test

Message: ERR04 <address><errdata><sub>  
Y40 gives the module number under test.

The test will read both by means of word and by byte read.  
In the latter case OK data is the byte contents of the address read by byte read.

sub = 02: right parity error = R  
04: left parity error = L  
06: left and right parity error = LR  
41: dataerror  
43: dataerror + R  
45: dataerror + L  
47: dataerror + LR

## B Memory Data Test

Message: ERR05 <address><errdata><sub>

Y40 gives the module number under test.

sub = 02: right parity error = R  
04: left parity error = L  
06: left and right parity error = LR  
40: dataerror, okdata = AAAA in addr 0000  
41: dataerror, okdata = 5555  
42: dataerror + R, okdata = AAAA  
43: dataerror + R, okdata = 5555  
44: dataerror + L, okdata = AAAA  
45: dataerror + L, okdata = 5555  
46: dataerror + LR, okdata = AAAA  
47: dataerror + LR, okdata = 5555

The test will write alternating AAAA,5555.

## D Internal Interrupt Test

Message: ERR06 <low,high><errdata><04>

low = byte with lowest interrupt  
high = byte with highest interrupt

OK data = high.

## F Schedule Test

Message: ERR07 <param1><errdata><sub>

sub = 01: no external interrupt  
02: maperror, okdata = 07FF  
03: external interrupt or missing "interrupt chain end  
plug"  
04: maperror, okdata = 0007  
05: coroutine error, okdata = 0007  
06: coroutine error, okdata = param1  
07: medium priority error, okdata = param1  
08: low priority error, okdata = param1  
09: high FF, okdata = 000F  
0A: mediumFF, okdata = 0017  
0B: low FF, okdata = 001F

## 11 Interrupt Map Test

Message: ERR08 <address><errdata><04>

okdata = address.

### 13 Prefetch Test

Message: ERR09 <address><errdata><sub>

```
sub = 01: load of ICD,      okdata = 5555
      02: load of ICD,      okdata = AAAA
      03: nxtbyte read ICD, okdata = AAAB
      04: nxtword read ICD, okdata = AAAD
      05: nxtbyte read ICD, okdata = address
      06: read of nxtbyte,   okdata = address and OFF
      07: ICD,              okdata = address
      08: nxtword even ICD, okdata = address
      09: nxtword,          okdata = address
      0A: odd addr,         okdata = address
```

### 15 Register Stack Test

Message: ERR0A <param1><errdata><sub>

```
sub = 01: not stack limit
      02: stack limit
      03: size error,      okdata = 0016
      04: stack limit
      05: stack limit
      06: data error,      okdata = param1+7
      08: stack limit
      09: stack limit
      0A: data error,      okdata = param1+7
```

### 2.3 RC5050 Processor Front Panel

The front panel of the RC5050 processor board contains 5 hexadecimal LED digits, 3 push buttons and a console jack.




Fig. 2.3. RC5050 Processor Front Panel

### 2.3.1 Hexadecimal LED Display

The hex display will, at any time during normal operation, indicate both the display mode and the display data type.

#### 2.3.1.1 RC5050 Display Mode

The display mode (i.e. the result caused by pressing the SELECT, UP or DOWN buttons, see section 2.3.2) is indicated by the decimal dots in the hex display.

Idle is indicated by

one dot walking slowly from data digit to data digit in the hex display in direction from LSB to MSB (processor running)

or

all dots blinking together (processor stopped).

Walking / blinking frequency is 1 step per second.

This display mode indicates that the UP and DOWN buttons are disabled.

One walking dot indicates that the processor is running, while all dots binking indicates that the processor is stopped.

Type Select is indicated by one fast blinking dot in the DISP digit. The blink frequency is 5 blinks per second.

This display mode indicates that the UP and DOWN buttons may be used to increase and decrease the value of DISP, thereby selecting the type of data being displayed.

Data Update is indicated by one fast blinking dot in one of the hex data digits. The blink frequency is 5 blinks per second.

This display mode indicates that the UP and DOWN buttons may be used to increase and decrease the value of the presently selected hex data digit, thereby updating the data being displayed.

### 2.3.1.2 RC5050 Display Data Type

The type of data displayed at any time is indicated by the lowest of the 5 hexadecimal LED digits. This digit is marked DISP.

The four upper display digits are used to display data. These are marked MSB to LSB, where MSB holds the most significant digit and LSB the least significant digit.

Below table describes the 16 display data types.

A plus sign in the column marked U means that the data displayed can be updated using the push buttons as described in section 2.3.2 below.

DISP MSB	LSB	U	Meaning
0 x1 x2 x3 x4 +	Autoload	Switches equal (x1 x2 x3 x4)	The autoload switch value may be changed either by using the Push Buttons as described in section 2.3.2 below, or by setting the NVM value by the I N command, see appendix N.
1 x1 x2 x3 x4 +	ID-register	equal (x1 x2 x3 x4)	This ID-register value will, however, be overruled by a physical ID-register such as F506 (IDR202). This value may be changed as described for DISP 0.
2 b1 b2 b3 b4 +	Console	baudrate	equal (b1 b2 b3 b4) This value may be changed as described for DISP 0.

DISP	MSB	LSB	U	Meaning
3	d t l m +			Mode
				<p>m: Console and Test mode, see section 2.2.1.2 . Console baudrate, however, is not affected by the value of m.</p> <p>d: d =&gt; console enabled, - =&gt; console disabled</p> <p>t: T =&gt; test enabled, n =&gt; test disabled</p> <p>l: L =&gt; testloop enabled, - =&gt; testloop disabled</p> <p>This value may be changed as described for DISP 0.</p>
4	t1 t2 e1 e2 -			Hard Error Code
				<p>The detection of a hard error will cause the display to display mode 4 with the mode digit blinking.</p> <p>Error type (e1 e2) indicates the type of error, numbers between 00 and 1F indicates testprogram number e1 e2 while other numbers indicates runtime errors.</p> <p>Error param (y1 y2) further describes the error, see below section 2.3.1.3 for a detailed description of all error displays.</p>
5	a1 a2 a3 a4 -			Latest error addr (a1 a2 a3 a4)
6	d1 d2 d3 d4 -			Latest error data (d1 d2 d3 d4)
7	m1 m2 a1 a2 -			Latest error module address (m1 m2)

DISP	MSB	LSB	U	Meaning
8	r1 r2 r3 r4	-		Service Processor revision
9	r1 r2 r3 r4	-		MicroProgram revision
A	t x1 x2 x3	-		SP Initiator test error  t= 1 => RAM error at addr (x1 x2 x3 0) t= 2 => NVM test t= 3 => Flash test
B	br nv f0 f1	-		SP initiator degraded mode  br: console baudrate 1: 110, 2: 300, 3: 600, 4: 1200, 5: 2400, 6: 4800, 7: 9600, 8: 19200  nv: nvm status (0: checksum error, 1: checksum ok)  f0: flash0 (0: checksum error, 1: checksum ok)  f1: flash1 (0: checksum error, 1: checksum ok)
C	ph - a1 a2	-		SP initiator EEPROM programming  ph: programming phase 0: init, 1: data load, 2: programming)  (a1 a2) current load address
D	- - a1 a2	-		MicroProgram load, addr (a1 a2)
E	- - a1 a2	-		MicroMap load, addr (a1 a2)
F	t1 t2 e1 e2	-		Test Mode, test (t1 t2), error (e1 e2) see below.

### 2.3.1.3 Test Program error display codes

Errors may be detected by either the builtin test programs or by hardware or microprogram during normal operation. In both events the processor stops and displays an error code at the hexadecimal display and on the debugger console. In addition the error code with parameters is stored in the Non Volatile Memory (nvm).

Below table describes the different error codes with their meaning.

test/ error	type	addr	data	description
00	aa	-	-	Configure memory, module aa. Done by SP.
01	-	d1	d2	SP / MP communication test.  If d1 equals 0 then d2 contains data found, which should have been \$ffff.  If d1 differs from \$ffff then d1 and d2 contains data found, which should have been \$55aa and \$aa55, respectively.
02	-	a	d	Register address test.  At address a was found data equal d, and data equal a was expected.
03	-	a	d	Register data test.  At address a was found data equal d, and data equal either \$5555 or \$aaaa was expected.
04	-	a	d	Working Register address test.  At address a was found data equal d, and data equal a was expected.

test/ error	type	addr	data	description
05	-	a	d	Working Register data test.  At address a was found data equal d, and data equal either \$5555 or \$aaaa was expected.
06	-	-	d	Gate Array Register test.  Gmode/Gstat register data error, data d found, data \$5555 expected.
07	-	a	d	Scheduler RAM test.  At scheduler RAM address a data d was found, (\$1ff8 -a) div 8 and 7 was expected.
08	-	exp	found	Scheduler NextSet test.  SchRAM(1):= 1; SchRAM(2):= 2; SchRAM(3):= 4;  Scheduler delivered found, not exp.
09	typ	intno	R1	Interrupt Chain test.  Type 1, R1 = 2000 : Interrupt 7 cannot be set.  Type 1, R1 < 100 : Interrupt R1 cannot be cleared.  Type 2 : Interrupt chain disconnected.
0A	Type	addr	data	Memory address test.  Error found at <errormodule>:<addr>, found <data>.  Type = GateArray ErTyp register or'd with \$10, see GA error code section.

test/ type addr data description  
error

0B Type addr data Memory data test.

Error found at <errormodule>:<addr>, found  
<data>.

ErrType = GateArray ErTyp register or'd  
with \$10, see GA error code sec-  
tion.

test/ error	type	addr	data	description
0C	Sub	d1	d2	Hardware Stack test.
				Sub Error
				1 Cs does not remove StkLim, d1 and d2 undefined.
				2 Cs, Pop does not set StkLim, d1 and d2 undefined.
				3 Cs, PopB does not set StkLim, d1 and d2 undefined.
				4 Less than 9 Push's set StkLim, d1 and d2 undefined.
				5 9 Pushs does not set StkLim, d1 and d2 undefined.
				6 Less than 9 Pop's set StkLim, d1 and d2 undefined.
				7 Data error during Pop after Push d1 = expected, d2 = found.
				8 Less than 9 PopB's set StkLim, n/a
				9 Data error during PopB after Push, n/a
			a	Less than 9 PushB's set StkLim, n/a
			b	Less than 9 Pop's set StkLim, n/a
			c	Data error during Pop after PushB, n/a
			d	Less than 9 PopB's set StkLim, n/a
			e	Data error during PopB after PushB, n/a
			f	Ssize error, d1 = expected size, d2 = Ssize found
			10	Stack(Radr) integrity Test data error, d1 = expected data, d2 = data found
			11	Stack(Radr) integrity Test size error, d1 = expected size, d2 = Ssize found

test/ error	type	addr	data	description
0D	0	-	v	Microsecond Timer test  The microsecond timer value v is outside the range 199 - 201 after 2000 microprogram steps.
0E	Sub	d1	d2	FIFO test.  Sub Error  1 Fe (FIFO empty) status after one Push, d1 = d2 = undefined  2 Data error at first 7 Pop's d1 = data expected, d2 = data found  3 Premature Fe (FIFO empty) status, d1 = d2 = undefined  4 Missing fe after 8 Pop's, d1 = d2 = un- defined  5 Data error at 8th Pop, d1 = data expec- ted, d2 = data found

test/	type	addr	data	description
error				
OF	Sub	d1	d2	PreFetch test Sub Error 1 Even addr Nxb (d2) differs from expected (hi(d1)) 2 Icd (d2) differs from expected (d1) 3 Smem NxbI byte counter (d1) differs from expected (d2) 4 Odd byte Nxw (d2) differs from expected (d1) 5 Odd byte Nxb (d2) differs from expected (d1) 6 Even byte Nxw (d2) differs from expected (d1) xx Where xx has bit 4 (\$10) set indicates a GateArray error xx, see GA error code section.
1F	-	-	-	Microprogram communication error. The Service Processor received a request from the microprogram with request code equal zero.
20	type	addr	data	Gate Array detected error. The Gate Array error code is found in <type>, see below description. The module is <addr>, if relevant, and the displacement is <data>, if relevant.
21	-	inst	reg	Stack Limit error The hardware stack for registerset <reg> has over- or underflowed during execution of an instruction with code <inst>.

test/ error	type	addr	data	description
22	-	-	-	<p>Unchain Register error</p> <p>An unchain register set operation terminated either because the register set were not part of any chain (CH = \$FFFF) or because the register set were not found as member of the chain.</p>

#### 2.3.1.4 Gate Array Error Codes

An Gate Array error code is a bit array, where each bit indicates an error.

Bin	Hex	Meaning
1xxxxxxx	\$80	Addressing non-existing memory.
x1xxxxxx	\$40	I/O timeout during IORS or IORW.
xx1xxxxx	\$20	Byte operation.
xxx1xxxx	\$10	This bit does not indicate an error and may be ignored.
xxxx1xxx	\$08	n/a.
xxxxx1xx	\$04	Left Parity error.
xxxxxx1x	\$02	Right Parity error.
xxxxxx1	\$01	RC3502 Bus Timeout. /read or /write exceeds 16 uSec.

E.g.: \$A0 means Addressing non-memory with byte access. \$B0 has same meaning.

### 2.3.2 Push Buttons

The RC5050 Front Panel has three push buttons located below the hex display marked: UP, DOWN, and SELECT.

The hex display will at any time during normal operation indicate both the display mode and the display data type.

Pressing the SELECT button will change the display mode in a cyclic way:

Idle Mode	to
Type Select	to
Data update digit 1 (MSB)	to
Data update digit 2	to
Data update digit 3	to
Data update digit 4 (LSB)	to
Idle Mode	

Result of pressing the UP or DOWN button depends upon the current display mode as indicated at any time during normal operation by the hex display decimal points.

The display data type (i.e. the type of data presently displayed) is indicated by the DISP digit as described in section 2.3.1.2 above.

The display mode (i.e. the result caused by pressing the UP or DOWN buttons) is indicated by the decimal dots in the hex display as described above.

Pressing one push button during power-up will cause the Service Processor Initiator to refrain from entering normal execution and at the same time select a specific console baud rate:

Push button	Result
UP	Select 19.200 baud
DOWN	Select 9.600 baud
SELECT	Select 1.200 baud

## 2.4 POW207 Power Supply

The power supply POW207 is supplied with the following controls:

POWER: Circuit breaker, lit when power on.

POWER OK: Indicator which is illuminated during power ok condition.

POWER FAILURE:

OVER-TEMPERATURE:

OVER-VOLTAGE: Error indicators which are illuminated after an error condition. These indicators are reset after activating the circuit-breaker later than 10 sec. after power off, or after activating the RESET pushbutton.

RESET: Push-button for manual generation of an autoload signal and a reset of the error indicators. When this control is activated, the voltage to the crate will be turned off. Use the Autoload button on the OCP to generate an autoload signal without turning off the power.

## 2.5 POW240/241 Power Supply

The power supplies POW240 / POW241 are supplied with the following controls:

PHASE NO  
SLAVE NO Hex switches used for setting the load levelling phasing of the mains supply. The recommended setting is:

Total no of supplies	Master setting	Slave 1 setting	Slave 2 setting
1	PHASE 0 SLAVE 1		
2	PHASE 0 SLAVE 1	PHASE 1 SLAVE 1	
3	PHASE 0 SLAVE 2	PHASE 1 SLAVE 2	PHASE 2 SLAVE 2

UNIT OK      This green LED indicates that the power module is working and contributes sufficient to the total load.

RESET      Pressing this countersunk pushbutton will reset both the power supply modules and all processing modules connected to the back plane bus.

## 3. CONSOLE OPERATION

The console may be in one of two possible modes: Debug-mode (D-mode) or Terminal-mode (T-mode). A switch between the two modes takes place when the BELL key (<CTRL>G) is activated.

### 3.1 Terminal Mode

The console may work as terminal for the RC5000 software system, while in T-mode.

An operator process coordinates the communication between the software system and the operator.

#### 3.1.1 Operator Process

Input and output messages to the operator are identified by a name. The operator process holds a variable 'current name', which identifies the current process for input or output.

'Current name' is updated in the following situations:

##### 1. <ESC> <name> <NL>

The input line contains a name which is assigned to 'current name'. The operator searches its queue of pending input messages for a message with <name> as identification. If at least one message is found, it is activated. If it is a reactivation, the old input is repeated.

If no message is found, BELL is echoed.

Note: <ESC> <NL> is attention to 'current name'.

##### 2. By output.

If the output message has name = 'current name', the output message is printed on the console.

If the output message has name <> 'current name', 'current name' is updated and

> "current name"

is printed followed by the text from the output message.

##### 3. <ESC> ? <NL>

Prints the identifications of all pending input messages. 'current name' is updated to the last name in the printout.

The operator has a number of facilities for controlling output and for editing purposes:

<CTRL> E	- deletes the whole line
<BS>	- deletes the last character
<ESC> <NL>	- repeats the whole line
<RUBOUT>	- deletes the last character ('-' is echoed).
<CTRL> S	- stops output. May be reset by <ESC>.
<CTRL> Q	- starts output.
<CTRL> O	- skips output. The function is alternating between skip and noskip, and is reset to 'no skip' by <ESC>.

Note: <NL> may be Carriage Return or Line Feed.

### 3.1.2 OPSYS Commands

OPSYs interprets the following commands. The underscored characters are sufficient for the interpretation.

More than one command may be typed on one line, unless the syntax is terminated by <nl>.

Whenever <process> or <program> is listed - unless otherwise stated - we refer to incarnations of two program families declared in ADAM with one of the following headings:

```
PROGRAM pip (VAR sv: system_vector);  
PROGRAM pop;
```

In the following all numbers are decimal, unless otherwise stated.

#### BREAK <process>

The child <process> is broken with the current value of excode as exception code.

The child may be any process in the process tree.

E.g.:      BREAK S

#### CHECK <module>

performs a CRC16 check of the memory module <module>. <module> is the hexadecimal base address. If an error is detected, the word address interval, the expected, and computed checksum are printed.

E.g.:      CHECK F2

CREATE <process> ( AS <program> ) <sup>1</sup>  
0

creates an incarnation of the program <program>. If AS <program> is omitted the program is supposed to have the same name as the process. The size of the stack is the current value of SIZE (see the SIZE command).

E.g.: CREATE T1 AS TEST CREATE T2 AS TEST

DATE ( <year>.<month>.<day> <hour>.<minute>.<seconds> ) <sup>1</sup>  
0

If the parameters are included the date is initialized. The command always responds with the current date.

E.g.: DATE 88.06.14 15.30.20

EXCODE <integer>

initializes the current value of excode to <integer>. Default: excode = -1.

E.g.: EXCODE 47

FREE ( <module> ) <sup>1</sup>  
0 <nl>

lists the free interruption levels and memory bytes. If <module> is specified, the free memory areas in the RAM module <module> are listed. The start displacement and size in bytes of the holes are listed, besides the number of holes, the minimum hole, the maximum hole and the sum of the holes.

FROM ( FPA  
LAN )

initializes the current value for load kind to FPA or LAN. Load kind controls the kind of driver used for dynamic load (see LOAD). Default load kind is taken from the hexadecimal switches.

E.g.: FROM LAN

GETSWITCHES

lists the current value of the four switches marked BUS on the Processor Front Panel.

HELP

lists the available OPSYS commands.

IN <inchannel>

initializes the current value of the I/O channel used for load.  
Default <inchannel> is taken from the hexadecimal switches.

E.g.: IN 16

KILL <process>

works as the REMOVE command.

LINK <program>

links a program with name <program> to a program declaration in ADAM.

E.g.: LINK CPUSE

LIST ( <process> ) <sub>n</sub> <sup>0</sup> <nl>

lists the process tree with root <process>. If <process> is missing 'adam' is taken as root. The wildcard character '\*' may be used in <process> to specify zero or more occurrences of "I don't care" characters. If wildcard characters occur, only processes fulfilling the wild compare operation are listed. The process state 'fault' means that the process has entered the 'exit' state via an exception.

E.g.:

list							
process	depth	prio	state	stack	regset	father	
adam	0	-1	wait	c0.d648	084	operator	
opsys	1	-1	run	c0.d9d0	085	adam	
fs	1		exit	c0.e0c0	086	adam	
bfs	2	-2	wait	c0.fa9c	08b	fs	
lfs	2	-2	wait	c6.aaf0	08a	fs	
fsevent	2	-2	wait	c0.f024	089	fs	
dsml	2	-2	wait	c0.ed04	088	fs	
sail	2	-2	wait	c0.e9c8	087	fs	

LISTMAILBOX <process> ( <mailbox> )

lists the mailbox catalog of the process, besides the state of the named mailboxes. If no key mailbox name is specified all catalogued names are listed. If the mailbox key contains wildcard characters, only the mailbox names fulfilling a wild compare operation are listed.

LOAD ( <program> )<sup>n</sup><sub>0</sub> <nl>  
or  
LOAD <filename> <nl> if LAN

loads the programs from an external device of kind 'current load kind' (see the FROM command) in the I/O channel 'current in-channel' (see the IN command). If no programs are specified, all appearing programs are loaded.

E.g.: FROM LAN IN 16 LOAD MYFILE  
E.g.: FROM FPA IN 81 LOAD PRINTCHAR PRINTNL

A binary relocatable file is loaded from RC8000 via FPA by e.g.:

MAIN35001 = CRC16 ( Bxxxx )<sup>n</sup><sub>1</sub>

LOG <module>

prints the contents of the MEM205 or MEM206 errorlog, if not empty.

E.g.: LOG C8

LOOKUP ( <program> )<sup>n</sup><sub>0</sub> <nl>

makes a lookup in the LINKER catalog for the listed programs.

If <program> is empty, the whole LINKER catalog is listed. 'LOOKUP PROGRAM' lists all the programmes, 'LOOKUP FUNCTION' lists all the functions, 'LOOKUP PROCEDURE' all the procedures, and 'LOOKUP DATA' all the data programmes. Note: The wildcard character '\*' may be used in <program> to specify zero or more occurrences of "I don't care" characters.

E.g.:

lookup program						
>linker						
PROGRAM linker	1990.03.25:13.53	1990.03.25:14.02	4312	3.4		
PROGRAM monitor	1990.11.05:08.34	1990.11.05:08.37	6438	3.4		
PROGRAM timer	1990.03.25:13.53	1990.03.25:14.02	3538	3.3		
PROGRAM allocator	1990.03.25:13.53	1990.03.25:14.02	4556	3.6		
PROGRAM printexcept	1990.10.30:09.57	1990.10.30:10.01	5676	3.10		
PROGRAM adam	1990.03.25:13.53	1990.03.25:14.02	9060	4.1		
PROGRAM opsys	1990.11.05:08.27	1990.11.05:08.31	11178	4.1		
PROGRAM loader	1990.10.30:08.57	1990.10.30:09.00	7878	3.10		
PROGRAM loaddriver	1990.10.30:08.57	1990.10.30:09.00	558	3.10		
PROGRAM fp	1990.10.15:22.55	1990.10.15:22.59	12064	1.18		
PROGRAM getfp	1987.06.09:14.12	1987.06.09:14.14	2314	1.7		
PROGRAM fts	1990.07.17:11.59	1990.09.10:10.30	5876	3.0		
PROGRAM lld	1990.10.24:08.07	1990.10.24:08.17	4884	2.11		
PROGRAM mfc2	1990.06.11:13.06	1990.06.11:13.13	6462	2.11		
PROGRAM fsformat	1990.09.27:11.35	1990.10.09:09.54	6966	2.13		
PROGRAM fstest	1987.05.11:10.40	1990.10.09:09.59	2974	0.0		
PROGRAM dsm	1990.09.27:16.25	1990.10.09:08.43	3850	2.8		
PROGRAM fosc	1990.10.09:07.40	1990.10.09:08.45	2986	2.3		
PROGRAM bfs	1990.09.19:14.45	1990.10.09:08.50	5512	2.5		
PROGRAM lfs	1990.10.01:17.49	1990.10.09:08.53	5300	2.7		
PROGRAM fs	1987.03.25:15.31	1990.10.12:16.38	3168	0.0		
PROGRAM saidriver	1990.11.02:16.25	1990.11.02:16.27	4916	1.7		
PROGRAM fsevent	1987.10.13:13.30	1990.10.09:09.48	5164	0.0		
PROGRAM resetsai	1990.08.28:09.33	1990.10.12:17.24	1642	1.1		
PROGRAM lf3502	1990.10.17:13.46	1990.10.17:13.52	10946	2.23		
PROGRAM initboot	1990.09.13:13.10	1990.09.27:15.55	248	6.2		
PROGRAM boot	1990.09.20:12.07	1990.09.27:16.25	36252	11.2		

The output has the interpretation:

1. program kind
2. program name
3. date of source
4. date of compilation
5. size of object code in bytes
6. version

PRINT ( <base> ) <first disp> ( <last disp>  
 ( <no of words per line> ( <delta> )<sup>1</sup><sub>0</sub> )<sup>1</sup><sub>0</sub> )<sup>1</sup><sub>0</sub> )<sup>1</sup><sub>0</sub> )<sup>1</sup><sub>0</sub> <nl>

outputs the specified memory area with a fixed format (see the example): <base>, <first disp>, and <last disp> are hexadecimal.

*<delta>* defines the default increase of *<first disp>* if *<last disp>* is not specified. After the PRINT command *<first disp> := <last disp> + 2*.

E.g.:

```
prin c0 0 10 2
  address
c0.0000 0204    516    2    4        0314    788    3    20
c0.0004 0000      0    0    0        000d    13     0    13
c0.0008 7f53 32595 127  83      S    4010 16400   64   16   @
c0.000c ff00   -256   255    0        8000 -32768  128    0
c0.0010 0000      0    0    0
```

#### PRIORITY <integer>

initializes the current value for priority used by the START or RUN command.

Default: priority = -2.

E.g.: PRIORITY -1

#### REMOVE <process>

removes the child *<process>* of ADAM and the associated subtree.

E.g.: REMOVE S

#### RENAME <old program> <new program>

changes the name of *<old program>* to *<new program>*. Only loaded programs (as opposed to autoloaded), which are not accessed by other programs in the system, may be renamed.

E.g.: RENAME MYPROG XMYPROG

#### RESOURCE ( <process> ) <sub>1</sub><sup>n</sup> <nl>

lists the memory resources occupied by the process tree with root *<process>*. The process tree is searched for like the LIST command.

The allocated and used memory for process stack and process heap are listed, besides the messages allocated by the process in terms of no. of messages with bufsize = 0 (Msg0), no. of messages with bufsize > 0 (MsgN) and a sum of all bufsizes (bufsizeN).

RESTART

removes ADAM and the whole application tree, whereafter a link, create and start of ADAM is executed.

RUN <process> AS <program>

links, creates, and starts an process with name <process> of the program <program>.

If <program> is omitted, the program is supposed to have the same name as the process.

E.g.: RUN T1 AS TEST RUN MIRROR

SERVER <servername>

initializes the current value for the FTS server name, used when loading from LAN.

SETSWITCHES <hex>

updates the current internal value of the four switches marked BUS on the Processor Front Panel. The BOOT program may be controlled without changing the physical switches.

SIZE <integer>

initializes the current value of SIZE in bytes used when creating ADAM children.

Default: SIZE = 0.

(Note: SIZE = 0 will trigger the use of the default create size for the program).

E.g.: SIZE 1526

START <process>

starts the ADAM child <process> with the current value of PRIORITY as priority.

E.g.: START S

STOP <process>

stops the ADAM child <process>.

E.g.: STOP S

TRACE <process>

the child <process> is stopped while the current stack of routine activation records of the process is listed.

UNLINK <program>

unlink a program with name <program> from a program declaration in ADAM.

E.g.: UNLINK CPUSE

UNLOAD <program> <nl>

unlink, if necessary, and deletes the programs from the LINKER catalog, if the programs are not referenced by other programs. If other programs become not referenced after the delete, these programs are also deleted.

E.g.: UNLOAD CPUSE TEST

USER <username>

updates the current value of the FTS username, used when loading from the current FTS server.

### 3.1.3 Messages from OPSYS

The rest of the command line is skipped if any of the following messages appear:

\*\*\* loader not ready

- the LOADER or the LAN Load Driver, LLD, is not included in the system or is unable to run owing to lack of memory.

\*\*\* command not implemented

- the command is not available in this version of OPSYS

\*\*\* syntax error

- misspelling of a command
- \*\*\* programname missing
- \*\*\* unknown process
- \*\*\* unknown program
- \*\*\* programname busy
  - incarnations of this program still exist
- \*\*\* processname missing
- \*\*\* name in use
- \*\*\* no free programdeclarations
  - you must release a program declaration in ADAM by the command UNLINK
- \*\*\* program not loaded
  - the LINKER catalog does not contain the stated program
- \*\*\* program parameters not equal
  - a program with the stated name exists in the LINKER catalog, but the parameter list does not fulfil the declaration
- PROCESS pip;
- \*\*\* size too small or too large
  - use the SIZE command to adjust the SIZE parameter
- \*\*\* program not linked
  - use the LINK command
- \*\*\* unknown program
  - the program is not in the LINKER catalog. The program may be loaded by the LOAD command
- \*\*\* program busy
  - the program is still accessed by other programs in the system

### 3.1.4 Messages from LOADER

\*\*\* install more ram memory

- the LOADER cannot get enough memory to run

\*\*\* loaddriver no stack

- the driver cannot be created due to lack of memory

\*\*\* level reservation trouble

- the interrupt level requested for load is occupied by another program incarnation in the system

scan no: x from fpa in xxxx

- initialize load from RC8000 when the first scan is announced (Note: xxxx is decimal). Later scans are performed by the loader itself with no need for operator assistance.

expected: xxxx

received: xxxx

- the crc16 data check reports an error. The programs should be reloaded

end loader

- normal finis message from the LOADER. A list of the loaded programs is printed with name and compilation date. The list may be extended with the information

\*\*\* warning: versionerror

- the program should be recompiled, but loading continues

\*\*\* loadfile unintelligible

- the loadfile has the wrong format or is garbage.

\*\*\* allready loaded

- the program is already in the LINKER catalog. The program in the catalog is used instead and the loaded program deleted

\*\*\* not defined

- the program was not in the LINKER catalog or amongst the loaded programs.

## 3.2 Debug Mode

### 3.2.1 Activation

When the MODE switch is set in the range 0 to 7, the console may be set into Debug-mode (D-mode) at any time by pressing the BELL key (CTRL and G keys). This will not change the processor execution state.

A number of display and control commands are available for technical purposes.

NOTE: In D-mode the commands must be typed with capital letters (e.g. with alpha lock activated).

An illegal command will be displayed as an asterix.

In below description the commands marked *RC5050* are available for the RC5050 processor only.

### 3.2.2 Display Commands

Display commands cause the display of 8 words or 16 bytes of data. RC5050 will display the data as ascii characters as well.

The following display commands are available:

M <addr>      Modify Memory  
                    Displays the contents of the 8 memory words starting at <addr>.

W <regset>      Modify Working Registers  
                    Displays the contents of the 8 working registers comprising registerset <regset>.

P <regset>      Modify Register Stack  
                    Displays the contents of the register stack associated with registerset <regset>. At most 8 register stack elements are displayed.

L <level>      Modify Working Registers  
                    Displays the level number, the registerset, and the contents of the 8 working registers comprising the registerset connected to <level>.

Y <yaddr>      Modify Control Microprocessor RAM  
                    Displays the contents of the 8 control microprocessor RAM bytes starting at <yaddr>.

I C <no>      Inspect Control Registers      *RC5050*  
                    Displays the contents of the 8 control registers starting with <no>. Control register x is equal to Work Memory address xFF.

I F <f><addr> Inspect Flash Memory *RC5050*

Display the contents of the 16 bytes of flash memory <f> (EEPROM) starting at address <addr>. Flash Memory 0 contains the Service Processor program and Flash memory 1 contains the microprogram.

I N <addr> Inspect Non-Volatile Memory *RC5050*

Display the contents of the 16 bytes of NVM memory starting at address <addr>. The format of the NVM is described in Appendix N. See also the command I ? .

I R <addr> Inspect Register *RC5050*

Display the contents of the 8 registers starting at address <addr>, which is an absolute register address. E.g. the command W 1 is equal to I R 8 .

I S <addr> Inspect Service Processor RAM *RC5050*

Display the contents of the 16 bytes of Service Processor Memory starting at address <addr>.

I W <wno> Inspect Work Memory *RC5050*

Display the contents of the 8 work registers starting at <wno>. <wno> is entered as three hexadecimal digits in the format baa, where b is the bank number in the range 0..F, and aa is the work register number in the range 00..7F. See appendix M for a description of work register utilization.

I Y Inspect Y-RAM Formatted *RC5050*

Display the memory area normally accessed by the Y command formatted and commented. Data cannot be updated with this command.

I ? Inspect Non-Volatile Memory Formatted *RC5050*

Display the Non-Volatile Memory (NVM) normally accessed by the I N command formatted and commented. Data cannot be updated with this command.

? Display all Service Processor commands *RC5050*

Display a list of all accepted Service Processor commands.

Display commands are executed, when a display command is entered.

It is now possible to modify the displayed data by entering new data in the same positions on the following line. Pressing the space bar will move the cursor one position to the right. All updates are byte per byte.

When a P command is terminated (by CR, +, or -) the cursor position defines the number of register stack elements. If the number has been changed, a H is displayed. Note, that a cursor on the first position does not empty the register stack. This is done by the # key (see later).

A display command is terminated by pressing one of the following keys:

- # The # key (ascii 23 hex) terminates the P command with an empty register stack. Otherwise # is blind.
- CR The CR key terminates the current display command. The console will await the next command.
- + The + key terminates the current display command and executes a display command for the succeeding 8 words (M), 8 bytes (Y), up to 8 elements (P), or the 8 registers on the succeeding level (W,L).
- The - key terminates the current display command and executes a display command for the preceding 8 words (M), 8 bytes (Y), up to 8 elements (P), or the 8 registers on the preceding level (W,L).
- . The . key terminates the current display command and executes a display command for the same 8 words (M), 8 bytes (Y), up to 8 elements (P), or the 8 registers on the same level (W,L).
- ESC The ESC key terminates the current display command, but no data modification takes place in the M, W, P, and L commands. The text <ESC> is displayed. The console will await the next command.

### 3.2.3 Control Commands

The following control commands are available:

R                   Run

The processor will start instruction execution.

S                   Instruction Step

The processor will execute one instruction, stop, and display the current levelno, the registerset, and the contents of the 8 working registers, and reactivate the console. Modification of the displayed data is not possible. The watchdog timer will stop, if started.

S <steps>       Multi-Instruction Step

The processor will execute <steps> instructions, stop and reactivate the console.

Z                   Instruction Step

The command works as the S command. The P display command is performed implicitly, so the contents of the current register stack is also displayed.

Z <steps>       Multi-Instruction Step

The command works as the S <steps> command, but a P display command is performed implicitly for each instruction step.

T <testno>      Single Selftest

The processor will execute a single selftest, in a loop mode, according to the following table. If testno is chosen as C1-D5 for RC5040 and 81-8F for RC5050, then there will be no errormessage, and the test will continue even if an error occurs. The memory test is performed on 64K bytes blocks according to the RAM configuration bit map. See app K.

The test can be terminated by use of the ESC key. Errorno + info are explained in 2.2.2.

In below test descriptions the function marked "stop at error" is to stop and output an error message at first occurrence of an error while the function marked "ignore error" is to detect errors, but not output any error message and not terminate the repetitive execution of the test.

**RC5040:**

testno stop at error	testno ignore error	err no	test
00C1	0081	00	fifo test
00C3	0083	-	7.5 interrupt test
00C5	0085	02	W-register address test
00C7	0087	03	W-register data test
00C9	0089	04	memory address test
00CB	008B	05	memory data test
00CD	008D	06	internal intr. test
00CF	008F	07	schedule test
00D1	0091	08	intmap test
00D3	0093	09	prefetch test
00D5	0095	0A	register stack test
00D7	0097	0B	8085 EPROM sum test
00DF	009F	-	'power' restart, but no reset of controllers

## RC5050:

testno stop at error	testno ignore errors	test
1	81	SP / MP Interrupt Test
2	82	Register Address Test
3	83	Register Data Test
4	84	Working Register Address Test
5	85	Working Register Data Test
6	86	Gate Array Register Test
7	87	Scheduler RAM Test
8	88	Scheduler Nxs Test
9	89	Interrupt Chain Test
MM0A	MM8A	Memory Address Test
MM0B	MM8B	Memory Data Test
C	8C	HW Stack Test
D	8D	MicroSec Counter Test
E	8E	FIFO Test
MM0F	MM8F	PreFetch Test

Tests marked MM will use the high order byte of the <testno> command parameter as module address, e.g: T C28F will start the Prefetch Test in module C2 and ignore errors encountered.

A 16 bits pass counter can be used in single test execution. It will be set to zero, when the T command is used, and is incremented by one before each pass. The value may be examined, when the T command has terminated after ESC or after an error. For RC5040 the command Y65 gives the LSB, and Y66 gives the MSB of the pass counter. For RC5050 the pass counter value is displayed at test termination.

T ? Display list of selftests *RC5050*

Display a list of available selftests.

C G Control: Gate Array Reset *RC5050*

This command will issue a Gate Array reset.

C I Control: Restart SP Initiator *RC5050*

This command will cause the processor to stop and enter the Service Processor Initiator to restart, i.e. micro program load, test programs and autoload will not be initiated.

C R

Control: Restart Processor

RC5050

This command will cause the processor system to issue a bus reset and restart the system exactly like a power on restart.

C W

Control: Watch Dog Restart Processor

RC5050

This command will cause the processor system to restart exactly like a Watch Dog restart.

### 3.2.4 Command Parameters

All numbers entered or displayed are hexadecimal.

At any time the entering of an empty command (i.e. pressing the CR key) will cause the previous command to be repeated.

An address (<addr>) is entered using one of the following formats:

or            <base> : <disp>  
                  : <disp>

<base>    is the leftmost 8 bits of the 24-bit address.

<disp>    is the displacement within the selected memory module, i.e. the rightmost 16 bits of the address.

If the second format (: <disp>) is used, the last entered address base will be echoed and used.

## 4. AUTOLOADING

The autoload function may be initiated by:

- Power Restart
- Watchdog Restart

### Power Restart

Power Restart happens:

- when power ON is performed manually on the OCP or on the power supply,
- by temporary power failure,
- by manual activation of the autoload button on the OCP or the AUTO push button on the power supply.

The built-in test programs are activated controlled by the 'MODE' switch, the CPU initializes the registers, whereafter control is passed to the autoload program residing on the first memory module.


### Watchdog Restart

Watchdog Restart may be activated both manually by means of the 'Y' or C W debug console command and from the software. See app. K.

The CPU initializes the registers, whereafter control is given to the autoload program. No built-in test programs are activated.

### 4.1 Autoload Switch Format

The autoload program interprets the four BUS switches on the Processor Front Panel according to the format:



The autoload KIND field defines which algorithm the autoload program executes, whereas the MODULE number and ADDRESS fields have different interpretations depending on the value of the KIND field. The description in this section is ordered according to the value of the KIND field. That is, a subsection for each value of the KIND field. The kind values 8, 9, 12, 14 and 15 (decimal) are currently not used.

#### 4.1.1 KIND = 0: LAN + X.25/3

Autoload is from RclAN. If the autoload fails, an X.25/3 autoload via COM204 is initiated. After autoload the software in EPROMs is included.

When loading from LAN, MODULE number controls the USER name, when the RC5000 tries to LOGON to an FTSSERVER.  
FTSUSER name

MODULE	FTSUSER NAME
0	cp<ID register>
1-E	cp1..cp14
F	cp

The ID register postfix is four hexadecimal digits. The FTSSERVER's are requested for autoload of the file 'boot9330' N times in a cyclic way. When this limit is reached, the basic FTSUSER name is changed from cp to pp and the cyclic file requesting is continued N times. If no success, a permanent fall back to X.25/3 autoload is performed.

When a X.25/3 autoload is performed with kind = 0, MODULE number is pretended to be 0, causing the X.25/3 autoload to try the possible X.121 addresses in a cyclic way.

For a detailed description of an X.25/3 autoload, please refer to section 4.1.8 below.

#### Conventions:

1. COM204 interruption level must be 72 (48 hex).
2. MFC20X interruption level must be 16 (10 hex).

#### Example

Autoload from RclAN via MFC20X with FTSUSER = cp7 on interruption level 16 (decimal). If the autoload fails after requesting N FTSSERVERs, change FTSUSER to pp7 and continue with N requests. If the autoload still fails, continue with X.25/3 autoload via COM204, as if the switch settings were 70xx.

70xx

#### 4.1.2 KIND = 1: WD

Autoload is from Winchester Disc, and the software in EPROMs is included.

The MODULE number field has the interpretation:

4-7

L		
U	C	U
N		

CU - defines the Control Unit number of the Disc Controller on the SCSI bus.

LUN - defines the Logical Unit Number of the Winchester Disc at the Disc Controller.

The ADDRESS field specifies the SAI201 DATA interruption level.

#### Example

Autoload from Winchester Disc with LUN = 1 via disc controller with CU = 2, SAI201 data interruption level 83 (decimal) and SAI201 control interruption level 82 (decimal):

1A53

#### 4.1.3 KIND = 2: FPA (Autoload Enabled)

Autoload is from FPA, and the software in EPROMs is included. Drivers controlling external devices may autoload the RC5000 by activating the watchdog function (autoload is enabled).

The MODULE number has no significance.

The ADDRESS field specifies the FPA100 REC interruption level.

Example

Autoload from FPA in channel 81 (decimal)

2x51

4.1.4 KIND = 3: WD + COM204

Autoload is from Winchester Disc. If the autoload fails, a COM204 autoload is initiated. After autoload the software in EPROMs is included.

The MODULE number and ADDRESS fields are only used to specify the COM204 autoload.

Therefore be aware of the following conventions concerning the WD autoload:

1. The Control Unit, CU, of the disc controller on the SCSI bus must be 0.
2. The Logical Unit Number, LUN, of the winchester disc at the disc controller must be 0.
3. The SAI201 data interruption level must be 87 (decimal).
4. The SAI201 control interruption level must be 86 (decimal)

If the WD autoload fails, a COM204 autoload is initiated. Then the interpretation of the MODULE number field is:

4-7

F	F A N		

F - defines the type of load request transmitted on the HDLC line:

- 0 PAXNET loadrequest
- 1 X.25/3 loadrequest

FAN- defines the maximum relative channel number used for autoload in a cyclic way if a channel fails. Channels 0,1,...FAN relative to the start channel are used.

The ADDRESS field specifies the CHANNEL\*128 + COM204 interruption level. That is, the leftmost bit of the ADDRESS field specifies the

channel (A/B corresponding to 0/1) and the rightmost 7 bits specify the COM204 interruption level.

Conventions:

1. Start address of the reference controller must be 90.0000.
2. Interruption level of the reference controller must be 72.
3. The controllers must be consecutive and increasing memorywise and according to interruption levels (see the following table).

	address	level	channel	
Reference Controller	90.0000	72	A B	<- 3)
	90.8000	73	A B	
	92.0000	74	A B	
First Controller	92.8000	75	A B	<- 3) <- 1)
	94.0000	76	A B	
Last Controller	94.8000	77	A B	<- 2) <- 3)
	96.0000	78	A B	
	96.8000	79	A B	

- 1) first channel in fan
- 2) last channel in fan
- 1) For COM204 strapped to 32 kbyte Dual Port memory only.

Example

Autoload from Winchester Disc with LUN = 0 via disc controller with CU = 0, SAI201 data interruption level 87 (decimal) and SAI201 control interruption level 86 (decimal). If the autoload fails, autoload is from COM204 address 92.8000 level 75 (decimal) channel B using PAXNET loadrequest and a fan consisting of 3 channels:

32CB

4.1.5 KIND = 4: LAN

Autoload is from RclAN, and the software in EPROMs is included.

MODULE number controls the USER name, when the RC5000 tries to LOGON to an FTSSERVER.

MODULE	FTSUSER NAME
0	cp<ID register>
1-E	cp1..cp14
F	cp

The ID register postfix is four hexadecimal digits.

The FTSSERVER's are requested for autoload of the file 'boot9330' indefinitely in a cyclic way.

The ADDRESS field specifies the MFC20X interruption level.

Example

Autoload from RclAN via MFC20X with FTSUSER = cp on interruption level 16 (decimal).

4F10

#### 4.1.6 KIND = 5: COM204

Autoload is from COM204 (Intelligent HDLC Controller), and the software in EPROMs is included.

The MODULE number field has the interpretation:

4-7

F		F	A
			N

F - defines the type of load request transmitted on the HDLC line:

- 0 PAXNET loadrequest
- 1 X.25/3 loadrequest

FAN- defines the maximum relative channel no. used for autoload in a cyclic way if a channel fails. Channels 0,1,...FAN relative to the start channel are used.

The ADDRESS field specifies the CHANNEL\*128 + COM204 interruption level. That is, the leftmost bit of the ADDRESS field specifies the channel (A/B corresponding to 0/1) and the rightmost 7 bits specify the COM204 interruption level.

Conventions:

1. Start address of the reference controller must be 90.0000.
2. Interruption level of the reference controller must be 72.
3. The controllers must be consecutive and increasing memorywise and according to interruption levels (see the following table).

	address	level	channel	
Reference Controller	90.0000	72	A B	<- 3)
	90.8000	73	A B	
First Controller	92.0000	74	A B	<- 3) <- 1)
	92.8000	75	A B	
Last Controller	94.0000	76	A B	<- 2)
	94.8000	77	A B	<- 3)
	96.0000	78	A B	
	96.8000	79	A B	<- 3)

- 1) first channel in fan
- 2) last channel in fan
- 1) For COM204 strapped to 32 kbyte Dual Port memory only.

#### Example

Autoload from COM204 address 92.8000 level 75 (decimal) channel B using PAXNET loadrequest and a fan consisting of 3 channels:

52CB

#### 4.1.7 KIND = 6: EPROM

No autoload from external device. Only software in EPROMs is included.

In this case neither the MODULE number nor the ADDRESS fields are used.

#### Example

No autoload, only inclusion of software in EPROMs.

6xxx
------

#### 4.1.8 KIND = 7: X.25/3

Autoload is X.25/3 via COM204, and the software in EPROMs is included.

MODULE number controls the X.25/3 calling algorithm. If the switch is zero, the possible X.121 addresses are tried in a cyclic way. If the switch differs from zero, the X.121 address with index in the internal X.121 address table equal to the switch value is used permanently for repeated calls.

The ADDRESS field has the following interpretation:

8	9	-	15
A / B		LEVEL	

where

A/B 0 indicates COM204 channel A and 1 channel B.

LEVEL defines the interruption level of the load controller.

Conventions for controller start address and interrupt level are identical to KIND 3 and KIND 5.

#### Example

X.25/3 autoload via COM204 at interrupt level 72 (48 hex) channel A using the X.121 address with internal index 2.

7248

4.1.9 KIND = 8: Not used4.1.10 KIND = 9: Not used4.1.11 KIND = 10 (A hex): FPA (Autoload Disabled)

Autoload is from FPA, and the software in EPROMs is included. Drivers controlling external devices may not autoload the RC5000 by activating the watchdog function. Autoload is disabled.

The MODULE number has no significance.

The ADDRESS field specifies the FPA100 REC interruption level.

Example

Autoload from FPA in channel 81 (decimal)

Ax51

4.1.12 KIND = 11 (B hex): WD + MEGA

Autoload is from Winchester Disc. If the autoload fails, a MEGA autoload is initiated. After autoload the software in EPROMs is included.

The MODULE number and ADDRESS fields are only used to specify the MEGA autoload.

Therefore be aware of the following conventions concerning the WD autoload:

1. The Control Unit, CU, of the disc controller on the SCSI bus must be 0.
2. The Logical Unit Number, LUN, of the winchester disc at the disc controller must be 0.
3. The SAI201 data interruption level must be 87 (decimal).

4. The SAI201 control interruption level must be 86 (decimal)

If the WD autoload fails, a MEGA autoload is initiated. Then the interpretation of the **MODULE** number field is:

4-7

F	F	A	N

F - not used

FAN- defines the maximum number of connectors used for autoload. If a connector fails the next connector is tried in a cyclic way. Connectors 0,1,...FAN relative to the first connector are used.

The ADDRESS field specifies the first connector to be tried and ADDRESS must be greater than 1.

Example:

B002

A Winchester Disk autoload is attempted. If it fails a Down Line Load from MEGA connector 2 is attempted. If that fails it is reattempted.

4.1.13 KIND = 12 (C hex): Not used4.1.14 KIND = 13 (D hex): MEGA

Autoload is via Down Line Load from one or more MEGA line connectors.

The interpretation of the MODULE number field is:

4-7

F	F	A	N

F - not used

FAN- defines the maximum number of connectors used for autoload. If a connector fails the next connector is tried in a cyclic way. Connectors 0,1,...FAN relative to the first connector are used.

The ADDRESS field specifies the first connector to be tried and ADDRESS must be greater than 1.

Example:

B103
------

Down Line Load from MEGA connector 3 is attempted. If it fails a Down Line Load from MEGA connector 4 is attempted. If that fails MEGA connector 3 is reattempted etc.

4.1.15 KIND = 14 (E hex): Not used4.1.16 KIND = 15 (F hex): Not used

## 4.2 Autoload Message

boot version x.x

Autoload from mfc level xxH  
user : <FTS User Name> file : boot9330

- FTS User Name is 'cp' appended the contents of the ID Register if the 'module number' switch is zero. '1' to '14' is appended if the 'module number' switch takes the values 1 to E (hexadecimal). If the 'module number' switch is F nothing is appended.

calling : <X.121 address>

calling : cyclic starting at : <X.121 address>

\*\* end print

- Announcement of autoload is no longer performed. The autoload procedures continue.

Autoload from fpa in xxH

Autoload from com204 addr xx.xxxx level xxH channel xxH

Autoload from eprom

Autoload from wd in xxH (D) xxH (C) CU xx lun xx  
file : /autoloadcat/<entryname>

- <entryname> is taken from the Control Microprocessor RAM. If the first character in this name is zero, the default name 'boot3502' appended the CU of the RC5000 is used.

\*\*\* undefined switchkind xxH

.....

- a full stop is printed for every program loaded.

:::

- a colon is printed for every RAM module, which contains programs with a checksum catalog.

:::

- a semicolon is printed for every PROM module, which contains programs with a checksum catalog.

boot \*\*\* exception: xxxx at: xx.xxxx

- consult appendix I for interpretation of the exception code. The autoload is restarted after one minute.

\*\*\* level not installed : xx

- the requested interruption level is not installed. The autoload program is restarted.

\*\*\* install more memory at : xx

- more RAM memory must be installed to hold the autoloaded programs. The autoload is restarted.

\*\*\*\* warning: versionerror at xx.xxxx

- the program identified by the address must be recompiled to be autoloaded. Consult the output from CROSSLINK for identification. The autoload is restarted.

\*\*\*\* warning: sumerror module : xx

- the crc16 data check reports an error in the EPROM module xx. Operation continues.

\*\*\*\* warning: <program> not included

- the basic program <program> should be included in the autoloaded programs or in EPROMs. Operation continues.

\*\*\* sumerror module : xx

- the crc16 data check reports an error in the RAM module xx. The autoload program will start all over again.

last-block xxxxH

new-block xxxxH

- block sequence error. The autoload program will start all over again.

\*\*\* harderror : xx

- a harderror occurred during autoload from Winchester Disc. The autoload program is restarted.

02 SCSI bus phase error in the selection phase.

09 No connection to the SAI201.

0a Timeout of interrupt from SAI201 control channel in the selection phase.

0b Hard error on SAI201. Reset of SAI201 failed.

12 Parity error on the SCSI bus in the selection phase.

- 22 SCSI bus phase error in the command phase.
- 2a Timeout of interrupt from SAI201 control channel in the command phase.
- 32 Parity error on the SCSI bus in the command phase.
- 42 SCSI bus phase error in the data input phase.
- 4a Timeout of interrupt from SAI201 control channel in the data input phase.
- 52 Parity error on the SCSI bus in the data input phase.
- 62 SCSI bus phase error in the data output phase.
- 6a Timeout of interrupt from SAI201 control channel in the data output phase.
- 72 Parity error on the SCSI bus in the data output phase.
- 82 SCSI bus phase error in the status phase.
- 8a Timeout of interrupt from SAI201 control channel in the status phase.
- 92 Parity error on the SCSI bus in the status phase.
- a2 SCSI bus phase error in the message phase.
- aa Timeout of interrupt from SAI201 control channel in the message phase.
- b2 Parity error on the SCSI bus in the message phase.

\*\*\* filelimit : root xxxx

- The catalog with name 'autoloadcat' is not found in the root catalog. The autoload program is restarted.

\*\*\* filelimit : autoloadcat xxxx

- The announced autoloadfile is not found in the catalog 'autoloadcat'. The autoload program is restarted.

\*\*\* filelimit : <autoloadfile> xxxx

- The announced autoloadfile is unintelligible. The autoload program is restarted.

### 4.3 Generating Autoload Files




Fig. 4.1. Autoload File Generation

#### 4.3.1 Generating an FTS Autoloadfile

If the file 'coreimage' has been produced on RC8000 by the 'CROSS-LINK' program, the following call will generate a file with a format for autoload via RCLAN by the FTS protocol. The file 'boot9330' must be placed at the FTS Server under the proper catalog bases or directory. The FTS Username is controlled by the 'module number' switch on RC5000.

```
boot9330 = convertplib coreimage
```

#### 4.3.2 Generating an FPA Autoload

If the file 'coreimage' has been produced on RC8000 by the 'CROSS-LINK' program, the following call will autoload the RC5000 if connected via the process 'main35001':

```
main35001 = crc16 coreimage
```

#### 4.3.3 Generating TES202 Eproms

Consult ref. 2.

## 5. ERROR PROCEDURES

For use in error situations it might be useful to get testoutput from the autoload program 'BOOT' or from the program MONITOR which starts and stops program incarnations.

### 5.1 Monitor Testoutput

The monitor stack address is obtained by the LIST MONITOR command to OPSYS or from the testoutput from BOOT (see 5.2).

If a bit is set in the byte, the testoutput associated the bit will be generated.




Fig. 5.1. Monitor testoutput

## 5.2 Boot Testoutput

The BOOT stack address is  $xx.F850$  where  $xx$  is the base address of the last RAM memory module in the RC5000. If testoutput during autoload from FPA is wanted, you must increase the software time out in the FPA xmt driver in RC8000 from 1 sec. to at least 5 sec.




Fig. 5.2. Boot testoutput

## A. REFERENCES

1. PN: 99000994  
RC3502-2 Real-Time Pascal Reference Manual
2. PN: 99103221  
RC3502 PROM Blasting Program User's Guide
3. RCSL No. 52-AA1177  
CPU212-219 Technical Manual
4. RCSL No. 52-AA1192  
RC3502/2 Reference Manual  
PN: 99001344  
RC5050 Reference Manual Addendum
5. PN: 99000990  
Debugger Listing ROB984

## B. OPSYS COMMANDS

break <process>

check <module base>

create <process> (as <program>)

date <year>.<month>.<day> <hour>.<minute>.<seconds>

excode <integer>

free (<module base>)

from lan  
from fpa

help

in <inchannel>

kill <process>

link <program>

list <process> <nl>

listmailbox <process> (<mailbox>)

load <program> <nl>  
load <filename> <nl> if LAN

log <module base>

lookup <program> <nl>

print <base> <firstdisp> <lastdisp>  
<no\_of\_words\_per\_line> <delta>

priority <integer>

remove <process>

rename <oldname> <newname>

resource (<process>)

restart

run <process> (as <program>)

server <servername>

setswitches <hex>

size <stacksize>

start <process>

stop <process>


trace <process>

unlink <program>

unload <program> <nl>

user <username>

### C. AUTOLOAD SWITCH LAYOUT



## KIND

0	LAN + X.25/3	8	Not used
1	WD	9	Not used
2	FPA (Autoload enabled)	A	FPA (Autoload
disabled)	3	WD + COM204	B
	4	LAN	C
	5	COM204	D
	6	EPROM	E
	7	X.25/3	F
			Not Used

MODULE number

LUN x 8 + CU	if WD
Load request*8+fan	if COM204 or WD+COM204
Cyclic or specific call	if X.25/3
FTS User Name	if LAN or LAN+X.25/3
Fan	if MEGA or WD+MEGA

ADDRESS

SA1201 DATA intrpt level	if WD
Interruption level	if FPA or LAN
Channelx128+intrpt level	if COM204 or WD+COM204
Channelx128+offsetx16+table	if X.25/3 or LAN+X.25/3
First connector	if MEGA or WD+MEGA

## D. SECRET VECTOR




Fig. D.3. )

## E. INSTRUCTION CODES

rec1	01	lt	34	jmprw	68	stvsd	9c	mbset	d0	
rec2	02	gt	35	jmpfc	69	svsb5	9d	mbtes	d1	
rec3	03	le	36	jmpga	6a	stvsd	9e	stvga	d2	
rec4	04	ge	37	jmcft	6b	svsb7	9f	revga	d3	
rec5	05	indh0	38	intrs	6c	mwit	a0	ststc	d4	
rec6	06	indh1	39	index	6d	mcit	a1	restc	d5	
rec7	07	topen	3a	intpa	6e	svsw2	a2	stvla	d6	
rec8	08	tlock	3b	inpdv	6f	rvsw2	a3	revla	d7	
rec9	09	teqad	3c	iorbbc	70	svsw4	a4	stvsf	d8	
rec10	0a	tnill	3d	iorbb	71	rvsw4	a5	revsf	d9	
rec11	0b	mmul	3e	iowbbc	72	svsw6	a6	rvlbns	da	
rec12	0c	madd	3f	iowbb	73	rvsw6	a7	rvlwns	db	
rec13	0d	cwait	40	iorbwc	74	rechw	a8	rvlans	dc	
rec14	0e	msub	41	iorbw	75	revgws	a9	rvldns	dd	
rec15	0f	uadd	42	iowbwc	76	stvlws	aa	crram	de	
csign	10	usub	43	iowbw	77	revlws	ab	cwram	df	
crele	11	add	44	pcals0	78	moveb	ac	mwist	e0	
movebs	11	1	sub	45	pcals1	79	indh02	ad	mcist	e1
escape	12	2	umul	46	pcals	7a	moveg	ae	reaid	e2
cinwq	13	3	udiv	47	pexit	7b	revpw	af	rvsd2	e3
coutwq	14	3	umod	48	lpush	7c	readw	b0	reald	e4
csens	15	mul	49	ipop	7d	crput	b1	rvsd4	e5	
lrele	16	div	4a	lrese	7e	stvgw	b2	reasd	e6	
mtime	17	mod	4b	llock	7f	revgw	b3	uadhw	e6	
mhalt	18	and	4c	mwt	80	reagd	b4	rvsd6	e7	
csell	1a	or	4d	mrecha	81	reaisd	b5	rechd	e8	
cstop	1b	xor	4e	svsb2	82	stvlw	b6	revgds	e9	
cstart	1c	crc16	4f	rvsb2	83	revlw	b7	stvlds	ea	
iocci	1d	neg	50	svsb4	84	revsb	b8	revlds	eb	
cslev	1e	abs	51	rvsb4	85	rvsb1	b9	setst	ec	
cgreg	1f	compl	52	svsb6	86	revsw	ba	indh12	ed	
mw1	20	shc	53	rvsb6	87	rvsb3	bb	stcea	ee	
iowc	21	shc8	54	rec0	88	revsa	bc	revpd	ef	
iors	22	not	55	revgbs	89	rvsb5	bd	rvsb0	f0	
iorw	23	setcr	56	stvlbs	8a	revsd	be	svsb0	f1	
ioww	24	settm	57	revlbs	8b	rvsb7	bf	rvsw0	f2	
ilog	25	3	setatm	58	stnhb	8c	mwst	c0	svsw0	f3
ilogi	26	3	seteq	59	indh01	8d	inth0	c1	rvsa0	f4
ionci	27	setsb	5a	renpb	8e	svsa2	c2	svsa0	f5	
mrest	28	setsp	5b	renhb	8f	rvsa2	c3	rvsd0	f6	
mstst	29	setun	5c	readb	90	svsa4	c4	revld	f7	
iocda	2a	setin	5d	crget	91	rvsa4	c5	stvld	f8	
ioibx	2b	setdi	5e	stvgb	92	svsa6	c6	revgd	f9	
mtrh	2c	setad	5f	revgb	93	rvsa6	c7	stvgd	fa	
iorsc	2d	mwis	60	setre	94	rechws	c8	reaad	fb	
mttrs	2e	mcis	61	resta	95	revgas	c9	reard	fc	
mnoop	2f	jmzeq	62	stvlb	96	stvlas	ca	reaxd	fd	
reasdl	30	jmzne	63	revlb	97	revlas	cb	cexch	fe	
uadhw1	30	jmzlt	64	stvsb	98	revsm	cc			
ult	31	jmzgt	65	svsb1	99	indh11	cd			
eq	32	jmzie	66	stvsb	9a	reagds	ce			
ne	33	jmzge	67	svsb3	9b	realds	cf			

1. RC5040 only = moveb.

2. RC5050 only.

3. RC5040 only.

## F. INSTRUCTION MNEMONICS

abs	51	iowbw	77	pcals	7a	revld	f7	ststc	d4
add	44	iowbw	76	pcals0	78	revlds	eb	stvga	d2
and	4c	iowc	21	pcals1	79	revlw	b7	stvgb	92
cexch	fe	ioww	24	pexit	7b	revlws	ab	stvgd	fa
cgreg	1f	jmcht	6b	reaad	fb	revpd	ef	stvgw	b2
cinwq	13	jmpga	6a	readb	90	revpw	af	stvla	d6
compl	52	jmpfc	69	readw	b0	revsa	bc	stvias	ca
coutwq	14	jmprw	68	reagd	b4	revsb	b8	stvlb	96
crc16	4f	mzeq	62	reagds	ce	revsd	be	stvlbs	8a
crele	11	jmzge	67	reaid	e2	revsf	d9	stvld	f8
crget	91	jmzgt	65	reaisd	b5	revsm	cc	stvlds	ea
crput	b1	jmzle	66	reald	e4	revsw	ba	stvlw	b6
cram	de	jmzlt	64	realds	cf	rvlans	dc	stvlws	aa
csell	1a	jmzne	63	reard	fc	rvlbns	da	stvsaa	9c
csens	15	le	36	reasd	e6	rvldns	dd	stvsb	98
csign	10	llock	7f	reasd1	30	rvlwns	db	stvsd	9e
cslev	1e	lpop	7d	reaxd	fd	rvsa0	f4	stvsf	d8
cstart	1c	lpush	7c	rec0	88	rvsa2	c3	stvsw	9a
cstop	1b	lrele	16	rec1	01	rvsa4	c5	sub	45
cwait	40	lrese	7e	rec10	0a	rvsa6	c7	svsa0	f5
cwram	df	lt	34	rec11	0b	rvsb0	f0	svsa2	c2
div	4a	madd	3f	rec12	0c	rvsb1	b9	svsa4	c4
eq	32	mbset	d0	rec13	0d	rvsb2	83	svsa6	c6
escape	12	mbtes	d1	rec14	0e	rvsb3	bb	svsb0	f1
ge	37	mcis	61	rec15	0f	rvsb4	85	svsb1	99
gt	35	mcist	e1	rec2	02	rvsb5	bd	svsb2	82
index	6d	mcit	a1	rec3	03	rvsb6	87	svsb3	9b
indh0	38	mhalt	18	rec4	04	rvsb7	bf	svsb4	84
indh01	8d	mmul	3e	rec5	05	rvsd0	f6	svsb5	9d
indh02	ad	mnoop	2f	rec6	06	rvsd2	e3	svsb6	86
indh1	39	mod	4b	rec7	07	rvsd4	e5	svsb7	9f
indh11	cd	moveb	ac	rec8	08	rvsd6	e7	svsw0	f3
indh12	ed	movebs	11	rec9	09	rvsw0	f2	svsw2	a2
inpdy	6f	moveg	ae	rechd	e8	rvsw2	a3	svsw4	a4
inth0	c1	mrecha	81	rechhw	a8	rvsw4	a5	svsw6	a6
intpa	6e	mrest	28	rechws	c8	rvsw6	a7	teqad	3c
intrs	6c	mstst	29	renhb	8f	setad	5f	tlock	3b
iocci	1d	msub	41	renpb	8e	setatm	58	tnill	3d
iocda	2a	mtime	17	resta	95	setcr	56	topen	3a
ilogi	26	mtrh	2c	restc	d5	setdi	5e	uadd	42
ilogo	25	mtrs	2e	revga	d3	seteq	59	uadhw	e6
ioibx	2b	mul	49	revgas	c9	setin	5d	uadhw1	30
ionci	27	mw1	20	revgb	93	setre	94	udiv	47
iorbb	71	mwis	60	revgbs	89	setsb	5a	ult	31
iorbbc	70	mwist	e0	revgd	f9	setsp	5b	umod	48
iorbw	75	mwit	a0	revgds	e9	setst	ec	umul	46
iorbw	74	mwst	c0	revgw	b3	settm	57	usub	43
iors	22	mwt	80	revgws	a9	setun	5c	xor	4e
iorsc	2d	ne	33	revla	d7	shc	53		
iorw	23	neg	50	revlas	cb	shc8	54		
iowbb	73	not	55	revlb	97	stcea	ee		
iowbbc	72	or	4d	revlbs	8b	stnhb	8c		

1. RC5040 only = moveb.

2. RC5050 only.

3. RC5040 only.

## G. PROCESS DESCRIPTOR LAYOUT

Dec	Hex
0	0 68
2	2 64
4	4 6C
6	6 6E
8	8 70
10	A 72
2	C 74
4	E 76
6	10 78
8	2
20	4
2	6
4	8
6	A
8	C
30	E
2	20
4	2
6	4
8	6
40	8
2	A
4	C
6	E
8	30
50	2
2	4
4	6
6	8
8	A
60	C
2	E
4	40
6	2
8	4
70	6
2	8
4	A
6	C
8	E

## H. MESSAGE HEADER LAYOUT

Dec	Hex
0	0
2	2
4	4
6	6
8	8
10	A
12	C
14	E
16	10
18	12
20	14
22	16
24	18
26	1A

## I. HEAP LAYOUT

heap\_head:

Dec	Hex
0	0
2	2
4	4
6	6
8	8

heap\_root:

Dec	Hex
0	0
2	2
4	4
6	6
8	8
10	A
12	C
14	E
16	.
18	10

heap\_ret\_chain

name\_entry:

Dec	Hex
0	0
2	2
4	4
6	6
8	8
10	A
12	C
14	E
16	10

## J. EXCEPTION CODES

<u>Code (Hex)</u>	<u>Meaning</u>
1	- parity error
2	- registerstack error
3	- undefined opcode
4	- odd number of bytes
5	- stack overflow
6	- pointer = nil
7	- signal: reference = nil - push: first param = nil - pop: second param = nil - lock: reference = nil - reference = nil
8	- wait: reference $\neq$ nil - pop: first param $\neq$ nil
9	- push: param locked - pop: second param locked - signal: reference locked - reference locked
A	- lock overflow
B	- arithmetic overflow
C	- index out of bounds - subrange out of bounds
D	- illegal zonestate
E	- field overflow
F	- move wraparound
10	- push: identical arguments
11	- push: first param not empty
12	- lock: size error - size too small
13	- top $\leq$ offset
14	- lock: not data message - not data message
15	- not channel message
16	- word block i/o: odd number of bytes
17	- block i/o at level 0
18	- setcr: first limit negative
19	- setad: truncation error
1A	- no resources
1B	- file does not exist
1C	- position outside file
1D	- wrong answer
1E	- setpriority: illegal priority
1F	- pool: no core
20	- process = nil
21	- arithmetic overflow
22	- double conversion exception
23	- system error
24	- illegal switch in case construction

<u>Code (Hex)</u>	<u>Meaning</u>
25	- upper limit in call of succ
26	- lower limit in call of pred
27	- with: size error
28	- lockdata: top < computed top
29	- local reference variable not nil at routine exit
2A	- local process variable not nil at routine exit
2B-2E	- system error
2F	- break by father

## K. RC5040 REGISTER LAYOUT

Description of the working registers: (for a more detailed description, refer to the reference manual, ref. 4)

### W: Index:

00	000-007	regset 0
01	008-00F	regset 1
-	-	
79	3C8-3CF	regset 121
7A	3D0-3D7	work regset for multiplications
7B	3D8-3DF	masks0
7C	3E0-3E7	masks1
7D	3E8-3EF	breakpointset
7E	3F0-3F7	monitorset
7F	3F8-3FF	com8085

### regset 0 thru regset 121:

1st reg.	ps
2nd reg.	sb
3rd reg.	gf
4th reg.	lf
5th reg.	lu
6th reg.	lm
7th reg.	ib
8th reg.	ic

### breakpointset:

1st reg.	breakpointmode (8000 means breakpoint active)
2nd reg.	breakpointbase
3rd reg.	breakpointdisp
4th reg.	unused
5th reg.	unused
6th reg.	unused
7th reg.	unused
8th reg.	unused

### monitorset:

1st reg.	memregsetbase
2nd reg.	memregsetdisp
3rd reg.	waitqueuelast
4th reg.	waitqueuefirst
5th reg.	monitorlevel
6th reg.	unused
7th reg.	unused
8th reg.	unused

com8085:

1st reg.	parityerrorregset
2nd reg.	fifo0, fifo1
3rd reg.	fifo2, fifo3
4th reg.	fifo4, fifo5
5th reg.	cow (value, disp)
6th reg.	message.errorcode
7th reg.	parityerrorbase
8th reg.	parityerrordisp

## L. RC5050 REGISTER LAYOUT

Description of the registers: (for a more detailed description, refer to the reference manual, ref. 4)

<u>W:</u>	<u>Index:</u>	
00	000-007	regset 0
01	008-00F	regset 1
-	-	
79	3C8-3CF	regset 121
7A	3D0-3D7	not used for compatibility reasons
-	-	
7E	3F0-3F7	not used for compatibility reasons
7F	3F8-3FF	com8085, for compatibility reasons
80	400-407	regset 128
-	-	
1FF	FF8-FFF	regset 511
200	1000-1007	regset 0 extra registers
-	-	
3FF	1FF8-1FFF	regset 511 extra register

### regset 0 thru regset 121 and 128 thru 511:

1st reg.	ps	Process Status Word
2nd reg.	sb	Stack Base
3rd reg.	gf	Global Frame
4th reg.	lf	Local Frame
5th reg.	lu	Last Used
6th reg.	lm	stack LiMit
7th reg.	ib	Instruction Base
8th reg.	ic	Instruction Counter

### regset 512 thru regset 1023:

1st reg.	th	cpu Timer High
2nd reg.	tl	cpu Timer Low
3rd reg.	ch	register CHain
4th reg.	rb	Reference Base
5th reg.	rd	Reference Displacement
6th reg.	hb	Head Base
7th reg.	hd	Head Displacement
8th reg.	cw	Control Word

## M. CONTROL MICRO RAM LAYOUT

00 RTC level:

Real Time Clock interruption level.

01 TTO level:

Console output interruption level.

02 TTI level:

Console input interruption level

04-03 Timer:

Low	High
-----	------

3        4

RC5000 is interrupted on level 'RTC level' every  $(256 \times \text{High} + \text{Low}) \times 2.5 \text{ mS}$ .

06-05 Watchdog:

Low	High
-----	------

5        6

Count down is performed every 2.5 mS. RC5000 is reset, when (if) watchdog.high is decremented from 1 to 0.

07 TTI input:

When an input character from the console is ready, the character is delivered here and RC5000 interrupted on level 'TTI level'.

08 TTO output:

RC5000 delivers an output character for the console here, and is interrupted on level 'TTO output', when the character is printed.

09

Version:

Model	Micro
-------	-------

9

Model is 1 for RC3502-1, 2 for RC5040 (RC3502-2) and 5 for RC5050. Micro is the micro program version number.

0A-0B

Switches:

10

11

0-3	4-7	8-11	12-15
A		B	

Contains the current value of the autoload switches. For RC5040 this is the four switches marked BUS on the Processor Front Panel. For RC5050 this is a displayable NVM parameter.

0C-1B

Interruption Levels:

Describes the 128 interruption level configuration. Level i exists if bit no i is set in the Interruption Level bitmask. Levels 0-7 are described in byte 12, Levels 8-15 in byte 13, etc.

1C-21

RAM Modules:

Is a bitmask, describing the RAM module configuration. A module is 64Kb. A module exists, if the corresponding bit is set in the bitmap.

Modules A0, A2, ..., AE are described in byte 28, modules B0, B2, ..., BE in byte 29, etc.

22-27

EPROM Modules:

Is a bitmask, describing the EPROM module configuration. A module is at most 64Kb. A module exists, if the corresponding bit is set in the bitmap. Modules A0, A2, ..., AE are described in byte 34, modules B0, B2, ..., BE in byte 35, etc.

28-29 ID register:

40	41
0-7	8-15
28	29

The contents of the F505 (IDR202) register or for RC5050 the NVM value may be examined here.

2A COM204 mask:

Controls the COM204 channels during down line load. If bit i is set the channel is skipped, otherwise a load request frame is transmitted on the channel.

2B Result:

If a down line load is successful, this byte contains the resultant relative channel plus 8, where  $0 \leq \text{channel} \leq 7$ .

If autoload is from Winchester Disc, the CU address of the RC5000 on the SCSI bus is passed here.

2C-33 Entryname:

Controls autoload from Winchester Disc.

If the first character in Entryname is zero, the default name 'boot3502x' is used, where x is the CU address of the RC5000 on the SCSI bus.

Otherwise Entryname is used for lookup in the catalog 'Autoload-cat'.

34-35 Cswitches:

Contains a copy of the field switches.

The contents of switches is transferred to Cswitches, whenever the autoloadprogram is started, and the first byte of Cswitches equals zero. The contents of Cswitches controls the autoload program.

36 Printcount:

Controls the number of times autoload announcements is performed.

## N. RC5050 NON-VOLATILE MEMORY LAYOUT.

NVM	Y-mem	Note	Description
00 .. 01	0a..0b		Load switches.
	02	-	Mode Switch w.o. baudrate.
	03	-	Baud Rate.
04 .. 05	28..29		ID-register, this ID register value will be used only in the absence of a hardware ID register such as F505 (IDR202).
	06	-	Enter Degraded Mode at restart, internal SP usage only.
	07	-	System mode, normal value zero. +80 Generate CWRAM testoutput. +40 Do not Run after startup and CW command. +20 Disable Watch Dog restart. +01 Disable compatible mode.
	08	-	3 Gate Array SMEM high byte.
	09	-	3 Gate Array SMEM low byte.
	0a	-	4 Gate Array mode.
	0b	-	5 First DMA module.
	0c	-	1 Latest Error Type.
	0d	-	1 Latest Error No.
0e .. 0f	-	1	Latest Error Address.
10 .. 11	-	1	Latest Error Data.
12 .. 13	-	1	Latest Error Module.
	14	-	2 Oldest Error Type.
	15	-	2 Oldest Error No.
16 .. 17	-	2	Oldest Error Address.
18 .. 19	-	2	Oldest Error Data.
1a .. 1b	-	2	Oldest Error Module.
1c .. 1d	-		Flash 0 burn count.
1e .. 1f	-		Flash 1 burn count.
20 .. 2f	-	6	Extended Memory Inclusion Table
32 .. 61	-		Reserved.
62 .. 63	-		CheckSum for addr 0..61.
64 ..127	-		FCO's followed by 0's, to be maintained by service organization.
128 ..255	-		SW EEPROM area, to be maintained by system software.

### Notes:

1. These locations are set to zero when the Service Processor starts or restarts. Whenever a testprogram or hardware error occurs these locations are set accordingly, see section 2.3.1.3 .

2. Whenever a testprogram or hardware error occurs and these locations are zero they are set to the old value of the locations marked 1.
3. The Gate Array control register SMEM controls the usage of streaming memory. After microprogram load the SP transfers the contents of these NVM bytes to the Gate Array SMEM register. The default value of these bytes are 00 00.
4. The Gate Array mode register controls various aspects of the Gate Array functions. After microprogram load the SP transfers the contents of this NVM bytes to the Gate Array mode register. The default value of this byte is 28.
5. This location indicates the address of the first module to be addressed by DMA-based controllers. The value is intended for use by the allocator. The default value of this byte is 80.
6. This 16 bytes constitute a boolean array of all possible memory modules. A value of true indicates that the corresponding memory module will be tested for presense and type during CPU initiation. A value of false will prohibit any testing of the corresponding module, i.e. the module will unconditionally be excluded. The default value, which excludes dual-port controllers and extended memory is: 00 00 00 00 00 00 00 00 00 00 ff ff ff ff ff ff.

## O. RC5050 WORK MEMORY LAYOUT

The RC5050 CPU is equipped with a fast work memory consisting of 16 x 128 16 bit words. 128 of these are used as interrupt map while the rest is used for various purposes.

Wm	Index	Ws	Description
0	00..7e	-	Interrupt Map,, i.e. Wm0( nxs ) == NextCurReg
0	7f	0	Interrupt Map,, i.e. Wm0( 7f ) == NextCurReg
1	00	-	ParityErrorCode
1	01..7e	-	n/u
1	7f	1	Service Proc Command 1
2	00	-	ParityBase
2	01..7e	-	n/u
2	7f	2	Service Proc Command 2
3	00	-	i.e. ParityDisp
3	01..7e	-	n/u
3	7f	3	Current GA mode
4	00	-	TestMode Register: 0001 Repeat/Resume Instruction does not count down stepcount 0002 Use TestMode exception action 8000 Generate itc at stepmode entry
4	01	-	Esc 3 instruction answer.
4	02..7e	-	n/u
4	7f	4	BreakPointMode
5	00..7e	-	n/u
5	7f	5	BreakPointBase
6	00..7e	-	n/u
6	7f	6	BreakPointDisp
7	00..7e	-	n/u
7	7f	7	SpMsg
8	00..7e	-	n/u
8	7f	8	SpMsg1
9	00..7e	-	n/u
9	7f	9	SpMsg2
10	00..7e	-	n/u
10	7f	10	Current Level
11	00..7e	-	n/u
11	7f	11	StopMode: Current RegSet All of Wm12 survives watchdog restart.
12	00..07	-	Used by SP: ROM locations
12	08..0f	-	Used by SP: RAM locations
12	10..7e	-	Available for SW usage.
12	7f	12	PS_waitbits
13	00..0f	-	Bits (\$0001..\$8000)
13	10..7e	-	n/u
13	7f	13	Local Work Var
14	00..7e	-	Move / Block Buffer
14	7f	14	Local Work Var
15	00..0f	-	Masks (\$0001..\$ffff)
15	10..7e	-	n/u
15	7f	15	Local Work Var

## P. SERVICE PROCESSOR INITIATOR

The RC5050 Service Processor Initiator is activated after power-up and after a C R or C I command. Normally the Service Processor, which is located in the builtin EPROM in the Service Processor, will execute initial tests and then activate the main Service Processor program located in EEPROM number 0.

In below cases, however, the Service Processor Initiator will not activate the main SP but instead activate a small command interpreter:

1. When a checksum error is detected in EEPROM 0 or 1.
2. When the SP Initiator is activated by the C I command.
3. When one of the front panel switches are pressed when the SP Initiator starts. Note that this will select a console baud rate as well.

The activated command interpreter uses "-\*" as prompt and accepts the following commands:

**E** Load EEPROM.

This command activates a EEPROM load sequence. First the EEPROM number is quiered, then an optional text describind the load is quiered, and finally the load image in Intel MCS-8 format is read.

For EEPROM 0 (Service Processor program) record types 0 and 1 are accepted only.

For EEPROM 1 (Microprogram) record types 1, 80, 81, 82, and 83 are accepted.

**F** Force full Service processor function.

This command will cause an unconditional transfer to the Service Processor main program in EEPROM 0.

**I N** Inspect NVM.

Inspect Non-Volatile Memory. This command will display and optionally change a single byte location in the NVM.

**I S** Inspect SP-RAM.

This command will display 16 bytes of SP RAM memory. Update is not possible.

N      Clear NVM memory.

All of the NVM except speed and mode are set to zero.

?      Display available SP Initiator commands.

## Q. INSTALLATION STANDARDS AND RECOMMENDATIONS

This is a recommendation concerning installation of hardware modules in the RC5000. The guidelines concern interruption levels, input/output priorities, module number selections, DMA priority.

### Q.1 Input/Output Modules

The priorities and interruption levels in the following table should be followed according to input/output channels and priority. The first module in a group should be the lowest channel number.

### Q.2 Memory Modules

Memory modules are strapped to cover one or more module addresses in the memory address space. They must not overlap. There must exist at least one RAM memory module with address C0 and at least one PROM memory module containing the BOOT program in module address E0. If the autoloaded programs occupy more than one module, there must be RAM memory modules with address C2, C4, etc. MEM204 RAM memory modules can be placed in the address space C0-DE. MEM205, MEM206, MEM207, and MEM209 RAM memory modules can use 80-FE. A special action can be taken on MEM204 to disable the PROM area, which is always equal to RAM module address + 20 (hex). The PROM memory module address on MEM205 and MEM206 may be set completely free in the whole address space, or may be disabled. The PROM areas E0 or E2 may be disabled on MEM207 and MEM209.

TES201 and TES202 can be strapped in the address space C0-FE. (Note, that C0 must always be used as RAM memory).

### Q.3 Controllers

COM204 occupies 2 positions. The one position connects to the Back Plane Bus. In the second position a CBL714 must be placed.

By convention the first COM204 must be strapped to dual port memory module address 90 (hex) and interruption level 72 (decimal). See section 4.1.4.

IMS208 through IMS212 occupies one position.

By convention the first IMS2XX must be strapped to dual port memory module address 80 (hex) and interruption level 8. The succeeding IMS2XX controllers must be set to 80.4000 and level 9, i.e. memory module addresses increase by 4000 (hex) and interruption levels by 1.

Q.4 Summary

			2.	1.	2.	1.	2.	1.
C P U 2 1 5	C P U 2 1 6	C P U 2 1 7	I O M 2 0 2	I O M 2 0 2	C O M 2 0 4	C O M 2 0 4	V C O 2 0 1	V C O 2 0 1

-&gt;

2.	1.	2.	1.	2.	1.	2.	1.	2.	1.
C O M 2 0 5	C O M 2 0 5	M F C 2 0 X	M F C 2 0 X	I M S 2 X X	I M S 2 X X	M E M 2 0 X	M E M 2 0 X	T E S 2 0 X	T E S 2 0 X

-&gt;

	2.	1.	2.	1.	2.	1.	2.	1.
C P U 2 2 2 1	I O M 2 0 3	I O M 2 0 3	C O M 2 0 4	C O M 2 0 4	V C O 2 0 1	V C O 2 0 1	C O M 2 0 6	C O M 2 0 6

-&gt;

-&gt;

2.	1.	2.	1.	2.	1.	2.	1.	2.	1.
C O M 2 0 5	C O M 2 0 5	M F C 2 0 X	M F C 2 0 X	I M S 2 X X	I M S 2 X X	M E M 2 0 X	M E M 2 0 X	T E S 2 0 X	T E S 2 0 X

The following three points should be observed:

1. The interruption level priority chain starts at the CPU and must not be broken by empty positions until the last module, which uses interruption level priority. At the end of the chain, there must be an "interrupt chain end plug" (CBL735).
2. The DMA priority chain starts at the CPU and must not be broken by empty positions until the last module, which uses DMA priority.
3. The module, which is closest to the CPU, has highest priority, both according to interrupt level and DMA.

Module name	Interrupt level (Hex)	Dual Port Memory Base (Hex)	No. of interrupt levels (Decimal)	No. x salesnumber
CPU	Lowest priority 00-04	-	5	
SPARE	05-07	-	3	
IMS2XX	08-0F	80-8E	8	8 x RC5330
MFC20X	10-1F	-	16	16 x RC5320
COM206	20-2F	-	16	16 x RC5371
COM205	20-2F	-	16	16 x RC5370
VCO201	30-37	-	8	8 x RC3583
COM204	48-4F	90-96	8	8 x RC5340
IOM202	50-6D	-	32	4 x RC5310
MCC240	6E-6F	-	2	1 x RC5010
SPARE	78-7E	-	4	
	Highest priority			

## R. ASCII CHARACTER SET

ASCII	dec	hex									
NUL	00	00	space	32	20	@	64	40	'	96	60
SOH	01	01	!	33	21	A	65	41	a	97	61
STX	02	02	"	34	22	B	66	42	b	98	62
ETX	03	03	\$	35	23	C	67	43	c	99	63
EOT	04	04	\$	36	24	D	68	44	d	100	64
ENQ	05	05	%	37	25	E	69	45	e	101	65
ACK	06	06	&	38	26	F	70	46	f	102	66
BEL	07	07	'	39	27	G	71	47	g	103	67
BS	08	08	(	40	28	H	72	48	h	104	68
HT	09	09	)	41	29	I	73	49	i	105	69
LF	10	0A	*	42	2A	J	74	4A	j	106	6A
VT	11	0B	+	43	2B	K	75	4B	k	107	6B
FF	12	0C	,	44	2C	L	76	4C	l	108	6C
CR	13	0D	-	45	2D	M	77	4D	m	109	6D
SO	14	0E	.	46	2E	N	78	4E	n	110	6E
SI	15	0F	/	47	2F	O	79	4F	o	111	6F
DLE	16	10	0	48	30	P	80	50	p	112	70
DC1	17	11	1	49	31	Q	81	51	q	113	71
DC2	18	12	2	50	32	R	82	52	r	114	72
DC3	19	13	3	51	33	S	83	53	s	115	73
DC4	20	14	4	52	34	T	84	54	t	116	74
NAK	21	15	5	53	35	U	85	55	u	117	75
SYN	22	16	6	54	36	V	86	56	v	118	76
ETB	23	17	7	55	37	W	87	57	w	119	77
CAN	24	18	8	56	38	X	88	58	x	120	78
EM	25	19	9	57	39	Y	89	59	y	121	79
SUB	26	1A	:	58	3A	Z	90	5A	z	122	7A
ESC	27	1B	;	59	3B	Æ	91	5B	æ	123	7B
FS	28	1C	<	60	3C	Ø	92	5C	ø	124	7C
GS	29	1D	=	61	3D	Å	93	5D	å	125	7D
RS	30	1E	>	62	3E	Ü	94	5E	ü	126	7E
US	31	1F	?	63	3F	-	95	5F	DEL	127	7F

## S. INDICES

### S.1 Survey of Figures

Fig. 2.1. OCP for Rack with up to Three RC5000	4
Fig. 2.2. RC5040 Processor Front Panel	5
Fig. 2.3. RC5050 Processor Front Panel	11
Fig. 4.1. Autoload File Generation	60
Fig. 5.1. Monitor testoutput	62
Fig. 5.2. Boot testoutput	63
Fig. D.3.	68

### S.2 Catchword Index

8085 communication test	7
8085 EPROM sum test	8

#### A

ADDRESS	45
ASCII character set	90
AUTOLOAD	4,45
autoload errors	57
autoload file	60
autoload messages	57
autoload PROM release	3
autoload PROM version	3
autoload switch	67
autoload switch format	45
Autoload Switches	13

#### B

baud rate	6
baud rate, console	23
baudrate	13
BOOT testoutput	63
boot9330	61
BREAK	27
bus RC5040 switches	6
BUS switches	45

#### C

CHECK	27
COM204 autoload	48,51
COM204 mask	81
command parameters	44
commands, control	41
commands, display	38
communication test, 8085	7
console baud rate	23

Console baudrate	13
Console mode	14
console operation	26
control commands	41
control micro RAM	79
convertplib	61
coreimage	61
crc16	61
CREATE	28
CROSSLINK	61
Cswitches	81
current name	26
current process	26

**D**

D-mode	37
DATE	28
DEBUG firmware release	3
DEBUG firmware version	3
debug mode	6,37
DI, disable interrupt	7
disable interrupt DI	7
display commands	38
Display Data Type	13
Display Mode	12
Display, Hexadecimal	12

**E**

entryname	81
EPROM modules	80
EPROM sum test, 8085	8
EPROMS, RES202	61
ERR00	7
ERR02	8
ERR03	8
ERR04	8
ERR05	9
ERR06	9
ERR07	9
ERR08	9
ERR09	10
ERR0A	10
ERR0B	8
Error Code, Hard	14
error explanation	7
error number, test	7
error procedures	62
errorlog	30
errors, autoload	57
errors, LOADER	36
errors, OPSYS	34
exception codes	74

EXCODE	28
F	
file, autoload	60
FPA autoload	47,54,61
FREE	28
FROM	28
front panel, RC5040 processor	5
Front Panel, RC5050 Processor	11
FTS loadfile	61
FTS-server	46
G	
GETSWITCHES	28
guidelines, installation	87
H	
Hard Error Code	14
heap	73
HELP	29
Hexadecimal Display	12
I	
ID register	81
ID-register	13
IN	29
indicator values	7
indicators	4,7
installation guidelines	87
instruction mnemonics	70
instruction step	41
internal interrupt test	9
interrupt map test	9
interrupt test	8
interruption levels	80
K	
KILL	29
KIND	45
KIND = 0	46
KIND = 1	47
KIND = 10	54
KIND = 11	54
KIND = 13	56
KIND = 2	47
KIND = 3	48
KIND = 4	50
KIND = 5	51
KIND = 6	53

KIND = 7	53
L	
LAN autoload	46,50,61
left parity error LP	7
LINK	29
LINKER catalog	30
LIST	29
LISTMAILBOX	30
LOAD	30
LOADER errors	36
LOADER messages	36
LOCK	4
LOG	30
LOOKUP	30
LP, left parity error	7
M	
MEGA autoload	54,56
memory address test	8
memory data test	9
message header	72
messages, autoload	57
messages, LOADER	36
messages, OPSYS	34
micro RAM	79
MicroProgram revision	15
Mode	14
MODULE number	45
MONITOR testoutput	62
N	
Non-Volatile Memory Layout	82
NVM, see Non-Volatile Memory	
O	
OCP, operators control panel	4
OFF	4
ON	4
OP, operating	7
OPERATING	4
operating OP	7
operating system release	3
operating system version	3
operation, console	26
operator process	26
operators control panel OCP	4
OPSYS commands	27,65
OPSYS errors	34
OPSYS messages	34

OVER TEMPERATURE	24
OVER VOLTAGE	24
<b>P</b>	
PHASE NO	24
POW207, power supply	24
POW240/241 Power Supply	24
POWER	24
POWER FAILURE	24
POWER OK	4,24
power on/off	4
power restart	45
power supply POW207	24
Power Supply, POW240/241	24
prefetch test	10
PRINT	31
printcount	81
PRIORITY	32
process descriptor	71
<b>R</b>	
RAM modules	80
RC5040 mode switch	6
RC5040 processor front panel	5
RC5040 register	76
RC5040 Switches	6
RC5040 switches, bus	6
RC5050 Processor Front Panel	11
RC5050 register	78
real time clock	79
register stack test	10
register, RC5040	76
register, RC5050	78
release, autoload PROM	3
release, DEBUG firmware	3
release, operating system	3
REMOVE	32
RENAME	32
RES202 EPROMS	61
RESET	24,25
RESOURCE	32
RESTART	33
restart, power	45
restart, watchdog	45
result	81
revision, MicroProgram	15
revision, Service Processor	15
right parity error RP	7
RP, right parity error	7
RTC level	79
RUN	33

## S

schedule test	9
secret vector	68
selftest	41
SERVER	33
Service Processor revision	15
SETSWITCHES	33
SIZE	33
SLAVE NO	24
START	33
STOP	34
switch format, autoload	45
switch, autoload	67
switch, RC5040 mode	6
switches	4,80

## T

T-mode	26
terminal mode	6,26
test error number	7
TEST MODE	4,14
test mode TM	7
test no	42,43
test program	6
testoutput, BOOT	63
testoutput, MONITOR	62
timer	79
TM, test mode	7
TRACE	34
TTI input	79
TTI level	79
TTO level	79
TTO output	79

## U

UNIT NO	25
UNLINK	34
UNLOAD	34
USER	34

## V

version	80
version, autoload PROM	3
version, DEBUG firmware	3
version, operating system	3

## W

watchdog	79
watchdog restart	45
WD autoload	47,48,54,56
working register address test	8
working register data test	8

## X

X.25/3 autoload	46,53
-----------------	-------

