Title:

RC3600 DATA ENTRY RELEASE 2

USER'S GUIDE FOR SUPERVISOR PROGRAM SURVEY



RCSL No: 43-GL5993 Edition: JANUARY 1978 Author: Flemming Havmøller

RC SYSTEM LIBRARY: FALKONERALLE 1 DK-2000 COPENHAGEN F

Keywords:

MUS, DOMUS, DATA ENTRY, SUPERVISOR PROGRAM, SURVEY

Abstract:

This manual descripes how to use the supervisor program SURVEY.

The program prints information about jobs, batches, formats, subprograms, tables or disctables in the Data Entry System.

Copyright © A/S Regnecentralen, 1976 Printed by A/S Regnecentralen, Copenhagen





CONTENTS

1

1. INTRODUCTION

2. PROGRAM: SURVEY - make survey on jobs, batches, formats, subprograms, tables. 2

INTRODUCTION.

1.

This manual descripes how to use the supervisor program SURVEY.

For further description of the program see the following pages, page 2, 3 and 4.

These 3 pages (page 101, 102 and 103) can be inserted in the:

RC3600 DATA ENTRY RELEASE 2 USER'S GUIDE PART 2 RCSL: 43-GL4796 EDITION: JUNE 1977

instead of the already exsisting pages.

The reason for this manual is some changes in the program as described below.

Batch statusword is extended with one word, this word (word 2) will now be printed.

Page 101

PROGRAM: SURVEY - make survey on jobs, batches, formats, subprograms, tables. 2. 2. KEYING: 1. Key: SURVEY 2. If survey of a single batch is wanted Key: BATCH If survey of all or a single job is wanted Key: JOB If survey of all formats is wanted Key: FORM If survey of all subprograms is wanted Key: SUBPROGRAM If survey of all core-tables is wanted Key: TABLE If survey of all disc-tables is wanted Kev: DISCTABLE 3. If survey of a BATCH or a single job is wanted Key: name of batch or job 4. If all informations is wanted in a survey of a single job Key: MAXI 5. Press the ENTER key. DESCRIPTION: SURVEY BATCH command The batch is described by the following: - JOBNAME - FORMAT - BATCH STATUS WORD 1 See section 5.3. in part 1 of - BATCH STATUS WORD 2 this Users Guide. NUMBER OF BLOCKS Number of disc sectors in the discfile containing data. - NUMBER OF RECORDS - NUMBER OF REKEYED RECORDS

- NUMBER OF INVALID RECORDS
- an indication of whether new records can be keyed to the batch in KEY-mode:

KEY-mode may be entered, the batch may be extended.

FINALLY TERMINATED: KEY-mode can not be entered as the END-statement was executed in connection with the last record.

SURVEY JOB command

EXTENSIBLE:

A survey of <u>all jobs</u> consists of a printout listing all jobnames in the system. A survey of <u>a single job</u> can be created in two ways: either as a compressed survey of all batches in the job (default) or as a survey containing all information (by using the parameter MAXI) about the batches using the same format as described above.

<u>A compressed survey</u> describes each batch by a line containing the following information:

- batchname
- formatname
- batch status

The text: 'batchname IN USE: batchstatus' is printed instead of a batchsurvey when a batch is being used by another keystation. The text: 'batchname DOES NOT EXIST' is printed when the name of a batch exists in the job but not as a discfile due to a fatal system error.

SURVEY FORM command

Each format is described by the following:

- FORMAT NAME
- FORMAT LENGTH The number of characters including subprograms IN CHARACTERS and core tables occupied by the format when brought into memory (f).
- REGISTER LENGTH The total number of characters used by the for-IN CHARACTERS mat for registers. (rg)
- RECORD LENGTH Length of the largest record which can be pro-IN CHARACTERS duced when keying with the format. (rc).
- IMAGE LENGTH The number of characters occupied by the image IN CHARACTERS when brought into core memory. (i).

The information may be used to calculate the corememory requirements of the format:

f + i + n • (rg + rc)

n = number of keystations using the format simultanously.

If no terminals use fill-in-the-blanks keying 'i' may be committed from the formula.

An extra record area(rc) must be added for each terminal which is using the format for rekeying or editing.

Page 4

SURVEY SUBPR, TABLE, DISCTABLE command

Makes a printout of the names and length in characters of all subprograms, core-tables, or disc-tables, respectively.

- SURVEY BATCH B0001 EXAMPLES: 1)
 - 2) SURVEY JOB
 - 3) SURVEY JOB J0005
 - 4) SURVEY JOB J0005 MAXI
 - 5) SURVEY FORM
 - 6) SURVEY SUBPROGRAM
 - 7) SURVEY TABLE
 - SURVEY DISCTABLE 8)

RECEIPTS:

NOT NAME

NOT BATCH

NOT JOB

BATCH IN USE JOB IN USE

PRINTOUT ERROR <Code>

ing batch. The jobname specifies a discfile which is not a job. The batch is used by another keystation. The job is used by another keystation. DISC ERROR <Code> Consult appendix 2

A specified job or batchname is not the

The specified batchname is not an exist-

Consult section 8.2.

name of a discfile.

