

Title:

Discette Formatting System RC8000/RC3600
Operators Guide.

 **REGNECENTRALEN**

RC SYSTEM LIBRARY: FALKONERALLE 1 DK-2000 COPENHAGEN F

RCSL No: 43-GL7940

Edition: 78.10.23

Author: Dan Andersen

Keywords:

RC3600, RC8000, DISCETTES, FORMATING, SYSTEM DESCRIPTION.

Abstract:

This manual describes how to load the Discette Formatting System, and how to prepare the start up of the system.

Copyright A/S Regnecentralen, 1978
Printed by A/S Regnecentralen, Copenhagen

Users of this manual are cautioned that the specifications contained herein are subject to change by RC at any time without prior notice. RC is not responsible for typographical or arithmetic errors which may appear in this manual and shall not be responsible for any damages caused by reliance on any of the materials presented.

1.	INTRODUCTION.....	1
2.	OPERATIONAL PROCEDURES.....	2

1. INTRODUCTION

The Discette formatting System is a disc with the basic software and a Discette Formatting Program.

The system can be used on any RC3600 or equivalent CPU for physical formatting of discs which are single or double sided.

The discs can be formatted with 128, 256 or 512 bytes sector-length and may be formatted screwed for increased speed during read and write of data.

- 8) The program responds with the text RUNNING, and starts execution.
- 9) Follow the instructions in the manual given above, which also has a description of the error messages possible during run of the formatting program.
- 10) When formatting is ended remember to reset the switches on the Front End Computer and insert the unit 0 plug or set the DSA switch to AUTOLOAD ENABLED.