

| Stift<br>Plugs | 1             | 2             | 3            | 4            | 5           | 6          | 7               | 8          | 9          | 10                     |
|----------------|---------------|---------------|--------------|--------------|-------------|------------|-----------------|------------|------------|------------------------|
| P6U            | AR9<br>F      | AR9<br>KB     | AR8<br>F     | AR8<br>KB    | AR7<br>F    | AR7<br>KB  | AR6<br>F        | AR6<br>KB  | AR5<br>F   | AR5<br>KB              |
| P7UA           | KB<br>AR9     | KB<br>AR8     | KB<br>AR7    | KB<br>AR6    | KB<br>AR5   | KB<br>AR4  | KB<br>AR3       | KB<br>AR2  | KB<br>AR1  | KB<br>AR0              |
| P7UB           | -200V         |               |              |              |             | 0V         |                 | +100V      |            | +150V                  |
| P8U            | AR4<br>F      | AR4<br>KB     | AR3<br>F     | AR3<br>KB    | AR2<br>F    | AR2<br>KB  | AR1<br>F        | AR1<br>KB  | AR0<br>F   | AR0<br>KB              |
| P3VA           | ARok<br>AR-1  |               |              |              |             | AIV        |                 |            | AN         |                        |
| P3VB           | ADD00<br>AR00 | ARDind<br>AR0 | AR0<br>Add00 | MDO<br>Add00 | CO<br>Add00 | AG         | AA <sup>o</sup> |            |            | AR00<br>ARO<br>ingrind |
| P3HA           | AN            | NP            | ANvk         | AIV          | f           | ARov       | n               |            |            |                        |
| P3HB           | ARok<br>AR-1  | AROind<br>AR0 |              | MDO<br>Add00 | CO<br>Add00 | AG         | AA <sup>o</sup> | 1→AR1      |            |                        |
| KP3A           | AR9<br>KB     | AR8<br>KB     | AR7<br>KB    | AR6<br>KB    | AR5<br>KB   | AR4<br>KB  | AR3<br>KB       | AR2<br>KB  | AR1<br>KB  | AR0<br>KB              |
| KP3B           | KB<br>AR0     | KB<br>AR1     | KB<br>AR9    | KB<br>AR8    | KB<br>AR7   | KB<br>AR6  | KB<br>AR5       | KB<br>AR4  | KB<br>AR3  | KB<br>AR2              |
| KP3C           | AR00<br>KB    | KB<br>AR00    |              |              |             |            |                 |            |            | AN<br>man              |
| KP4A           | -200V         | 0V            | +100V        | +150V        | +225V       | +300V      |                 | -400V      |            |                        |
| KP4B           | DNKB          |               |              |              |             |            |                 |            |            |                        |
| KP4C           | AR0<br>33k    | AR1<br>33k    | AR2<br>33k   | AR3<br>33k   | AR4<br>33k  | AR5<br>33k | AR6<br>33k      | AR7<br>33k | AR8<br>33k | AR9<br>33k             |
|                |               |               |              |              |             |            |                 |            |            |                        |
|                |               |               |              |              |             |            |                 |            |            |                        |

REGNECENTRALEN  
Dansk Institut for  
Matematikmaskiner

Tegnet *T.V. 2-6-56.*  
Kontrol  
Godk.

Plugsskema  
A0nn

AE32