

---

RCSL No: 44-RT2050

Edition: January 1983

Author: Jens Peter Jacobsen

---

Title:

MON503 - Monitor  
Technical Manual

---

---

**Keywords:**

RC850, MON503, Monitor.

---

**Abstract:**

This manual contains a reprint of the OEM service manual, OEM display manual supplement and a note of the modifications made by RC.

(38 printed pages)

---

Copyright © 1983, A/S Regnecentralen af 1979  
RC Computer A/S

Printed by A/S Regnecentralen af 1979, Copenhagen

Users of this manual are cautioned that the specifications contained herein are subject to change by RC at any time without prior notice. RC is not responsible for typographical or arithmetic errors which may appear in this manual and shall not be responsible for any damages caused by reliance on any of the materials presented.

<u>TABLE OF CONTENTS</u>	<u>PAGE</u>
1. OEM SERVICE MANUAL .....	1
2. OEM DISPLAY MANUAL SUPPLEMENT .....	24
3. RC MODIFICATIONS .....	28




**MOTOROLA**

### GENERAL INFORMATION

The monitors described herein are fully transistorized (except CRT) and applicable for displaying alphanumeric characters. The DS3000, DS3003 series monitors use a 12-inch CRT and the DS4000, DS4003 series monitors use a 15-inch CRT. Each monitor accepts a TTL non-composite video, with separate TTL horizontal and vertical sync pulses. Additional inputs include optional TTL StepScan, and/or optional +24VDC to operate the monitor.

A universal power transformer permits operating the monitor from 120, 220 or 240 volts AC, 50/60 Hz. A built-in regulated power supply provides operating voltages of +24V, +13V and +5V.

Input and output connections for the monitor are made through a standard 10-pin edge connector, (or optional 20-pin connector) on the circuit card. Inputs consist of non-composite video, horizontal sync, vertical sync, and signal ground. The optional TTL level StepScan and +24VDC are also connected to the monitor via the 10-pin edge connector. Three pins on the edge connector are also provided for alternate interconnecting of the remote brightness control.

Circuitry consists of two stages for non-composite video amplification, one integrated circuit for vertical sync and deflection processing, five stages for horizontal sync and deflection processing, and a three stage regulated power supply. All models also contain dynamic focusing and spot kill circuitry.

## SERVICE MANUAL

— VP38 —


### TTL INPUT CRT DISPLAY MONITORS

**DS3000, 3003 SERIES**  
(12-INCH)

**DS4000, 4003 SERIES**  
(15-INCH)


**StepScan™**  
 **MOTOROLA**

One etched circuit card is utilized, which contains all necessary circuitry. Components are mounted on the top of the circuit card and plated copper foil on the bottom. Schematic reference numbers are printed on the top and bottom of each circuit card to aid in the location and identification of components for servicing. All standard operating/adjustment controls are mounted in a convenient manner on the circuit card.



FAEPC-31349-0

Model DS4000, DS4003 Series (15" CRT)



Model DS3000, DS3003 Series (12" CRT)


**MOTOROLA INC.**

Display Systems

1299 E. Algonquin Road, Schaumburg, IL. 60196 (312) 397-8000

MANUAL VP38  
10/81

PART NO. 68P25253A82-1  
© MOTOROLA, INC. 1981

## SAFETY WARNING

**CAUTION: NO WORK SHOULD BE ATTEMPTED ON AN EXPOSED MONITOR CHASSIS BY ANYONE NOT FAMILIAR WITH SERVICING PROCEDURES AND PRECAUTIONS.**

1. **SAFETY PROCEDURES** should be developed by habit so that when the technician is rushed with repair work, he automatically takes precautions.

2. A **GOOD PRACTICE**, when working on any unit, is to first ground the chassis and to use only one hand when testing circuitry. This will avoid the possibility of carelessly putting one hand on chassis or ground and the other on an electrical connection which could cause a severe electrical shock.

3. Extreme care should be used in **HANDLING THE PICTURE TUBE** as rough handling may cause it to implode due to atmospheric pressure (14.7 lbs. per sq. in.). Do not nick or scratch glass or subject it to any undue pressure in removal or installation. When handling, safety goggles and heavy gloves should be worn for protection. Discharge picture tube by shorting the anode connection to chassis ground (not cabinet or other mounting parts). When discharging, go from ground to anode or use a well insulated piece of wire. When servicing or repairing the monitor, if the cathode ray tube is replaced by a type of tube other than that specified under the Motorola Part Number as original equipment in this Service Manual, then avoid prolonged exposure at close range to unshielded areas of the cathode ray tube. Possible danger of personal injury from unnecessary exposure to X-ray radiation may result.


4. An **ISOLATION TRANSFORMER** should always be used during the servicing of a unit whose chassis is connected to one side of the power line. Use a transformer of adequate power rating as this protects the serviceman from accidents resulting in personal injury from electrical shocks. It will also protect the chassis and its components from being damaged by accidental shorts of the circuitry that may be inadvertently introduced during the service operation.

5. Always **REPLACE PROTECTIVE DEVICES**, such as fishpaper, isolation resistors and capacitors and shields after working on the unit.

6. If the **HIGH VOLTAGE** is adjustable, it should always be **ADJUSTED** to the level recommended by the manufacturer. If the voltage is increased above the normal setting, exposure to unnecessary X-ray radiation could result. High voltage can accurately be measured with a high voltage meter connected from the anode lead to chassis.

7. **BEFORE RETURNING A SERVICED UNIT**, the service technician must thoroughly test the unit to be certain that it is completely safe to operate without danger of electrical shock. **DO NOT USE A LINE ISOLATION TRANSFORMER WHEN MAKING THIS TEST.**

In addition to practicing the basic and fundamental electrical safety rules, the following test, which is related to the minimum safety requirements of the Underwriters Laboratories should be performed by the service technician before any unit which has been serviced is returned.



Voltmeter Hook-up for Safety Check

A 1000 ohm per volt AC voltmeter is prepared by shunting it with a 1500 ohm, 10 watt resistor. The safety test is made by contacting one meter probe to any portion of the unit exposed to the operator such as the cabinet trim, hardware, controls, knobs, etc., while the other probe is held in contact with a good "earth" ground such as a cold water pipe.

The AC voltage indicated by the meter may not exceed 7 1/2 volts. A reading exceeding 7 1/2 volts indicates that a potentially dangerous leakage path exists between the exposed portion of the unit and "earth" ground. Such a unit represents a potentially serious shock hazard to the operator.

The above test should be repeated with the power plug reversed, when applicable.

**NEVER RETURN A MONITOR** which does not pass the safety test until the fault has been located and corrected.

## Table of Contents

GENERAL INFORMATION .....	1
SAFETY WARNING .....	2
SPECIFICATIONS .....	4
SERVICE NOTES	
BLOCK/SCHEMATIC DIAGRAMS*	5
ELECTRICAL/MECHANICAL PARTS LISTS*	5
CIRCUIT TRACING .....	5
COMPONENT REMOVAL .....	5
POWER TRANSISTOR REPLACEMENT .....	5
INSTALLATION-MOUNTING SLOT HOLE DIMENSIONS .....	6
CRT REPLACEMENT .....	6
SERVICE PHOTOGRAPHS .....	6
OPERATIONAL CHECK/ADJUSTMENT PROCEDURES	
GENERAL .....	9
EQUIPMENT REQUIRED .....	9
ISOLATED GROUND/COMMON RETURN CHECK .....	9
+24V VOLTAGE REGULATOR CONTROL ADJUSTMENT .....	9
BRIGHTNESS/CONTRAST ADJUSTMENT .....	10
HORIZONTAL OSCILLATOR ADJUSTMENT .....	10
HORIZONTAL SIZE ADJUSTMENT .....	10
VERTICAL HOLD ADJUSTMENT .....	10
VERTICAL SIZE/LINEARITY ADJUSTMENT .....	10
STEPSCAN ADJUSTMENT .....	11
RASTER CENTERING ADJUSTMENT .....	11
RASTER GEOMETRY ADJUSTMENTS .....	12
FOCUS ADJUSTMENT .....	13
THEORY OF OPERATION	
POWER SUPPLY CIRCUIT .....	15
VIDEO AMPLIFIER CIRCUIT .....	15
SPOT KILL CIRCUIT .....	16
STEPSCAN FUNCTION .....	16
STEPSCAN CIRCUIT .....	17
VERTICAL SCAN CIRCUITRY .....	17
HORIZONTAL DRIVE/SYNC DELAY AND REGENERATOR CIRCUITS .....	18
PHASE DETECTOR CIRCUIT .....	18
HORIZONTAL OSCILLATOR/DRIVER CIRCUITS .....	19
HORIZONTAL OUTPUT CIRCUITRY .....	19
DYNAMIC FOCUS CIRCUIT .....	20
SERVICE DIAGRAMS*	
BLOCK DIAGRAM .....	21
CIRCUIT CARD LAYOUT - COMPONENT SIDE .....	22
CIRCUIT CARD LAYOUT - SOLDER SIDE .....	23

\* Service schematic diagrams and electrical/mechanical parts list for the basic DS-Series CRT monitors are not included in this manual; instead, they accompany this manual as a separate supplement (VP38-S1), Motorola Part No. 68P25253A84.

For users of unique variations of the DS-Series (TTL Input) CRT monitors, however, order the schematic diagram by its complete model number.

## SPECIFICATIONS

### DISPLAY

- **DS3000** – 12" diagonal measure
- **DS4000** – 15" measured diagonally, 14" diagonal viewable area
- 110° deflection angle
- 3 x 4 aspect ratio
- P4 phosphor standard (other EIA phosphors available)
- T band U.L. implosion protection
- Direct etch and PPG optional
- **Standard Display Size:** (DS3000) 8.5 X 6.0, (DS4000) 10.0 x 7.5
- Capable of displaying over 3400 characters.

### VIDEO PERFORMANCE

- **Resolution:** 1200 lines center, 950 lines corners (P4 phosphor)
- **Bandwidth:** within 3 dB, 10 Hz to 30 MHz is typical.

### PERFORMANCE FEATURES

- **StepScan<sup>TM</sup>:** Stepped vertical scanning option provides an increased capacity display at any horizontal frequency, thus conserving bandwidth and in many cases, eliminating the need for a higher frequency clock for increased performance.
- **Dynamic Focus:** Excellent corner focus is achieved by supplying dynamic voltage to the focus element of the cathode ray tube.

### SYNCHRONIZATION

- **Horizontal:** 15.7 kHz  $\pm$  500 Standard; 18.7 kHz  $\pm$  500 optional
- **Vertical:** 47 to 63 Hz
- **Horizontal Blanking:** 11  $\mu$ Sec minimum (for scanning frequency of 15.7 kHz); 10  $\mu$ Sec minimum (at 18.7 kHz). Time includes retrace and delay.
- **Vertical Blanking:** 800  $\mu$ Sec (includes retrace and video delay)

### INPUT SIGNALS

- **Horizontal:** 4 to 32  $\mu$ Sec, input TTL compatible, positive-going (negative optional), 4.0V PP  $\pm$  1.5
  - **Vertical:** 50 to 1400  $\mu$ Sec, input TTL compatible, positive (negative optional), 4.0V PP  $\pm$  1.5
  - **Video:** positive white, input termination 470 ohms  $\pm$  5%, 2.5 - 5.0V PP
- Composite video input with DHHS protection circuit optionally available.

### POWER INPUT

- 120/240V AC (105–135), 50/60 Hz, 65VA max.
- 24V DC optional

### INTERCONNECT TO CUSTOMER SYSTEM

- 10 pin edge connector standard
- 20 pin ribbon cable optional

### CONTROLS

- **Internal:** Horizontal size, horizontal video centering, brightness, focus, vertical hold, vertical size, vertical linearity. (All controls adjustable from top or back of unit)
- **External:** Brightness (as an operator control)
- Optional contrast control available.

### GEOMETRY (Pin & Barrel)

- Sides equal less than 1% of height.
- Top and bottom equal less than 1% of width.

### LINEARITY

- Character height or width will not vary  $\pm$  7% from the average character size.
- Adjacent characters will not vary more than 5%.

### ENVIRONMENT

- **Operating Temperature:** 0° to +55°C
- **Storage Temperature:** -40°C to +65°C

**Note:** CRT's with bonded etched panels should not be subjected to storage or operating temperatures above 50°C

- **Operating Altitude:** 10,000 ft. max.

Designed to comply with DHHS Radiation Performance Standards, U.L. and C.S.A. specifications.

\*In a continual effort to upgrade our standard products as new technological advances are made, specifications are subject to change without notice.

### — NOTE —

This manual is up-to-date and correct as of the printing date.

**— CAUTION —**  
NO WORK SHOULD BE ATTEMPTED ON ANY EXPOSED MONITOR CHASSIS BY ANYONE NOT FAMILIAR WITH SERVICING PROCEDURES AND PRECAUTIONS.



### SERVICE NOTES

## BLOCK/SCHEMATIC DIAGRAMS

Refer to Figure 1 for a functional view of an DS-Series Display Monitor in block form. It will help in becoming familiar with the overall schematic diagram, which accompanies this manual as a separate supplement (VP38-S1), Motorola Part No. 68P25253A84.

## ELECTRICAL/MECHANICAL PARTS LISTS

A complete listing of field replaceable parts in alphanumeric sequence is also included with the separate supplement, VP38-S1.

## CIRCUIT TRACING

Component reference numbers are printed on the top and bottom of the circuit card to facilitate circuit tracing. In addition, top (component) and bottom (solder) view drawings are included for convenient viewing of the circuit card. Transistor elements are identified as follows:

E — emitter, B — base, and C — collector

## COMPONENT REMOVAL

On the circuit card, component removal requires the use of a "desoldering" iron, carefully applied to pre-

vent lifting of the foil from the circuit card. An iron with a temperature controlled heating element is recommended to reduce the possibility of card damage. Use latest recommended desoldering procedures. The nozzle of the solder extracting gun should be inserted directly over the component lead which is heated only long enough to melt the solder and draw it away. This should leave the component lead free of the circuit card.

## POWER TRANSISTOR REPLACEMENT

When replacing transistors Q101 (+24V Reg.) or Q402 (Horiz. Output), use the following information and observe all precautions:

1. There are no plug-in sockets; instead, two (2) screws are soldered from the bottom of the circuit card to protrude up through the circuit card and its bracket. The transistors are secured with two (2) nuts each on the top of the circuit card bracket, which also serves as a heat sink.
2. When replacing a transistor, silicone grease (Motorola Part No. 11M490487) should be applied evenly to the top of the heat sink (circuit card bracket) and bottom of the transistor. In addition, be sure a mica insulator is positioned properly between the transistor and heat sink.




Figure 1. DS-Series Display Monitor – Functional Block Diagram

3. The transistor mounting nuts must be tight before applying power to the monitor. This insures proper cooling and electrical connections. **NON-COMPLIANCE WITH THESE INSTRUCTIONS CAN RESULT IN FAILURE OF THE TRANSISTOR AND/OR ITS RELATED COMPONENTS.**

**— NOTE —**

Use caution when tightening transistor mounting nuts. If the screw or nut threads are stripped by excessive pressure, a poor electrical and mechanical connection will result.

### INSTALLATION—MOUNTING SLOT HOLE DIMENSIONS

Figure 2 is a bottom view drawing that clearly illustrates mounting slot hole dimensions. Use it to identify mounting clearances in the final installation.

### CRT REPLACEMENT

#### General

Use extreme care in handling the CRT as rough handling may cause it to implode due to high vacuum pressure.




Figure 2. Mounting Slot Hole Dimensions

Do not nick or scratch glass or subject it to any undue pressure in removal or installation. Use goggles and heavy gloves for protection. Also, be sure to disconnect the monitor from all external voltage sources. Refer to Figure 5 for location of the CRT identification label. Information on the label is essential for ordering the correct replacement CRT!

#### Procedure

- Step 1. Connect a grounding strap (first) to the metal chassis for a good earth ground; then discharge CRT by shorting the H.V. 2nd anode to ground.
- Step 2. Remove the CRT socket, deflection yoke (loosen clamp screw) and 2nd anode lead.
- Step 3. Remove CRT from the front of the chassis by loosening and removing four screws, one at each corner of CRT.
- Step 4. Reverse the above steps to re-install the new CRT.
- Step 5. After installation perform operational check/adjustment procedures.

### SERVICE PHOTOGRAPHS

#### Figure 3:

Figure 3 shows the rear view of a typical DS-Series display monitor. Callouts identify the circuit card edge connector (P1) for signal inputs, a six (6) pin power input connector, and a remote brightness control (R213) soldered to the circuit card. Variations to the aforementioned will include a different type of power connector, and the remote brightness control can be interconnected via the circuit card edge connector.

#### Figure 4:

For convenient access to the component (top) side of the circuit card, reference Figure 4. Callouts accompanying the illustration are self-explanatory.

#### Figure 5:

For convenient unobstructed troubleshooting of the circuit card, stand the monitor on its side as shown in Figure 5. Notice also in this illustration the location of the CRT identification label. The information on this label is essential for ordering the correct replacement CRT.

#### Figure 6:

Reference Figure 6 for quick identification and location of adjustable controls, transistors, integrated circuits, etc.




Figure 3. Typical DS-Series Display Monitor - Rear View




Figure 4. Circuit Card Troubleshooting from Component Side




Figure 5. Circuit Card Troubleshooting from Solder Side




Figure 6. Identification and Location of Circuit Card Components - Adjustable Controls, Transistors, Integrated Circuits, Etc.

## OPERATIONAL CHECK/ADJUSTMENT PROCEDURES

### GENERAL

The following procedures are provided to check the operation of the monitor and perform simple preinstallation adjustments (if required), or readjust after servicing and component replacement.

When reference is made to adjust to a specific size display (vertically and horizontally), refer to original model specifications for correct dimensions by the monitor model number. This also applies to minimum and maximum tolerances when adjusting for correct CRT geometry, linearity, focus, etc.

#### — NOTE —

To assist in understanding more of the preceding terminology, refer to a separate Motorola Manual, "Incoming Inspection Guide" (Motorola part number 68P25253A71).

Perform the procedures in the sequence presented, and allow at least five (5) minutes warm-up before adjusting the monitor. In addition, when instructed to disconnect an input signal, do not ground the signal at the circuit card edge connector (P1). This action could damage the signal source generator. Instead, disconnect the signal at its source.

CCW = Counter Clockwise Rotation, CW = Clockwise Rotation. (As viewed from rear of circuit card.)

### EQUIPMENT REQUIRED

Variac (0-150 Volts AC)

Precision Digital Voltmeter

Non-Metallic Alignment Tool

Test Signals (Bench test signals must be same amplitude, polarity, and frequency as final installed operating signal source. Refer to original specifications for values by monitor model number.)

The following Motorola gauges are required for performing complete and accurate CRT geometry and linearity alignment. Refer to original model specifications for correct gauges to use.

Linearity Gauge

Slot Gauge

Parallelogram Gauge

### ISOLATED GROUND/COMMON RETURN CHECK

#### — CAUTION —

Do not connect power or signals to monitor.

**Procedure No. 1.** For monitors with circuit card common return foil isolated from metallic chassis/earth ground. Isolating components are R112 (22K resistor) and C104 (0.1  $\mu$ F capacitor); jumper JU101 is out.

Step 1. Connect ohmmeter leads between edge connector P1, pin 1, and chassis (earth) ground. Resistance reading should be 22K ohms,  $\pm$  5%.

Step 2. Connect ohmmeter leads between edge connector P1, pin 10, and chassis (earth) ground. Resistance reading should be 22k ohms,  $\pm$  5%.

#### — NOTE —

Step 3 is only for monitors that have their Remote Brightness control (R213) interconnected to the circuit card via edge connector P1, pins 2, 3 and 4.

Step 3. Connect ohmmeter leads between edge connector P1, pin 2, and chassis (earth) ground. Resistance reading should be 22K ohms,  $\pm$  5%.

**Procedure No. 2.** For monitors with non-isolated circuit card common return foil; whereby, the foil is connected direct to the metallic chassis/earth ground via a (white) wire. (Jumper JU101 is in, while components R112 and C104 are out.)

Step 1. Measure between edge connector pins and chassis (earth) ground as described in Procedure No. 1. Resistance readings should be 0.2 ohms or less.

### +24V VOLTAGE REGULATOR CONTROL ADJUSTMENT

#### Procedure

Step 1. Connect monitor to AC line supply. Adjust supply to 120 volts.

Step 2. Apply signal connector to circuit card edge connector, P1.

Step 3. Adjust Vertical (R310) and Horizontal (R418) Hold controls until display is synced.

Step 4. Connect a DC digital voltmeter or other precision accuracy voltmeter to the collector (case) of the regulator output transistor, Q101.

Step 5. Adjust the +24V Voltage Regulator control, R107, for output of +24 volts  $\pm$  0.5 volts.

Step 6. When adjustment is complete, vary the AC line supply voltage between 105 and 135 volts to check for proper regulator operation. If regulator is operating properly there should be no change in display size.

## BRIGHTNESS/CONTRAST ADJUSTMENT

### Procedure

Step 1A. Disconnect video signal input (only) at pin 8 of edge connector P1 . . .

or

Step 1B. If monitor is equipped with a Contrast control (R216 on monitor circuit card or customer supplied off-circuit card), rotate to the position that cuts off the video input signal.

Step 2. Rotate Master Brightness control (R212) fully CCW (raster off).

Step 3. Rotate Remote Brightness control (R213) fully CCW (raster off).

Step 4. Rotate Master Brightness control (R212) until the raster just begins to appear on the CRT; then back off slightly to the threshold of raster cutoff.

Step 5A. Reconnect video signal . . .

or

Step 5B. Adjust Contrast control (if present) for desired video display level on CRT.

Step 6. Adjust Remote Brightness control (R213) for desired (overall) brightness level.

## HORIZONTAL OSCILLATOR ADJUSTMENT

### Procedure

Step 1. Disconnect horizontal sync input (only) at pin 6 of edge connector P1.

Step 2. Adjust Horizontal Hold control (R418) until video display approaches best horizontal sync condition. (Without the horizontal sync input connected, however, the display will never quite lock in.)

### — NOTE —

It may be necessary to temporarily increase the raster brightness with the Remote Brightness control (R213) to view the raster edges.

Step 3. Reconnect the horizontal sync signal. (At this point the video display should be in sync.)

Step 4. Adjust the Horizontal Delay control (R402) until the video display is centered horizontally within the raster (as viewed from the left side to the right side of the raster).

## HORIZONTAL SIZE ADJUSTMENT

### Procedure

Adjust Horizontal Width coil (L401) for specified video width (horizontally).

### — NOTE —

To increase width, rotate coil slug CCW (away from circuit card); to decrease width, rotate coil slug CW (toward circuit card).

## VERTICAL HOLD ADJUSTMENT

### Procedure

If video display is rolling, adjust the Vertical Hold control (R310) until the video display remains locked in.

## VERTICAL SIZE/LINEARITY ADJUSTMENT

### Procedure No. 1 (Monitors without StepScan)

Step 1. Adjust the Vertical Size control (R312) until the specified size display (vertically) is obtained.

Step 2. (Refer to Figure 7.) Adjust the Vertical Linearity control (R315) until the extreme top and bottom characters (designated "A" and "B") are equal in height to the center characters (designated "C").

Step 3. Readjust the Vertical Size control (R312), if necessary, for specified size display (vertically).

### Procedure No. 2 (Monitors with StepScan)

Step 1. With specified StepScan input connected to pin 5 of edge connector P1, rotate the Step Adjust control (R504) for minimum vertical size. (This control will be final adjusted later.)

Step 2. Adjust Vertical Size control (R312) for specified vertical size display — before StepScan is actively applied with Step Adjust control, R504.

Step 3. (Refer to Figure 7.) Adjust the Vertical Linearity control (R315) until the extreme top and bottom characters (designated "A" and "B") are equal in height to the center characters (designated "C").

Step 4. Readjust the Vertical Size control (R312), if necessary, for specified size display (vertically) as described in Step 2.




Figure 7. Partial CRT Display of Characters for Vertical Linearity Adjustment

#### STEPSCAN ADJUSTMENT (Applicable to monitors with StepScan only)

##### General

StepScan is a unique input signal that is accounted for, and incorporated, when the original video signal format is being developed. As a result, it cannot be connected to just any monitor, even if the monitor has the necessary StepScan circuitry. Check original video signal format specification.

##### Procedure:

- Step 1. Be sure specified positive-going TTL level Step-Scan signal is connected to pin 5 of edge connector P1.
  - Step 2. Rotate the Step Adjust control (R504) through its entire range slowly, and observe that the display size increases vertically.
  - Step 3A. Adjust the Step Adjust control (R504) for correct vertical size per original model specifications
- or
- Step 3B. If the StepScan is not required in the final installed application, rotate the Step Adjust control (R504) for minimum vertical size. (See following NOTE.)

#### — NOTE —

In Step 3B this is applicable only if the StepScan input remains connected to the edge connector from its source. However, if the StepScan source is physically disconnected from pin 5 of the edge connector, pin 5 must be grounded to pin 1 or 10. In either of these conditions, proceed to Step 4.

- Step 4. Readjust Vertical Size control (R312) to desired height vertically.

#### RASTER CENTERING ADJUSTMENT (Applicable only if the CRT and/or deflection yoke have been changed.)

#### — NOTE —

Depending on the input signal format, the video display on some monitors will be down-centered more than normal within the raster. As a result, an up-centering resistor (R325) is added, which shifts the entire raster (and video display) up. (The shift will vary between 0.1 – 0.4 inches.) This action is necessary to minimize over-adjusting the Centering Magnets to recenter the video display. (Excessive adjustment of the Centering Magnets could cause geometric distortion.)




Figure 8. Partial View of CRT Neck/Deflection Yoke — Centering Magnets

### General

This procedure should be performed while the monitor is free-standing on a bench, and in the correct sequence (preceding the Raster Geometry Adjustment procedure). Do not readjust after the monitor has been installed in a cabinet or terminal.

#### Procedure No. 1 (For monitors without up-centering resistor R325.)

- Step 1. Turn up the Remote Brightness control (R213) until the four (4) edges of the raster are visible.
- Step 2. (Reference Figure 8.) Rotate the two (2) centering magnets (simultaneously) until the raster is centered (horizontally and vertically) within the active phosphor area of the CRT. (Reference Figure 9.)
- Step 3. Readjust the Remote Brightness control (R213) for desired (overall) brightness level.




Figure 9. Raster Centering Without Up-Centering Resistor, R325

#### Procedure No.2 (For monitors with up-centering resistor R325.)

- Step 1. Turn up the Remote Brightness control (R213) until the four (4) edges of the raster are visible.
- Step 2. (Reference Figure 8.) Rotate the two (2) centering magnets (simultaneously) until the left and right edges of the raster are centered horizontally, and the top and bottom edges of the video display are centered vertically within the active phosphor area of the CRT. (Reference Figure 10.)




Figure 10. Raster Centering With Up-Centering Resistor, R325

- Step 3. Readjust the Remote Brightness control (R213) for desired (overall) brightness level.

### — CAUTION —

Remember, do not readjust the centering magnets after performing the CRT Raster Geometry Adjustment procedure that follows, or after final installation. CRT raster geometry will be affected.

## RASTER GEOMETRY ADJUSTMENTS

### General


This adjustment is normally required only if the yoke and/or CRT have been replaced. Upon completion of the geometry adjustments, there may not be a yoke magnet installed on every yoke mounting pin. Normal installation ranges from one to four yoke magnets per deflection yoke. In addition, keep in mind that there will be some interaction between yoke magnets on the deflection yoke mounting pins. Whereby, as the geometry adjustment proceeds, it may be necessary to remove an earlier positioned magnet from one pin when a new magnet is positioned (or added) on a different pin.

There are two (2) different strength yoke magnets available for correcting CRT geometry. The soft core (or flexible) magnet is the stronger of the two magnets. (Reference Figure 11 to identify their north poles.) Pincushion and trapezoidal correction generally require high strength magnets, and barrel correction requires a lower strength magnet for correction.



**— WARNING —**

High voltages are present at the deflection yoke and are a potential shock hazard. Exercise caution when performing the following adjustment procedures.




AEP-01371-0

*Figure 11. Yoke Magnet North Pole Identification*

**Pincushion/Barrel Correction (top, bottom and sides) Procedure**

Perform this adjustment if the raster exhibits the abnormal effects shown in Figure 13.

- Step 1. Push a magnet on the yoke mounting pin as shown in Figure 13. A magnet should be placed only on the pin that corresponds to the affected area.
- Step 2. Rotate the magnet to obtain the desired raster, labeled "NORMAL" on Figure 13.
- Step 3. If the desired raster cannot be obtained, add a second magnet to the yoke mounting pin. Both magnets must be aligned as shown in Figure 12; then rotated simultaneously.



*Figure 12. Installing a Second Yoke Magnet*

**Trapezoidal Correction (corners) Procedure**

Perform this adjustment if the raster exhibits the abnormal effects shown in Figure 14.

- Step 1. Push a magnet onto the yoke mounting pin as shown in Figure 14. Magnet should be placed only on the pin that corresponds to the affected area.
- Step 2. Rotate the magnet to obtain the desired raster, labeled "NORMAL" in Figure 14.
- Step 3. If the desired raster cannot be obtained, add a second magnet to the yoke mounting pin. Both magnets must be aligned as shown in Figure 12; then rotated simultaneously.

**FOCUS ADJUSTMENT**

**Procedure**

The optimum focus of the display is obtained by adjusting the focus control, R429, for best focus at a point which is near the center and approximately one-third (1/3) down from the top of the display.




Figure 13. Pincushion/Barrel Effects and Adjustment




Figure 14. Trapezoidal Effect and Adjustment

## THEORY OF OPERATION

**POWER SUPPLY (Refer to Figure 15)**

The power supply is a transformer operated, full wave, regulated series pass circuit that maintains a constant output voltage with line input variations of  $\pm 12.5\%$ . Depending on how connector S1 is wired, operation from 120, 220 or 240 volts, 50/60 Hz is possible. Integrated circuit IC101 is the reference amplifier, transistor Q102 is the regulated output driver, and Q101 is the series pass transistor.

The output voltage, +24V, appears at the collector of Q101. This voltage is divided between R106, R107 and R109. Resistor R108 limits the range of R107. The voltage appearing on the arm of potentiometer R107 (24V ADJ. control) is the reference input to the inverting input (—) of reference amplifier IC101.

A temperature compensated zener diode, VR101, establishes a fixed reference voltage at the non-inverting input (+) to IC101. Resistors R110 and R111 and diode D105 provide bias current for VR101. The junction of R110 and R111 is the +13V source for the horizontal oscillator, IC402. Regulator VR101 is also the 5 volt source for the monitor circuitry. Operating voltage for IC101 is derived from resistor network R101 and R105.

An increase in output current will cause a decrease in output voltage due to internal supply impedance. This will cause the voltage at the base of Q102 to become more positive via the inverting amplifier IC101. With the base more positive, Q102 will conduct more, increasing its collector current. This increases the base current in Q101. The result is increased output current from Q101, raising the output voltage and maintaining the proper output voltage level.


Electrolytic capacitor C101, section "A", filters the bridge rectifier (D101–D104) output, while section "B" provides additional filtering of the +24V regulator output. Capacitor C103 filters the +5 volt source, R102 is the load resistor for Q102. Resistors R103, R104 bias Q102. Capacitor C102 increases regulation at high frequencies for improved transient response.

### VIDEO AMPLIFIER (Refer to Figure 16)

The linear video amplifier consists of two stages, Q201 and Q202, which are connected in a cascode configuration. This common emitter-common base arrangement greatly reduces the effect of Miller capacity (when compared to a conventional single transistor video amplifier/output stage).

A TTL compatible non-composite video signal, approximately 4.0 volts P-P, is DC coupled to the base of Q201 via R202. Resistor R201 provides proper termination for the high frequency input video signal. R203 and C201 provide high frequency compensation to maintain a flat response when Q201 and Q202 conduct. Contrast control R216 (when present) is used to limit the input video signal, which indirectly varies the amplitude of the video drive to the CRT cathode. This action is necessary to provide a contrast function when more than one level of video is applied to the input. Capacitor C208 (when present) provides high frequency compensation for the input video signal.

During a no-signal condition, video driver transistor Q201 is off. At the same time, video output transistor Q202 is base



**Figure 15. AC Power Input/Regulated Power Supply Output**






Figure 17. Displaying Characters on a Monitor with StepScan

### STEPSCAN CIRCUIT (Refer to Figure 18)

The StepScan circuit requires an external TTL positive-going pulse of approximately 4.0 volts P-P. These pulses are applied to pin 5 of IC201C through the protective network R501, D501 and D502. These pulses switch the TTL input of IC201C from the low state, normally maintained by resistor R502, to the high state. The open collector output of IC201C, pin 6, conducts during these pulses. These current pulses, regulated by control R504, are applied to the height adj. pin (7) of the vertical processor, IC301. The slope of the output sawtooth current is increased during these pulses to "step" the vertical position to the next character.

The rate at which the vertical processor "steps" is determined by the repetition rate of the incoming StepScan pulses. The slope (charge rate) of the stepped portion of the sawtooth is adjustable with the STEP ADJ. control, R504, which varies the spacing between the character rows. With the vertical sawtooth thus modified, the yoke vertical deflection current will be "stepped" during the line between character rows chosen. One additional component associated

with StepScan operation is capacitor C307. It increases the response of IC301 internal amplifier output (pin 4) by coupling the leading edge of the StepScan pulses into the amplifier input of IC301 (pin 10).

### VERTICAL SCAN (Refer to Figure 18)

Input TTL level pulses pass through resistor R301 and protective diodes D301 and D302 to IC201B or IC201E inputs. The input to IC201B accepts, through jumper JU302, negative vertical sync and the input to IC201E accepts, through jumper JU301, positive vertical sync. R303 holds the input of IC201B low to prevent its output, an open collector, from shorting the input to IC201E when negative sync is not selected.

Output pulses from IC201E (pin 10) are differentiated by capacitor C301 and resistor R306. Diode D303 couples only the negative-going spikes from the differentiator circuit to the sync input of IC301 (pin 8). R307 and R308 provide input current limiting. The sync input (pin 8) performs several functions. It strips away any random noise that may be present on the input line and conditions the vertical pulses for processing. It also converts the input voltage pulses to current to control the internal oscillator. The oscillator generates a non-symmetrical square wave with a short duty cycle at the vertical scan frequency (50 to 60 Hz). Components R310, R311 and C304 determine the frequency. This square wave signal is applied to a ramp generator whose slope and amplitude is determined by R312, R313, C305 and C306. The ramp voltage signal is applied to a buffer stage which isolates the ramp generator from the output stages and reduces any loading effect on the previous stages. Components R314, R316 and R315 reshape the ramp voltage to make it extremely linear.




Figure 18. StepScan and Vertical Circuits

The output signal from pin 4 (IC301) drives the vertical deflection coils directly via coupling capacitor C312. Components R321 and C311 provide damping to prevent any oscillations in the output circuit. R320, R322, R319, R318, R323, C310 and C308 provide AC and DC feedback for the output stage to maintain proper gain and linearity. When the scan reaches the bottom of the screen a sync pulse initiates retrace. To insure a quick return to the top of the screen the voltage across the yoke is doubled during retrace to quickly discharge the yoke inductance. This voltage doubling circuit consists of diode D304, capacitor C302 and a transistor network in IC301. Capacitor C314 provides additional (external) compensation for IC301, pin 11. Resistor R325 (when present) is used to up-center the raster and video display.

#### HORIZONTAL DRIVE/SYNC DELAY AND REGENERATOR (Refer to Figure 19)

TTL horizontal rate sync is coupled to the input of IC401B through the protective network consisting of resistor R401 and diodes D401 and D402. Capacitor C426 prevents non-horizontal rate transients from false-triggering IC401B. Jumpers W1 or W2 and W3 select positive or negative sync respectively. IC401B is a monostable multivibrator with its time constant being established by resistor R403, HORIZ. DELAY control R402, and capacitor C401. A positive pulse appears at pin 13 of IC401B, the leading edge coincident with the selected leading edge of horizontal sync and the trailing edge determined by the HORIZ. DELAY control, R402.

The falling edge of this pulse triggers IC401A, another monostable multivibrator, whose time constant (established by R406 and C403) regenerate a positive pulse at pin 5 of IC401A. Pulse width at this point is approximately equal to the input sync pulse. This pulse is inverted and increased in amplitude to 24V P-P by IC201D.

#### PHASE DETECTOR (Refer to Figure 19)

The phase detector consists of two diodes (D403 and

D404) in a keyed clamp circuit. Its function is to develop a control voltage for synchronizing the horizontal oscillator with the incoming sync pulses. Two inputs are required to generate the required output; one from the horizontal sync regenerator IC401A, and one from the horizontal output circuit, Q402. The required output must be of the proper polarity and amplitude to correct phase differences between the input horizontal sync pulses and the horizontal time base. Each pulse from the collector of the horizontal output, Q402, is integrated into a sawtooth by R411 and C405. Capacitor C406 blocks DC from the collector of Q402. The output transistor of IC201D is normally at cut-off and its collector voltage rests at approximately 24 volts. Since C404 is connected to the output of IC201D, it will charge up to the collector voltage. When a pulse turns on and saturates the output of IC201D, its collector voltage drops to near ground potential. C404 will now discharge, coupling a negative-going sync pulse to the cathodes of D403 and D404. This negative potential is sufficient to forward bias both diodes to conduct and discharge any positive or negative charge on C405 to ground. In other words, it clamps the voltage on capacitor C405 during sync pulse time to approximately zero volts.

Without considering the sync pulses, the sawtooth wave would cause current flow into capacitor C405 when it is negative, and out of C405 when it is positive. Since the sawtooth is symmetrical about its AC axis, the charge and discharge currents of C405 are equal. C405 would therefore average a zero voltage level. A sync pulse (waveform A, Figure 20) clamping the sawtooth as it passes through its AC axis (waveform B, Figure 20), will not affect its positive and negative symmetry. Therefore, the average voltage on C405 would remain zero. However, if the horizontal time base begins to lag, the sync pulse will clamp the sawtooth to ground at a point below its AC axis, resulting in a non-symmetrical charge on C405. This clamping action will cause the sawtooth's AC axis to shift to a point above the




Figure 19. Horizontal Drive/Sync Delay, Sync Regenerator and Phase Detector Circuits




Figure 20. Phase Synchronization Waveforms

ground reference (waveform C, Figure 20). Therefore, most of the sawtooth's waveform is now above ground which will produce a positive voltage on C405. This is the correct polarity to cause the horizontal oscillator to speed up to correct the phase lag. Likewise, if the horizontal time base is leading the sync pulse, the sawtooth will be clamped to ground at a point above its AC axis. This clamping action will cause the sawtooth's AC axis to shift to a point below the ground reference (waveform D, Figure 20). Now most of the sawtooth's waveform is below ground, which will produce a negative voltage on C405. This is the correct polarity to cause the horizontal oscillator to slow down. The voltage level on C405 is dependent upon which point of the sawtooth is clamped. This also determines how far its AC axis will shift above or below ground.

R412, C407, R413 and C408 comprise the phase detector filter. The bandpass of this filter is designed to provide correction of horizontal oscillator phase without ringing or hunting.

#### HORIZONTAL OSCILLATOR/DRIVER (Refer to Figure 21)

Integrated circuit timer IC402 operates as an astable square wave oscillator. Its free running frequency is determined by resistors R415, R416, and capacitor C409. The phase detector correction voltage is coupled through resistor R414 to pins 2 and 6 of IC402 to vary the frequency of the oscillator. A second input to IC402, pin 5, allows control of the oscillator free-run frequency by means of R418, HORIZ. HOLD control.

The non-symmetrical output of IC402 (pin 3) is coupled to the horizontal driver transistor, Q401, through C411 and current limiting resistor R419. D405 protects Q401 from

reverse base-emitter voltage. Q401 operates as a switch to drive the horizontal output transistor Q402 through transformer T401. T401 is a voltage stepdown transformer to provide a low impedance drive to Q402. R421 is a current limiting resistor for Q401 and C414 is an AC bypass capacitor. R420 and C413 damp the transformer to prevent ringing when Q401 goes into cutoff.

#### HORIZONTAL OUTPUT (Refer to Figure 21)

The secondary of T401 provides the required low drive impedance for Q402. Components R422 and C415 form a time constant for fast turn-off of Q402. The horizontal output transistor, Q402, is simply a switch that is turned on and off at the horizontal scan rate by the drive signal applied to its base. A sawtooth current through the deflection coils is required to sweep the beam linearly across the CRT screen. The sweep begins at the center of the CRT and sweeps to the right. This happens when Q402 is turned on and its collector voltage drops to near zero. C419 begins discharging through the deflection coils to deflect the beam to the right edge of the CRT. At this time, Q402 cuts off and C419 ceases to supply current to the deflection coils. However, an induced voltage appears across the deflection coil as the magnetic field collapses, and an oscillation occurs between the deflection coils and C416.

During the first half cycle of this oscillation, the induced voltage is felt across the collector of now cut off Q402, C416, and the primary of T402, the flyback transformer. This voltage is stepped up by T402 and rectified to produce the required high voltage that is applied to the 2nd anode of the CRT. The electron beam is also deflected to the left edge of the CRT at this time because the collapsing magnetic field of the deflection coils reverses polarity.

During the second half cycle of the deflection coils/C416 oscillation, the voltage on the collector of still cut off Q402 becomes negative. At this time, damper diode D406 becomes forward biased and begins conduction. The deflection coil current gradually decreases to zero during damper conduction allowing the beam to sweep linearly to the center of the screen.

The horizontal retrace pulse charges C422 through D407 to provide operating voltage for G2 of the CRT. Momentary transients at the collector of Q402, should they occur, are limited to the voltage on C422 since D407 will conduct if the collector voltage exceeds this value. Coil L402 is a magnetically biased Horiz. Linearity coil that shapes the deflection current for optimum trace linearity. Coil L401 is a series Horiz. Width control. Components R425 and C418, R424 and C417 are damping network components for the Horizontal Linearity (L402) coil and WIDTH (L401) control.

The 24 volt supply to the horizontal output is coupled through diode D409 to pin 3 of the transformer, T402. Autoformer action of the transformer boosts the effec-




Figure 21. Horizontal Oscillator, Driver and Output Circuits, and Dynamic Focus Circuit


tive supply voltage to the transformer to the 70 volts appearing on pin 1 of T402. This voltage is filtered by C205 and provides the 70 volt source for the chassis. A capacitive divider, C421 and C420, and diode D408 provides a -70 volt supply for the CRT G1 electrode.

#### DYNAMIC FOCUS (Refer to Figure 21)


Due to the geometry of a CRT, the electron beam travels a greater distance when deflected to a corner as compared to the distance traveled at the center of the CRT screen. As a result of these various distances traveled, optimum focus can be obtained at only one point. For general applications, an adequate adjustment can be realized by setting the focus while viewing some point mid-way between the center of the CRT screen and a corner, thus optimizing the overall screen focus. When an application requires a

tighter specification, one of the simplest methods for improvement is to modulate the focus voltage at a horizontal sweep rate. Now optimum focus voltage is made variable on the horizontal axis of the CRT, which compensates for the beam travel along this axis. The AC component of the focus voltage is developed by stepping up the voltage across capacitor C419 via transformer T403. The linear current ramp in the horizontal yoke winding, L1B, also flows through capacitor C419. The ramp is integrated, the result being a parabolic waveform. This parabola is coupled through capacitor C424 and resistor R433 to the primary of transformer T403. The approximately 250V P-P parabola present at pin 6 of T403 is superimposed on the DC voltage from the FOCUS control, R429, via capacitor C423. This mixed AC and DC voltage results in a waveform of proper phase and amplitude, which is coupled through isolating resistor R431 to the CRT focus anode.





— COMPONENT SIDE SHOWN —



### Monitor Circuit Card Layout – Component Side



**MOTOROLA**

VP38-S1

**DISPLAY MANUAL SUPPLEMENT****INSTRUCTION MANUAL AFFECTED:**

Service Manual VP38  
Motorola Part No. 68P25253A82

**PURPOSE:**

Provide service information in the form of a replacement parts list and two (2) schematics. The information contained in this supplement is to be used in conjunction with a separate Motorola service manual, part no. 68P25253-A82 (File VP38).

**DESCRIPTION:**

The two (2) schematics represent the following models:

DS3000, 3003 - 100 thru _00	}	<u>without</u> StepScan
DS4000, 4003 - 100 thru _00		
DS3000, 3003 - 140 thru _40	}	<u>with</u> StepScan
DS4000, 4003 - 140 thru _40		

The replacement parts list is integrated to represent all models, with or without StepScan.

(Page 1 of 4)

**MOTOROLA INC.****Display Systems**

1299 East Algonquin Road, Schaumburg, IL. (312) 397-8000


(VP38-S1)  
8/8168P25253A84-1  
© MOTOROLA INC. 1981

## DS SERIES (TTL VERSION WITH AND WITHOUT STEPSCAN) REPLACEMENT PARTS LIST

NOTE —  
When a component requires replacement, it is recommended that only Motorola part numbers be used. This is necessary to ensure optimum performance and reliability from selected components with specific operating characteristics. When a part number is not listed, however, an equivalent may be substituted.

The following parts list represents components for the four (4) basic CRT display models; DS3000, DS3003, DS4000 and DS4003 (100, 200, 300, etc., and 140, 240, 340, etc.) Series. For replacement of components that differ in unique CRT display models, compared to the four (4) basic models, order by the unique model number, schematic designator and description.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
<b>CAPACITORS:</b> (Unless otherwise noted, all capacitor values are in microfarads)											
C101	23R2694A06	4500/50V, 2000/30V; Lytic	C418	21S180E78	270 pF 10K, X5F, 500V; Cer.	R104	6S126A33	FCC; 220 5%, 1W	T402	24D26291A13	Transformer, High Voltage; Incl.
C102	23R2697A12	0.22 10K, 50V; Poly	C419	8R29951A07	1.0 10K, 200V; Poly	R107	18D2590A06	FCC; 100 5%, 2W (Standup Type)	T402	24D26291A10	Transformer, High Voltage; Incl.
C103	23R2691A21	100, 10V; Lytic	C420	8R29951A06	0.08 10K, 200V; Poly Carb	R110	6S127A26	FCC; 82 5%, 1W	T402	24D26291A11	Transformer, High Voltage; Incl.
C104	—	0.1 (Optional)	C421	8R2997A31	0.033 10K, 200V; Poly	R111	6S126A23	WW; 1.2K 5%, 5W	T403	24D26291A11	Transformer, High Voltage; Incl.
C201	21S180E50	120 pF 5%, NPO, 100V; Cer.	C422	8R2998A58	0.01 10K, 600V; Poly	R120	17-136197	FCC - Fixed Carbon Film	T403	28D26772806	Transformer, Dynamic Foos
C202	23R2691A47	22, 35V; Lytic	C423	8R2998A58	0.01 10K, 600V; Poly	R210	18D2590A02	FCC - Fixed Carbon Composition			
C203	21R2696A06	0.1 80-20%, ZSU, 100V; Cer.	C424	21R2696A06	0.05 20K, ZSU, 500V; Cer.	R212	18D2590A02	WW - Wirewound			
C204	21S132482	0.1 80-20%, ZSV, 100V; Cer.	C425	—	(Special)	R213	18D2590A02	FCC - Fixed Carbon Composition			
C205	23R2694A06	68, 100V; Lytic	C426	21S131625	330 pF 10K, X5F, 500V; Cer.	R214	6S126A33	WW - Wirewound			
C206	23R2694A06	0.1 80-20%, ZSV, 100V; Cer.				R215	18D2590A02	FCC; 220 5%, 1W			
C207	21S180A62	0.05 20K, ZSU, 500V; Cer.				R216	6S126A33	FCC; 220 5%, 1W			
C208	—	(Special)				R217	18D2590A02	FCC; 220 5%, 1W			
C301	21R2696A06	0.1 80-20%, ZSU, 100V; Cer.	D101 D104	48R191A12	Rectifier, Silicon; (91A12)	R218	6S126A33	FCC; 220 5%, 1W			
C302	23R2691A406	100, 50V; Lytic	D105	48R20205A00	Silicon Diode, Gen. Purpose; (205A)	R219	6S126A33	FCC; 220 5%, 1W			
C303	21R2696A06	0.1 80-20%, ZSU, 100V; Cer.	D201	48R20205A00	Silicon Diode, Gen. Purpose; (205A)	R220	6S126A33	FCC; 220 5%, 1W			
C304	8R2697C31	0.15 10K, 100V; Poly	D304	48R191A02	Rectifier, Silicon; (91A02)	R221	6S126A33	FCC; 220 5%, 1W			
C305 C306	8R2697C29	0.1 10K, 100V; Poly	D401 D405	48R20205A00	Silicon Diode, Gen. Purpose; (205A)	R222	6S126A33	FCC; 220 5%, 1W			
C307	21S180E58	150 pF 5%, NPO, 100V; Cer.	D406	48R134821	Silicon Diode, Damp; 800V	R223	6S126A33	FCC; 220 5%, 1W			
C308	21S180B94	33 pF 10K, NPO, 500V; Cer.	D407	48R134821	Silicon Diode; (D1K)	R224	6S126A33	FCC; 220 5%, 1W			
C309	23R2691A47	22, 35V; Lytic	D408	48R20205A00	Diode, Fast Recovery; 200V	R225	6S126A33	FCC; 220 5%, 1W			
C310	21R2696A06	0.1 80-20%, ZSU, 100V; Cer.	D409	48R20205A00	Diode, Fast Recovery; 800V	R226	6S126A33	FCC; 220 5%, 1W			
C311	23R2691A406	1800, 25V; Lytic	D501 D502	48R20205A00	Silicon Diode, Gen. Purpose; (205A)	R227	6S126A33	FCC; 220 5%, 1W			
C312	—	(Not Used)	FUSES:			R228	6S126A33	FCC; 220 5%, 1W			
C313	21S180B91	0.01 10K, X5F, 500V; Cer.	F101	6S126A33	2.5 Amp, 250V (120, 220 VAC Operation)	R229	6S126A33	FCC; 220 5%, 1W			
C401	21S180E50	120 pF 5%, NPO, 100V; Cer.				R230	6S126A33	FCC; 220 5%, 1W			
C402	23R2694A06	0.1 80-20%, ZSV, 100V; Cer.				R231	6S126A33	FCC; 220 5%, 1W			
C403 C404	21S180B91	0.01 10K, X5F, 500V; Cer.				R232	6S126A33	FCC; 220 5%, 1W			
C405	21S180C41	0.027 10K, ZSF, 100V; Cer.				R233	6S126A33	FCC; 220 5%, 1W			
C406	21S180E91	0.039 10K, ZSF, 100V; Cer.				R234	6S126A33	FCC; 220 5%, 1W			
C407	23R2691A47	0.1 80-20%, ZSV, 50V; Cer.				R235	6S126A33	FCC; 220 5%, 1W			
C408	23R2691A47	0.1 80-20%, ZSV, 50V; Cer.				R236	6S126A33	FCC; 220 5%, 1W			
C409	23R2691A47	0.1 80-20%, ZSV, 50V; Cer.				R237	6S126A33	FCC; 220 5%, 1W			
C410	23R2691A47	0.1 80-20%, ZSV, 50V; Cer.				R238	6S126A33	FCC; 220 5%, 1W			
C411	23R2691A47	0.1 80-20%, ZSV, 50V; Cer.				R239	6S126A33	FCC; 220 5%, 1W			
C412	23R2691A47	0.1 80-20%, ZSV, 50V; Cer.				R240	6S126A33	FCC; 220 5%, 1W			
C413	23R2691A47	0.1 80-20%, ZSV, 50V; Cer.				R241	6S126A33	FCC; 220 5%, 1W			
C414	23R2691A47	0.1 80-20%, ZSV, 50V; Cer.				R242	6S126A33	FCC; 220 5%, 1W			
C415	23R2691A47	0.1 80-20%, ZSV, 50V; Cer.				R243	6S126A33	FCC; 220 5%, 1W			
C416	8R26930E45	0.091 5%, 1200V; Poly Carb				R244	6S126A33	FCC; 220 5%, 1W			
C417	8R26930E45	0.091 5%, 1200V; Poly Carb				R245	6S126A33	FCC; 220 5%, 1W			
C418	8R26930E41	0.091 5%, 1200V; Poly Carb				R246	6S126A33	FCC; 220 5%, 1W			
C419	8R26930E97	0.091 5%, 1200V; Poly Carb				R247	6S126A33	FCC; 220 5%, 1W			
C420	21S180B51	0.01 10K, X5F, 500V; Cer.				R248	6S126A33	FCC; 220 5%, 1W			
C421	21S180B51	330 pF 10K, X5F, 500V; Cer.				R249	6S126A33	FCC; 220 5%, 1W			
C422	21S180B51	(DS3003, 4000)				R250	6S126A33	FCC; 220 5%, 1W			
<b>TRANSISTORS:</b>											
Q101	48R137875	PNP, 7875 (24V Reg.)	Q101	48R137875	PNP, 7875 (24V Reg.)	T401	25D26772A04	Transformer, Horiz. Driver			
Q102	48R03026A00	NPN, 3026 (Reg. Driver)	Q102	48R03026A00	NPN, 3026 (Reg. Driver)	T402	24D26291A12	Transformer, High Voltage; Incl.			
Q201	48R134952	NPN, A21 (Video Driver)	Q201	48R134952	NPN, A21 (Video Driver)						
Q202	48R03026A00	NPN, 3026 (Video Output)	Q202	48R03026A00	NPN, 3026 (Video Output)						
Q401	48R03030A00	PNP, 3030 (Horiz. Driver)	Q401	48R03030A00	PNP, 3030 (Horiz. Driver)						
Q402	48R137886	NPN, 7886 (Horiz. Output)	Q402	48R137886	NPN, 7886 (Horiz. Output)						
<b>MECHANICAL PARTS LIST</b>											
REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
41C26830A02	41C26830A02	Spring, Aquadag	41C26830A02	41C26830A02	Spring, Aquadag	41C26830A02	41C26830A02	Spring, Aquadag	41C26830A02	41C26830A02	Spring, Aquadag
42B25168C01	42B25168C01	Clamp, Deflection	42B25168C01	42B25168C01	Clamp, Deflection	42B25168C01	42B25168C01	Clamp, Deflection	42B25168C01	42B25168C01	Clamp, Deflection
1V2557A401	1V2557A401	Socket, CRT (Incl. leads and retainer)	1V2557A401	1V2557A401	Socket, CRT (Incl. leads and retainer)	1V2557A401	1V2557A401	Socket, CRT (Incl. leads and retainer)	1V2557A401	1V2557A401	Socket, CRT (Incl. leads and retainer)
14S562353	14S562353	Insulator, Transistor	14S562353	14S562353	Insulator, Transistor	14S562353	14S562353	Insulator, Transistor	14S562353	14S562353	Insulator, Transistor
7025901A01	7025901A01	Bracket, Side, Right-Hand (DS4000, 4003)	7025901A01	7025901A01	Bracket, Side, Right-Hand (DS4000, 4003)	7025901A01	7025901A01	Bracket, Side, Right-Hand (DS4000, 4003)	7025901A01	7025901A01	Bracket, Side, Right-Hand (DS4000, 4003)
7025901A02	7025901A02	Bracket, Side, Left-Hand (DS4000, 4003)	7025901A02	7025901A02	Bracket, Side, Left-Hand (DS4000, 4003)	7025901A02	7025901A02	Bracket, Side, Left-Hand (DS4000, 4003)	7025901A02	7025901A02	Bracket, Side, Left-Hand (DS4000, 4003)
7025902A01	7025902A01	Bracket, Mounting Foot (2 Rec'd)	7025902A01	7025902A01	Bracket, Mounting Foot (2 Rec'd)	7025902A01	7025902A01	Bracket, Mounting Foot (2 Rec'd)	7025902A01	7025902A01	Bracket, Mounting Foot (2 Rec'd)
7025902A04	7025902A04	Heat Sink/Support (IC301)	7025902A04	7025902A04	Heat Sink/Support (IC301)	7025902A04	7025902A04	Heat Sink/Support (IC301)	7025902A04	7025902A04	Heat Sink/Support (IC301)
7025902A12	7025902A12	Clip, Fuser, F101 (2 Rec'd)	7025902A12	7025902A12	Clip, Fuser, F101 (2 Rec'd)	7025902A12	7025902A12	Clip, Fuser, F101 (2 Rec'd)	7025902A12	7025902A12	Clip, Fuser, F101 (2 Rec'd)
702590301	702590301	Bracket, Side, Right-Hand (DS3000, 3003)	702590301	702590301	Bracket, Side, Right-Hand (DS3000, 3003)	702590301	702590301	Bracket, Side, Right-Hand (DS3000, 3003)	702590301	702590301	Bracket, Side, Right-Hand (DS3000, 3003)
702590302	702590302	Bracket, Side, Left-Hand (DS3000, 3003)	702590302	702590302	Bracket, Side, Left-Hand (DS3000, 3003)	702590302	702590302	Bracket, Side, Left-Hand (DS3000, 3003)	702590302	702590302	Bracket, Side, Left-Hand (DS3000, 3003)
58R2694A01	58R2694A01	Adapter, Adjusting Control Magnet, Yoke, Flexible Soft Core	58R2694A01	58R2694A01	Adapter, Adjusting Control Magnet, Yoke, Flexible Soft Core	58R2694A01	58R2694A01	Adapter, Adjusting Control Magnet, Yoke, Flexible Soft Core	58R2694A01	58R2694A01	Adapter, Adjusting Control Magnet, Yoke, Flexible Soft Core
58R2694A02	58R2694A02	Magnet, Yoke, Non-Fluxable Hard Core	58R2694A02	58R2694A02	Magnet, Yoke, Non-Fluxable Hard Core	58R2694A02	58R2694A02	Magnet, Yoke, Non-Fluxable Hard Core	58R2694A02	58R2694A02	Magnet, Yoke, Non-Fluxable Hard Core






3. RC MODIFICATIONS

3.

Changes indicated on right hand page, the circuit card corresponds to the one shown on page 22.

- 1) C416 replaced by 0.012  $\mu$ F
- 2) C243 replaced by 4.7 nF/1 kV
- 3) Potentiometer replaced by resistance 100 K






### Monitor Circuit Card Layout – Component Side

Changes indicated on right hand page, the circuit card corresponds to the one shown on page 23.

- 1) T402, pin 5                    - connected by resistance 330E in series  
   Q201, emitter                with diode 1N914
- 2) R204 adapted with resistance 91E in parallel
- 3) R203 adapted with resistance 62E in parallel
- 4) R201 removed



## Monitor Circuit Card Layout – Solder Side



## RETURN LETTER

Title: MON503 - Monitor  
Technical Manual

RCSL No.: 44-RT2050

A/S Regnecentralen af 1979/RC Computer A/S maintains a continual effort to improve the quality and usefulness of its publications. To do this effectively we need user feedback, your critical evaluation of this manual.

Please comment on this manual's completeness, accuracy, organization, usability, and readability:

---

---

---

---

Do you find errors in this manual? If so, specify by page.

---

---

---

---

How can this manual be improved?

---

---

---

---

Other comments?

---

---

---

---

---

Name: \_\_\_\_\_ Title: \_\_\_\_\_

Company: \_\_\_\_\_

Address: \_\_\_\_\_

Date: \_\_\_\_\_

Thank you

..... Fold here .....

..... Do not tear - Fold here and staple .....

Affix  
postage  
here

 **REGNECENTRALEN**  
af 1979

Information Department  
Lautrupbjerg 1  
DK-2750 Ballerup  
Denmark