SYSTEM BUS CABLING, INTERNAL

1.CPU



1050:CBL815 (Bus Out)

1010:BCU802 + BTU803

2.CPU



1050:CBL815 (Bus Out)

1010:CBL816 (Bus In)

3. and 4. CPU: same cabling as 2. CPU

I/O



1050:CBL816 (Bus In)

1010:CBL815 (Bus Out)
or
BTU802 + BTU803

SYSTEM BUS CABLING, EXTERNAL

Connect external System Bus Cable,CBL905, from 1.CPU CBL815 (Bus Out) to 2. CPU, CBL816 (Bus In) etc.