RCSL No:	31-D690
Edition:	April 1983
Author:	Torben Steen Hansen

Title:

OPERATING SYSTEM s Basis System Version 2 Reference Manual



RCSL No 42-i 2164

Keywords:

RC8000, basic operating system, catalog initializing, s-user catalog, basis system version 2.

Abstract:

This manual describes the function of the basic operating system s, and the functions of the commands used for initializing the backing storage system. Further a description of s-user-catalog is given.

(114 printed pages)

Copyright © 1983, A/S Regnecentralen af 1979 RC Computer A/S

Printed by A/S Regnecentralen af 1979, Copenhagen Users of this manual are cautioned that the specifications contained herein are subject to change by RC at any time without prior notice. RC is not responsible for typographical or arithmetic errors which may appear in this manual and shall not be responsible for any damages caused by reliance on any of the materials presented.

FOREWORD

First edition: RCSL No 31-D455.

The major changes, compared to the version described in "RCSL No 31-D300: MONITOR3", are the introduction of a usercatalog (processes may be created by the JOB-command with prespecified claims) the initializing commands and the lock/unlock facility to prevent/reestablish the use of ALL and NEW commands, from other consoles than the mainconsole or privileged consoles.

Palle Andersson

A/S Regnecentralen, January 1979

Second edition: RCSL No 31-D595.

The major changes in this manual compared to RCSL No 31-D 455 are the inclusion of the corrections described in RC Information Note NCJ 790715 "Corrections to s Reference Manual", and some corrections in the examples in use of usercat.

Further the prio command has been changed:

The priority is now a parameter in the console buffer, and the prio command merely sets this parameter. The create command will then set the priority when the process is created. It is also possible to set the priority in the jobspecification in Susercat. The remarks about the priority are valid from monitor release 6.0. In previous releases the prio command works as described in the RC Information Note NCJ 790715, "Corrections to s Reference Manual".

Henrik Sierslev A/S REGNECENTRALEN af 1979, May 1980

i

Third edition: RCSL No 31-D643.

The major changes in this manual are the introduction of five new commands to s and the two parent messages finis and replace. These changes are valid from monitor release 7.0.

It is now possible to let s read commands from a bs area instead of the console, and it is possible to set primary input in an internal process causing FP to start immediately reading commands.

Henrik Sierslev A/S REGNECENTRALEN af 1979, May 1981

Fourth edition: RCSL No 31-D690.

The major changes in this manual are the introduction of four new commands to s and one new parent message.

Further the reading of commands has been changed. In some cases s will accept more than one line of commands without being selected for input before each command line is entered.

Once a disckit has been used with monitor release 9.0 it is not possible to use it with an older monitor release unless all the logical discs on the disckit have been properly excluded from the monitor 9.0 backing storage system, see section 3.4.

This manual includes those parts concerning the operating system s in RC Information Note HSI 820315: "Changes in Monitor Release 8.0" and RC Information Note TSH 830215: "Changes in Monitor Release 9.0".

The manual is valid from monitor release 9.0.

Torben Steen Hansen A/S REGNECENTRALEN af 1979, January 1983

ii

1

...

٦.	BASI	SIC OPERATING SYSTEM FUNCTIONS		
	1.1	Introduction	1	
	1.2	Handling of Consoles	2	
	1.3	Console Description	3	
		1.3.1 Explanation of Command Mask	4	
		1.3.2 Use of Console Descriptions	5	
	1.4	Some Important Commands	6	
	1.5	Relocation of Processes	6	
	1.6	The Command Language	7	
	1.7	s and FP-Commands in the same File	8	
	1.8	Alfabetic List of the Commands for Handling of		
		Internal Processes	10	
	1.9	Miscellaneous	59	
2.	MESS	AGES FROM s	60	
	2.1	Console Messages	60	
	2.2	Child Messages	62	
3.	ALFA	BETIC LIST OF COMMANDS FOR INITIALIZATION OF THE		
	CATA	LOG SYSTEM	65	
	3.1	Introduction	65	
	3.2	Description of the Commands	65	
	3.3	Examples of Using the Initializing Commands	81	
		3.3.1 Initializing of a New System from Magtape	81	
		3.3.2 Normal (Daily) Start with a New Specific		
		Maincatsize	82	
		3.3.3 Normal Start, but Maincatalog is not on the		
		'First' Oldcatdevice	83	
	3.4	How to Change to an Older Monitor Version	83	
4.	SURV	EY OF S COMMANDS	84	
	4.1	Commands for Handling of Internal Processes	34	
	4.2	Commands for Initialization of the Catalog System .	85	
5.	PROG	RAM SCATOP	87	

iii

TABLE OF CONTENTS (continued)

PAGE

*

-

APPENDICES:

A.	REFERENCES	99
-		1.00
в.	BACKING STORAGE	100
	B.1 Representation of Scope	101
c.	LOGICAL STATUS BITS	104

BASIC OPERATING SYSTEM FUNCTIONS

The functions of the basic operating system s, which can initiate and control the execution of parallel programs on request from terminals/consoles (in the following called consoles), are described.

1

1.1 Introduction

After initial system loading, the internal store contains the monitor and the basic operating system s, enabling operators to initiate and control internal processes from consoles. In addition, s can name peripherals as for instance magnetic tape.

s may be the "pater familias" of a family tree of internal processes. Initially s owns all system resources, such as core storage, backing storage, peripherals, message buffers, process description tables etc. Apart from being the initial process in the system, s has no special status, and it is treated as any other internal process. It is possible to replace s with another operating system.

Each process running under s has its own primary storage area, where the user may execute programs just as he pleases. This is sometimes an advantage in industrial process control, for example, as the user can run a supervisor program without being swopped out.

1.1

The following figure shows the layout of the primary store with s as the sole operating system in the computer.



The s command language is used to describe the resource requirements of an internal process and to create and control the process from a console.

For each console or terminal communicating with s, it maintains a console description containing the parameters to be used in the creation and control of the process, for example it contains the name of the process. Parameter values are assigned explicitly by means of commands.

1.2 Handling of Consoles

Commands to s are served sequentially in the order of their arrival. The processing of a line of commands is either terminated by a short reply or by asking for more input, depending on which commands s has processed.

A line of commands to s is processed from left to right, one command at a time. If syntax errors or other errors are detected during the processing of a line, an alarm is issued and a possible rest of the line is skipped. However s will ask for more input if necessary.

For every command session with s you perform

att s
<one or more command lines>

If one of the commands get, all or new has been used and none of the commands run or start have been issued on the same command line, s will send an input message to the console (i.e. the command session will continue).

s will continue sending input messages to the console until one of the commands start or run have been executed, or an inputmessage has not been returned within one minute, or another process is selected for input.

The monitor permits simultaneously input of messages from all consoles. The operating system, however, can only respond to a limited number of messages. The maximum number of simultaneous console action within s is an option defined in the assembly of the monitor with s.

1.3 Console Description

For each console communicating with the operating system, s maintains a description defining the parameters to be used in the creation of an internal process with the console as primary input and primary output (see ref. 1). This is done by means of a common consolebuffer pool. The size of this pool is an option to the monitor. 1.3

A console description is initiated by means of commands to s.

The parameters referred in this paper are listed below together with their type. The type describes what may be stored in each field. The meaning of type are: string \sim max 11 characters; integer \sim -8388608 <= number < 8388607; integer pair \sim 2 integers; short integer \sim 0 <= number <= 4095.

3

parameter name:

process name string first address integer top address integer buffer claim short integer area claim short integer internal claim short integer function mask short integer max interval integer pair standard interval integer pair user interval integer pair process size integer program name string short integer priority first logic address integer integer cpa. short integer mode primary input (FP) short integer, name primary output (FP) short integer, name

and for each possible bs-device

temp	segments	1. device	integer
temp	entries	1. device	integer
perm	segments	1. device	integer
perm	entries	1. device	integer
6 9			
perm	entries,	n. device	integer

1.3.1 Explanation of Command Mask

The command mask is a bit mask in the console buffer. It consists of two parts. A part defining the allowed s command from this console type (i.e. predefined or consolepool), and a part, used for signalling between commands, the command bits.

4

type:

1.3.1

Format of command mask:

1 1 shift 10 ; command bit : all bs resources. 2 1 shift 9 ; mode, modify, print, date. 3 1 shift 8 ; job, start, stop, break, dump, list, max, remove, proc, prog, load, i, o, get, unstack. 4 1 shift 7 ; include, exclude. 5 1 shift 6 ; size, login, user, project, prio, base, relocate. 6 1 shift 5 ; addr, function, buf, area, internal, bs, temp, perm, all, call, cpa. 7 1 shift 4 ; new, create, run, init. 1 shift 3 ; privileged console. 8 9 1 shift 2 ; command bit : mode = 0 1 shift 1 ; command bit : absolute address. 10

bit 2 - 8 are generated as options to the system and cannot be altered.

bit 1, 9 and 10 can be used in connection with a job in susercat (see chapter 5).

1.3.2 Use of Console Descriptions

1.3.2

The content of a console buffer used in the communication with s is undefined when the communication is finished, i.e. it is not (always) possible to do for example:

Att s job tsh . . Att s remove run

But in some cases it is possible to do it anyway. When a command session is started, s will try to select a console description which has been used in an earlier command session with that particular console. If one is not found a free console description

5

is selected. This will only happen the first time a session is started after an autoload or after the link to the console has been released or when s has used the console description in a command session with another console. The latter can only happen if the number of consoles which can be connected at any time, is greater than the number of console descriptions in s (which is an option to s).

1.4 Some Important Commands

Three commands to s, initializing the whole set of console parameters, exist: 1.4

1.5

The <u>new</u> command using some standard values, the <u>all</u> command, searching and using the maximum available resources, and the job command, searching a file named "susercat" in order to find suitable values to insert into. The job command will also create, load and start an internal process according to the parameters found. These three commands are followed by a string to be used as process name.

The <u>run</u> command will create, load and start an internal process according to the console description. The <u>stop</u> command will stop a running process without removing it. The process may be restarted by means of the start command. The <u>start</u> command will restart a stopped process. The process may either have been stopped by means of the stop command or by "itself", for instance after having requested a magnetic tape.

The remove command will stop and remove an internal process.

All commands are described in section 1.8 below.

1.5 Relocation of Processes

It is possible for s to relocate a process when it is created.

6

If the core size is greater than 1,000,000 halfwords, s will as default relocate all processes to first free address (first address of the first process created by s).

The default relocation is controlled by the privileged command autorel. A process which lets its children refer to addresses inside its own core area should not be relocated, as the addresses delivered by the parent will be logical addresses in the parent's process but will be referred to as physical addresses by the children.

The relocation of a process is controlled by the command relocate.

1.6 The Command Language

A command line to s is one line which can be empty or contain a number of commands. A line is either terminated by a new line character or by semicolon followed by a comment consisting of any string of characters terminated by a new line character. The commands in a message may consist of one or more of the following syntactical elements:

<separator>::= <space> |.|,|/|=|<separator><SP>
<space>::= <SP>|*
<unsigned number>::= <digit>|<unsigned number><digit>
<radix>::= <unsigned number>
<radix number>::= <radix>:<unsigned number>
<radix number>::= <radix>:<unsigned number>
<number>::= <unsigned number>|- <unsigned number>
<number>::= <letter> {<letter> {<letter> {<letter> {</letter> {</letter} {</letter

A command consists of a command word possibly followed by one or more parameters.

Command words and parameters are separated from each other by a separator. In the syntactical definition of the commands in section 1.8 below, separators are not shown explicitly. It must be understood that a definition like the following

temp <devicename><segment><entries>

strictly speaking means

temp <separator><devicename><separator><segments><separator><entries>

1.7

1.7 s and FP-Commands in the same File

It is now possible to have both s and FP-commands in the same file, provided the following rules are followed:

All lines with s-commands must start with "*". All s commands must precede all FP-commands. The file must have bases corresponding with the rule for the s-command used to start the execution of the commands in the file, i.e. if the command read <file> is used, the file must be on system base. If the parent messages newjob or replace are used, the file must be visible from the sending process.

Example:

A file named file could have the following contents:

	;first all s commands
*get pip	;get the jobdescription of pip in susercat
*i.4. file	;tells FP to read commands from this file.
*run	7
*unstack	; important: tells s to stop reading from this
	;file
lookup a	;start of FP-commands.
i fileone	;
•	

8

If the execution is started by the s-command read file, file must have maximum bases (required by the read command).

If the execution is started by means of the parent message newjob or replace, the file must be visible from the sending process (required by the parent messages) and from the process pip (required by FP).

Addr Command

Syntax: addr <first storage address>
 <first storage address>::= <unsigned number>

The console parameter first address is defined and used in a possible subsequent creation of an internal process. An odd number is decreased by one.

Example: addr 16320

ģ

All Command

Syntax: all <process name> <process name>::= <name>

First the console parameter process name is defined by the parameter to the all command. Next all the other console parameters are initiated by setting the name "fp" into the console parameter program name, and the maximum of s's rest claims into the remaining parameters. The core size used is the greatest free consecutive core area found. Notice that the values may be redefined (diminished) by means of commands defining only a few parameters (except the bs claim commands temp and perm). The bases (max, standard, user) are set to the standard base of s.

After this command s expects more input to come and will start a continuous reading from the console until one of the commands run or start is executed. Is the input not given within one minute, or is another process selected for input, the continuous reading will be cancelled.

Example: all us

Area Command

Syntax: area <area claim> <area claim>::= <unsigned number>

The console parameter area claim is defined. This defines the number of available area processes.

Example: area 20

If the job wants to communicate with 20 backing storage files at the same time, it will need 20 area processes. Autorel Command

Syntax: autorel { yes no <first logic address>}

<first logic address>::= <unsigned integer>

(privileged consoles only).

Controls the default relocation of all the processes created under s.

Autorel yes causes s to relocate all processes created hereafter to the first free address i.e. top address of s' own code.

Autorel no causes s to cancel the relocation of all processes created hereafter.

Autorel <first logic address> causes s to relocate all processes created hereafter to the specified value.

Example: autorel no

Base Command

Syntax: base <number><number>

Assigns the number pair to the console parameters max interval, standard interval and user interval.

Example: base -100 200

Break Command

Syntax: break

Stops the execution of the internal process, defined by the console parameter process name, stores its registers and the interrupt cause 8 at the head of its internal interrupt procedure ("break sequence"), and restarts the process in its interrupt procedure (see ref. [1]).

Example: break

Bs Command

The claims of the (already created and possibly running) process defined by the console parameter process name are increased by the (possibly negative) amount given by entries and segments for all keys on the backing storage given by bs device name.

Example: bs disc2 1500 20

The claims on disc2 will be increased with 20 entries and 1500 segments for all perm keys.

Buf Command

Syntax: buf <buffer claim> <bufferclaim>::= <unsigned number>

The console parameter buffer claim is defined. This defines the number of available message buffers.

Example: buf 14

If the job has 14 data transfers (or other I/O operations) going on simultaneously, it will need 14 message buffers.

Call Command

Syntax: call $\left\{ \text{ <device number> <device name>} \right\}_{1}^{*}$

<device number>::= <unsigned number> <device name>::= <name>

Assigns names to a sequence of peripheral devices. The devices must not be reserved by internal processes.

Example: call O=reader 10=magtape 5 printer

Cleanup Command

Syntax: cleanup

(privileged consoles only).

Stops and removes all internal processes created under s.

For each process bs-claims in "susercat" is adjusted, if the process was created by means of the job-command.

Example: cleanup

Cpa Command

Syntax: cpa <cpa value>

<cpa value>::= <unsigned number>

Sets the console parameter cpa to the value given in the call.

If the value equals 0 the cpa register of the internal process will be set to the top address of the last monitortable.

If the value equals 1 the cpa register of the internal process will be set to the top address of the primary storage.

If the value is greater than 7 the cpa register of the internal process will be set to the specified value.

Default value of the cpa register is top address of the process allowing the process to read in the whole primary storage below its own top address.

Example: cpa 0

Will set the cpa register, of the internal process to be created, to the topaddress of the last monitortable.

Create Command

Syntax: create

Creates an internal process as described by the console parameters.

If the addr command has been used, the availability of the storage area is checked. Otherwise s scans the store from the low address end and chooses the first available core area of sufficient size.

If mode=0 has been used the write limits in the process description is set to maximum, allowing the process to write in the whole storage, else the write limits will equal the storage area found above.

The ability of s to supply the specified claims is checked. After the creation s assigns the backing storage claims and sets the priority of the process. The process is included as a user of a standard configuration of peripherals (but not as user of temporary links, except the link to the console from which the process is created, see section 1.9).

The registers of the process are initialized as required by ref. [2].

The catalog base of the process is the standard (login) base.

Example: create

Date Command

Syntax: date <year><month><day><hour><min><sec>
 <year>::= <digit> <digit>
 <month>::= <digit>|<digit> <digit>
 <day>::= <digit>|<digit> <digit>
 <hour>::= <digit>|<digit> <digit>
 <min>::= <digit>|<digit> <digit>
 <sec>::= <digit>|<digit> <digit>
</or>

Sets the internal clock of the monitor to the value given in the call.

If the main catalog has not yet been defined, s will continue with the "oldcat" command.

Example: date 81.05.10 9.30.0

Dump Command

Syntax: dump <dump area> <dump area>::= <name>

The process defined by the console parameter process name is stopped (if not already stopped) and its core area is copied to the dump area. If the size of the dump area is not sufficient, only the first part of the core area is copied. The dump area must be visible from the catalog base of the internal process.

Example: dump image

Exclude Command

Syntax: exclude { <device number> } {* } 1 <device number>::= <unsigned number>

The (already created and possibly running) process, defined by the console parameter process name is excluded as a user of a sequence of peripheral devices.

Example: exclude 5

Function Command

į

The console parameter function mask is set to contain ones in the selected bits. The rest is set to contain zeroes.

Example: function 4 5 6

Get Command

Syntax: get <process name> <process name>::= <name>

Searches the systemfile "susercat" for an entry with the given process name and initializes the console description according to the entry, but unlike the job command, no process is created.

> Example: get student run,

will be the same as

job student

As the i and o commands are not implemented in susercat, you may instead use

get student i 4 input run

After this command s expects more input to come and will start a continuous reading from the console until one of the commands run or start is executed. Is the input not given within one minute, or is another process selected for input, the continuous reading will be cancelled.

The entry in "susercat" describing the job, will not be updated when the process is removed.

26

I Command

Sets the console parameter primin to the parameters given in the call. At load time the registers of the created internal process are set as required by ref. [2], causing FP to select the given name as primary input.

Example: new jobl i 4. input run

FP will select the area (kind=4) "input" as primary input.

If FP is reinitialized, maybe because of a syntax error, FP will start reading from the beginning of the input file. The private modebits, however, will not be changed, so the following commands will prevent FP from looping:

> if mode.l yes finis mode.l yes

Include Command

Syntax: include { <device number>}
1
<device number>::= <unsigned number>

Includes the (already created and possibly running) process, defined by the console parameter process name, as a user of a sequence of peripheral devices.

Example: include 6 7

Init Command

Syntax: init

This command has the same effect as a create command followed by a load command.

Example: init

Internal Command

Assigns a number to the console parameter internal claim.

Example: internal 2

A job will only need internal processes if it acts as an . operating system.
Job Command

Syntax: job <process name> <process name>::= <name>

Searches the system file "susercat" for an entry with the process name given. If the entry is found, the console description is initialized according to the entry, and a process is started by means of the functions implementing the create, the load and the start commands in the order mentioned.

Example: job student

List Command

Syntax: list

Prints a list of all internal processes having a parent.

Each process is described on one line with the format:

<process name><first storage address><size of storage area> <priority><stop-count><state><parent name>

Example: list

÷

Load Command

Syntax: load

Loads the program defined by the console parameter program name into the beginning of the internal process defined by the console parameter process name.

The program must be located on the backing store, and be described as a catalog entry with a positive size and content key (see ref. [1]) must be 3 or 8.

A possible area process for the entry must not be reserved. The number of halfwords to load and the relative entry point of the program must not exceed the size of the internal process. The program must be visible from the catalog base of the internal process.

After loading, the registers are set as required by ref. [2], and the instruction counter is set to the absolute address corresponding to the relative entry point. The catalog base of the internal process is set to the user base, given in the console description.

Example: load

Lock Command

Syntax: lock

(privileged console only)

When this command has been used, it is only possible to use the following commands from a non privileged console:

break dump i job list load max o proc prog read remove start stop unstack

Example: lock

Login Command

Syntax: login <ll standard base> <ll standard base>::= <number> ::= <number>

Assigns the number pair to the console parameter standard interval. This usually defines the temp scope in the sense of "File Processor".

Example: login 1025 1025

Max Command

Syntax: max

Prints the maximum of certain available resources with the format:

max <max storage area><buf claim><area claim><internal claim>

Example: max

Mode Command

Syntax: mode <integer>

If integer = 0 the internal process is allowed to write in the whole primary storage. If integer <> 0, the process can only write in its own storage area.

Default is mode <> 0

Example: mode 0 - : mode 1

Modify Command

Syntax: modify <address><old contents><new contents> (privileged console only)

This command changes the word with address <address> to <new contents> if <old contents> is the present contents of the word.

Example: modify 29276 30 34

Example: modify 29314 8:24700014 8:24300014

This command changes word 29314 from rl.w3 8:14 to rl.w1 8:14.

New Command

Syntax: new <process name> <process name>::= <name>

First the console parameter process name is defined by the parameter to the new command. Then all the other console parameters are initiated by setting the name fp into the console parameter program, and some standard values into the remaining parameters.

Example: new me

The most commonly used standard values are:

priority	0
no. of message buffers	7
no. of area processes	6
no. of internal processes	0
function mask (octal value)	7440
core size	12800
perm entries on work device	
perm segments on work device	800
standard work device	<:disc:>
all base values	8388605

When this command has been executed, s expects more input to come and will start a continuous reading from the console until one of the commands run or start is executed. Is the input not returned within one minute, or is another process selected for input, the continuous reading will be cancelled. 0 Command

Sets the console parameter primout to the parameters given in the call.

At load time the registers of the created internal process are set as required by ref. [2], causing FP to select the given name as primary output.

Example: new job1 o 8 sub010 run

The terminal "sub010" is selected for output.

Perm Command

Searches the monitor for a backing storage device with the stated name. Then the console parameters for permanent claims for that device are defined. The stated values are added to the temp claims for the device.

Example: perm disc1 1500 20

Print Command

Syntax: print <first storage><last storage>
 <first storage>::= <unsigned number>
 <last storage>::= <unsigned number>

Reserves the device named printer and prints the contents of the core storage starting with <first storage>. The printing ends when last storage has been passed after printing at least one word, or the current word is outside core store, or the printer could not be used properly (e.g. because of endpaper or because the printer was reserved). Then the printer is released.

The format of the printing is:

<address decimal><word decimal><halfword 1 decimal><halfword 2 decimal><word octal><word text>

Example: print 10246 10700

Prio Command

Syntax: prio <short integer>

The console parameter priority is set to the value given in the call.

Normally a process will be created with priority 0, which is the highest possible priority of an internal process.

(

Proc Command

Syntax: proc <process name> <process name>::= <name>

Assigns a name to the console parameter process name. It may for instance be used as a preample to commands like include, exclude, start etc.

Example: proc him start proc me

This sequence may for instance be used by the main operator (sitting at a privileged console) after having mounted and called a magnetic tape. After having started the waiting process, the operator reinserts the name of his own process in the console description.

Prog Command

Syntax: prog <program name> <program name>::= <name>

Assigns a name to the console parameter program name.

Example: prog batchsystem

Project Command

Assigns the number pair to the console parameter max interval. This defines the scope project in the sense of the "File Processor".

Example: project 0 2000

Relocate Command

Syntax: relocate { no <first logic address>

Relocate yes causes s to set the console parameter "first logic address" to first free address i.e. to the top address of s' own code.

Relocate no causes s to cancel the automatic relocation of the process, independent of a previous use of the autorel command.

Relocate <first logic address> causes s to set the console parameter "first logic address" to the specified value.

Example: relocate 100000

Remove Command

Syntax: remove

Stops and removes an internal process defined by the console parameter process name. The console must be either the console from which the process was created or a privileged console. Note that the console parameters are unchanged. If the process is created by means of the job-command, the description of the permanent bsclaims in "susercat" belonging to the process is adjusted.

Read Command

Syntax: read <area name> <area name>::= <name>

Causes s to stack the current input pointer and start reading commands from the bs area. The last command must be "unstack" which will cause s to restore the previous input pointer and continue the command reading from there.

The area must be visible from the catalog base of s.

The stack depth is an option to s. Default is stack depth = 2, i.e. it is allowed to have one read command in an area.

Example: read pip

where pip contains

all fut run unstack,

will be the same as the command line

all fut run

When reading commands from a bs-area certain kinds of errors will not terminate the execution of commands, see section 2.1. Replace Command

Syntax: replace <area name> <area name>::= <name> (privileged consoles only)

The area must contain an independent program (contents key = 8). This program is loaded replacing the code of s (see ref. [1]).

The area must be visible from the catalogbase of s.

Run Command

Syntax: run

The run command has the same effect as a create command followed by a load command and a start command.

Causes s to stop sending input messages to the console.

Example: run

Size Command

Assigns a number to the console parameter size of storage area. An odd number is decreased by one.

Example: size 20000

Start Command

Syntax: start

Starts the execution of an internal process defined by the console parameter process name.

The console must be either the console from which the process was created or a privileged console.

Causes s to stop sending input messages to the console.

Example: start

Stop Command

Syntax: stop

Stops the execution of an internal process defined by the console parameter process name. The console must be either the console from which the process was created or a privileged console.

Example: stop

Temp Command

Syntax: temp <bs devicename><segments><entries>

<bs devicename>::= <name>
<segments> ::= <unsigned number>
<entries> ::= <unsigned number>

Searches the monitor for a backing storage device with the given name. Then the console parameters for temporary segments and entries for that device are defined.

Example: temp disc2 1500 3

Unlock Command

Syntax: unlock (privileged console only)

Will establish the use of the commands excluded by the lock command.

Example: unlock

Unstack Command

Syntax: unstack

Causes s to continue reading commands from a previously stacked input source. If no input source is stacked, the command will be blind.

Input will be stacked by the read command. The stack depth is an option to s. Default is 2. User Command

Syntax: user <11 userbase>
 <11 userbase>::= <number>
 ::= <number>

Assigns the number pair to the console parameter user interval. This usually defines the user scope in the sense of "File Processor".

Example: user 1025 1035

1.9 Miscellaneous

When s creates a process the new process will not be included as user of temporary links except the link to the console from which it is created. When s later removes the process the link to the console normally will be removed.

2. MESSAGES FROM s

2.1 Console Messages

When a command session is successfully finished the operating system prints the reply:

ready

If an error is detected during processing of a command, an error message is displayed. If the operating system is executing commands entered from a console the rest of the command line will be ignored, but if necessary an input message will be sent to the console (see section 1.2). If the operating system reads commands from a bs-area, some kinds of errors will allow the execution of commands to continue.

The following is a list of error messages printed by the operating system. An '*' indicates that the error will not terminate the processing of commands when s reads from a bs-area:

error message:	meaning:
area error	input/output error during area loading or the print-command is trying to print a word outside corestore
area reserved	area reserved by another process
area unknown	area not described correctly in catalog or area name incorrect
base illegal*	incorrect use of the bases remedy: examine your use of the project, user, login- and base-command
bs claims exceeded*	bs claims not available; the process is removed remedy: create the process with "smaller" claims

2.

2.1

bs device unknown* device name does not exist remedy: examine your use of the bs-command

catalog error input/output error during catalog lookup or catalog system not initialized

device reserved* device reserved by another process remedy: wait until the device is not reserved

device unknown* device number does not exist remedy: use the correct device-number

illegal cpa the specified value was negative or in the range 2-7 or greater than the top address of the internal storage.

illegal relocation* the logical address space of the process is not within the max physical address space 0-8388606 remedy: use the relocate command to change the logical address space

input aborted the buffer from the console has been received with an abnormal status remedy: send the command line to s once more

name unknown name does not exist in "susercat" remedy: create an entrance in "susercat" with the given name

no areas* area process description not available remedy: use the area-command

no buffers* messages buffers not available remedy: use the buf-command

no core*	storage area not available remedy: use the size-command
no entries in maincat*	the number of temporary entry claims are not available in the main catalog remedy: create the process with less temporary entries
no internals*	internal process descriptions not available remedy: use the internal-command
not allowed	command forbidden from this console, sys- tem under initialization or state of pro- cess does not permit this command
not implemented	optional command not assembled
process unknown*	process does not exist remedy: use the proc-command
prog name unknown*	the program name is not visible from the catalog base of the internal process remedy: examine your use of the user- and base-commands
program too big*	program size or entry point exceeds primary storage area remedy: use the size-command
syntax error	illegal command syntax

2.2 Child Messages

Format of a parent message (a message sent from a child to the

2.2

When the operating system receives a parent message, the following is done:

a) If the waiting bit is equal to one (bit No 23 in the first word of the message) then the child process is stopped, an answer is sent to the process and a message is printed on the console from which the process was created:

pause <processname><text>

The operator can now start, break, or remove the process depending on the function in the message.

b) If the waiting bit is equal to zero, then an answer is sent to the process, and a message is printed on the console from which the process was created:

message <processname><text>

Function If function is "finis" (2), s will remove the process. If function is "replace" (10), s will remove the process and start reading from the bs-area specified. If function is "newjob" (12), s returns an answer result=1 and starts reading from the bs-area specified.

The bs-area specified in the "replace" and "newjob" commands must be visible from the calling process.

Pattern Specifies how the message is to be displayed to the operator. The pattern contains seven bits, one to each of the words in +2 to +14 of the message. A bit being one means that the corresponding word should be printed as an integer, otherwise the word is printed as a text portion of 3 characters. Thus 1<11 means that the word in +2 is an integer.

Wait May be zero or one.

For further information see ref [5].

3. ALFABETIC LIST OF COMMANDS FOR INITIALIZATION OF THE CATALOG SYSTEM

The functions of the initializing commands, which can initiate the backing storage, are described.

3.1 Introduction

If you want to overrule the automatic oldcat action, change the maincatsize or name, initialize a new system, change the kitlabel etc., you may use the following commands to the operating system s. These commands can only be used until the first process is created.

The commands may be typed as described in section 1.6, but in contrast to the reaction on 'normal' error messages, see section 2.1, the rest of the command line will not be skipped in case of errors.

3.2 Description of the Commands

AUXCLEAR Command

Syntax: auxclear $\begin{cases} fast \\ slow \\ \end{cases}$ <devno> <lowerbase> <upperbase> {<entryname> }

<devno>::= <unsigned integer> <lowerbase>::= <number>

<upperbase>::= <number>

<entryname>::= <name>

This command includes temporarily, the stated device in the bssystem with anonymous auxcatname and documentname, and possibly with changed device kind (fast/slow). 3.2

3.1

All the stated catalog-entries will be removed from auxcatalog.

The discdrive will be excluded from the bs-system.

Example:

auxclear slow 6 8: 40000001 8388606 catalog auxclear slow 6 -8388607 8388606 catalog

Both of these commands delete the catalog entry with the name <:catalog:> and the interval -8388607, 8388606 from auxcat on device 6.

Errortexts

- a) syntax error
- b) as the KIT-command a.-e.
- c) remove aux entry <entryname> result <integer>

<integer> is explained in the description of the monitor procedure 'remove aux entry' (see ref. [3])

d) as the NOKIT-command
BININ Command

Syntax: binin $\begin{cases} bs \\ mto \\ nrz \\ tro \end{cases}$ <docname> $\{$ <position> $\}_1^*$ <docname>::= <name> <position>::= <unsigned number>

This command reads from the stated device (cf. BININ RCSL No 31-D234).

If the reading is performed from bs/mto/nrz you must as the very first name the device by using the CALL-command.

If tro the paper tape must be ready in the paper tape reader.

<position> indicates:

On disc it is the number of the first segment in the BININ-file.

On magnetic tape it is the filenumber.

On papertape it is irrelevant.

Example:

call 10 systemtape binin mto systemtape 2 3 4 5 6 7 8 9

These commands will name the magnetic tape station and read 8 files from the tape.

Errortexts/Messages

Meaning:

a) modekind illegal

the first parameter is not bs/mto/nrz/tro

 b) <docname> status <logical status bitpattern after input status-bitpattern> (see appendix C)

c)	input	sum	error	sur	n	error	in	SLANG-segment
----	-------	-----	-------	-----	---	-------	----	---------------

d) input size error command segment > 256 words

- e) <command name> syntax illegal command in command error segment
- f) create <entry name> result create entry <> 0 <integer>
- g) change <entry name> result change entry <> 0 <integer>
- h) rename <entryname> result rename entry <> 0 <integer>
- i) remove <entryname> result remove entry <> 0 <integer>
- j) perman <entryname> result permanent entry <> 0
 <integer>
- k) load <entryname> result create area process <> 0
 <integer>
- <entry name> status
 status bitpattern after area
 <logical status bitpattern>
 output (see appendix B)

<integer> is the resultvalue described in the matching monitor procedure (see ref. [3]).

Clearcat Command

Syntax: clearcat

This command releases all discdrives/chaintables/catalogs.

The chaintables on all the discs mounted will be changed so they match the format used in monitor releases older than 9.0. Now the discs can be used with any monitor release (including release 9.0).

Errortexts:

a) delete bs <docname> result <integer>

<integer> is explained in the description of the monitor procedure 'delete backing storage'.

b) delete entries <docname> result <integer>

<integer> is explained in the description of the monitor procedure 'delete entries'.

 $\left\{ \begin{array}{c} \text{fast} \\ \text{slow} \end{array} \right\}_{0}^{1}$ Syntax: kit <new docname> (<new auxcat name> <device number> <new docname>::= <name> <new auxcat name>::= <name>

70

<device number>::= <unsigned number>

This command includes device <device number> in the bs-system with the documentname <new docname> and possibly with changed auxcatname <new auxcatname> and device kind (slow is used in connection with discdrives).

The document name and name of auxiliary catalog will be changed in the kitlabel (i.e. the chainhead).

If the disc drive is switched off, this command is blind.

Example: kit privkit catprivkit slow 8

When the first kit is included in the bs-system, the monitor searches in the corresponding auxcat for an entry describing a maincatalog with the name <maincatname> (see the MAINCAT command). If the entry exists, but the size or no of keys of the catalog has been changed (by use of the MAINCAT command) it will be removed from the auxcat. If the entry does not exist, it will be created with the size (and no of keys) specified by the maincat-command. This entry will be connected as the main catalog.

To indicate inclusion in the bs-system the following text is printed:

<docname> mounted on <devicenumber>

Errorreaction:

In case of an I/O-error when reading from an auxcatalog, the following message will be issued:

KIT

<auxcatalog name> status <logical status bit pattern> <auxcatalog name> segment <segment no>

Entries on that segment will not be included in the bs-system. If it was a parity-error the inclusion will continue with the next segment on that device, otherwise the inclusion of the device will terminate.

In case of a parity error, the automatic startup after initialization of the maincatalog will not take place. It is then possible to kit off the device (by means of the nokit command) and try to repair the aux-catalog by means of the repair-command followed by the kit-command.

If repair of the auxcatalog is selected when a parity error is detected, the following is done: Each non-delete entry in the erroneous segment is written on the console:

entry format (head)

+0:	first slice, keys	5 :	<first< th=""><th>slice>,<keys></keys></th><th>></th></first<>	slice>, <keys></keys>	>
+2:	lower upper base		<lower< td=""><td>limit><upper< td=""><td>limit></td></upper<></td></lower<>	limit> <upper< td=""><td>limit></td></upper<>	limit>
+6:	name	:	<entry< td=""><td>name></td><td></td></entry<>	name>	

where <keys> is namekey*8 + permanent key.

It is then tried to insert the entry in the maincatalog. If the entry is rejected because of chaintrouble (result 5) or nametrouble (result 6), the entry is deleted.

Errortexts:

a) create peripheral process wrkname on <devno> result
 <integer>

<integer> is explained in the description of the monitor procedure 'create peripheral process'.

b) reserve process wrkname on <devno> result <integer>

<integer> is explained in the description of the monitor procedure 'reserve process'.

c) create peripheral process documentname on <devno> result <integer>

<integer> is explained in the description of the monitor procedure 'create peripheral process'.

d) prepare bs on <devno> result <integer>

<integer> is explained in the description of the monitor procedure 'prepare backing storage'.

e) on <devno> status <logical status bit pattern>

I/0 - error. <logical status bit pattern> is explained in appendix B.

- f) <auxcatname> status <logical status bit pattern>
 <auxcatname> segment <erroneous segment no>
 I/O error. <logical status bit pattern> is explained in the Binin-command.
- g) <auxcat-name> status <logical status bit pattern> repair not possible

I/0 - error. <logical status bit pattern> is explained in the Binin-command.

h) insert entry <entryname> result <integer>

<integer> is explained in the description of the monitor procedure 'insert entry'.

i) auxcat to be repaired

j) main catalog not defined no maincat connected catalog error

> use the MAINCAT-command or the KIT-command with the devices in the right order, to remove this errortext.

 k) connect main catalog <maincatname> result <integer> no maincat connected catalog error

<integer> is explained in the description of the monitor procedure 'connect main catalog'.

remove aux entry <maincatname> result <integer>
 no maincat connected
 catalog error

<integer> is explained in the description of the monitor procedure 'remove aux entry'.

- m) create aux entry <maincatname> result <integer> no maincat connected catalog error <integer> is explained in the description of the monitor procedure 'create aux entry'.
- n) (as the NOKIT-command)
 no maincat connected
 catalog error.
- o) (errortext a-i)
 no maincat connected
 catalog error.

p) entry format (head)
+0: first slice, keys: <first slice> <keys>
+2: lower upper base : <lower base> <upper base>
+6: name : <entry name>

(see the errorreaction description).

q) insert entry <entryname> result <integer> entry deleted

<integer> is explained in the description of the monitor procedure 'insert entry'. Only possible after a call of 'repair' and when result is 5 or 6.

r) <auxcatalog name> size trouble - end area at segment <segment no>

The physical size of the auxcatalog does not correspond with the size recorded in the chainhead for that device. The inclusion of the device in the bs-system is terminated. KIT

Syntax: kit {<devicenumber>}^{*} <devicenumber>::= <unsigned number>

This command functions like the former command, with the exception that no fields of the kitlabel (i.e. the chainhead) are changed.

Errortexts:

see the former command

KITLABEL

Syntax: kitlabel <devicenumber> <docname> <auxcatname>

{slow
fast
<catsize> <slice length> <no. of slices>
<catsize>::= <unsigned number>
<slice length>::= <unsigned number>
<no. of slices>::= <unsigned number>

At present: <no. of slices> must be less than or equal to 2046

This command causes the writing of a chaintablehead and an empty auxcatalog on the device stated.

The device will be partially included in the bs-system to prevent unintentional use of the disc-kit.

If you want to use the disckit at once, then use the NOKIT-command followed by the KIT-command.

Errortexts:

intervention on <devno> (i.e. the discdrive was switched off)

and

see KIT

MAINCAT

Syntax: maincat <name of catalog> <size of catalog> or maincat <name of catalog> <no of partitions> <no of keys>

<name of catalog>::= <name> <size of catalog>::= <unsigned number> <no of partitions>::= <unsigned number> <no of keys>::= <unsigned number>

A "partition" is the part of the catalog within which a given entry is allowed to be located. A partition may never exceed 512 segments. No of keys is the number of segments in one partition. Therefore <size of catalog> and <no of partitions> must be greater than 0. <no of keys> must be in the range 1 to 512.

If <size of catalog> is given, <no of partitions> and <no of
keys> will be computed.
<no of partitions> is computed as:
p:= (size//512) + 1
If p is even p is incremented by one.

<no of keys> is computed as k:= size//p

Finally size is computed as size:= k*p

If <no of partitions> and <no of keys> are given, size is simply computed as size:= <no of partitions>*<no of keys>

s will finally write the message:

<name of catalog> size:<size> partitions:<partitions> keys:<keys>

Errortexts:

erroneous number: <number> A nonvalid number was given.

NOKIT

Syntax: nokit <devicenumber>

<devicenumber>:: <unsigned number>

This command releases discdrive/chaintable/auxcatalog from device <devicenumber>.

The chaintables of all logical discs on that device will be changed so they match the format used in monitor releases older than 9.0.

Now the disc can be used with any monitor release (including release 9.0).

Errortexts:

See CLEARCAT

OLDCAT

Syntax: oldcat

This command uses a table from monitor-options with the bs-devicenumbers, to generate a call of the KIT-command.

Example:

If the monitor is generated with bs-device 6, 7 and 8 (in this sequence), the OLDCAT-command is exactly the same as the command KIT 6 7 8.

Errortexts:

see KIT

REPAIR

Syntax: repair

When this command has been performed before a call of the kit or oldcat command, s will try to insert entries on an erroneous aux-catalog segment (caused by parity error) in the maincatalog. It is tried to insert all nondeleted entries on erroneous segments. See the description of the errorreaction in the kit command. It is common to the succeeding examples that the monitor is loaded, and s asks for the date/time but before date/time is written on the keyboard.

3.3.1 Initializing of a New System from Magtape

- Switch off all the dicsdrives. This will make the automatic OLDCAT-action completely blind.
- Type date/time on the keyboard. Now the system is ready for KITLABEL etc.
- 3. Mount relevant disckits and switch on all discdrives. Write a label on the disckits e.g. kitlabel 6 disc catdisc slow 50 21 2045 kitlabel 7 disc1 catdisc1 slow 50 21 2045 kitlabel 22 diablo1 catdiablo1 slow 20 2 1212
- Perform the cleaning after KITLABEL and include the disckits in the system by giving the commands

clearcat maincat catalog 73 (or another size if wanted) oldcat

5. Transfer the standardprograms from systemtape e.g.

call 10 systemtape binin mto systemtape 2 3 4 5 6 7 8 9

Now the system is ready for creation of processes etc.

3.3.1

3.3.2 Normal (Daily) Start with a New Specific Maincatsize

This can be done in several ways.

Either:

- Mount all relevant disckits and apply power to the discdrives.
- Type in date/time on the keyboard. (Now an automatic oldcataction is performed).
- 3. Give the commands:

clearcat maincat catalog 83 oldcat

Or:

- 1. Switch off all the discdrives.
- Type in date/time on the keyboard. (Notice: all discdrives are switched off, therefore the automatic oldcat-action is blind).
- Mount all relevant disckits and apply power to the discdrives.
- 4. Give the commands:

maincat catalog 83 oldcat

Now the system is ready for creation of processes etc.

3.3.3 Normal Start, but Maincatalog is not on the 'First' Oldcatdevice 3.3.3

- 1. Switch off all discdrives.
- Type in date/time on the keyboard (notice: an automatic oldcat-action will be blind).
- Mount all relevant disckits on and apply power to the discdrives.
- 4. If necessary define the size of the maincatalog and include the disckits in the wanted order.

e.g.

maincat catalog 59 (if necessary) kit 7 6 22

3.4 How to Change to an Older Monitor Version

If a monitor older than release 9.0 has to be loaded, all discs which have to be used with the old monitor must be excluded properly from the bs-system. As the maximum size of a catalog has been increased, the format of the chaintable (which describes a logical disc) has been changed. When a disc has been used with monitor release 9.0, the disc will be rejected if it is attempted to include it in a bs-system of a monitor older than 9.0 (it will be rejected with result 5 "illegal chainkind"). When a disc is properly excluded from the bs-system by use of the CLEARCAT or NOKIT commands (or by use of the utility program KITOFF), the format of the chaintable is changed to match older monitor releases if it is possible (i.e. size of the catalog is less than 512 segments).

4.1 Commands for Handling of Internal Processes

If the command is marked with a 'c' or 'p' in the list below, the command acts on the console description or on a process respectively.

	conmand	parameters
С	addr	<first address="" storage=""></first>
С	all	<process name=""></process>
С	area	<area claim=""/>
		(yes)
	autorel	{ no }
		<first address="" logic="">]</first>
С	base	<number> <number></number></number>
р	break	
р	bs	<pre></pre>
С	buf	<pre><buffer claim=""></buffer></pre>
	call	$\left\{ < \text{device number} > < \text{device name} \right\}_{1}^{*}$
	cleanup	
С	cpa	<cpa value=""></cpa>
р	create	
	date	<year> <month> <day> <hour> <min> <sec></sec></min></hour></day></month></year>
	dump	<dump area=""></dump>
р	exclude	$\left\{ < \text{device number} \right\}_{1}^{*}$
С	function	$\left\{ < \text{bit number} \right\}_{1}^{*}$
С	get	<process name=""></process>
С	i	<kind> <name></name></kind>
p	include	$\left\{ < \text{device number} \right\}_{1}^{*}$
р	init	
С	internal	<internal claim=""></internal>
р	job	<process name=""></process>
	list	
p	load	

84

	TOCK	
C	login	<low base="" standard=""> <high base="" standard=""></high></low>
	max	
С	mode	<integer></integer>
	modify	<address> <old contents=""> <new contents=""></new></old></address>
С	new	<process name=""></process>
С	0	<kind> <name></name></kind>
С	perm	<bs device="" name=""> <segments> <entries></entries></segments></bs>
	print	<first storage=""> <last storage=""></last></first>
C	prio	<short integer=""></short>
С	proc	<process name=""></process>
C	prog	<program name=""></program>
С	project	<low maxbase=""> <high maxbase=""></high></low>
С	relocate	yes no <first address="" logic=""></first>
р	remove	
	read	<area name=""/>
	replace	<area name=""/>
р	run	
С	size	<size area="" halfwords="" in="" of="" storage=""></size>
р	start	
р	stop	
С	temp	<bs devicename=""> <segments> <entries></entries></segments></bs>
	unlock	
	unstack	
С	user	<low userbase=""> <high userbase=""></high></low>

4.2 Commands for Initialization of the Catalog System



PROGRAM SCATOP (S-CATALOG OPERATION)

5.

The program is intended for use on operators level for s-usercatalog managing purposes, i.e. initializing the catalog, creating/changing/deleting entries or printing out contents of single entries.

The s-user-catalog is supposed to be placed on an area, named <:susercat:>, and should be present before using the scatop-program.

The program is called with a number of parameters, of which the first determines the action/subprograms to be performed. This first parameter should be one of the following names:

newcat	a new s-user-catalog will be created
insert	creation of an entry is attempted
change	changing of an entry is attempted
delete	deletion of an entry is attempted
print	an entry is attempted printed out
printcat	the usernames in susercat are printed out.

The newcat and printcat action will unconditionally be executed.

If the parameter following the action is a name the action will act upon the hereby named entry (gives no meaning for newcat and printcat). If the parameter is not a name the action will act upon the "entry0" (the catalog-describing entry).

A parameter to any action must be one of the following types:

87

Full Syntax



All actions have in common:

- -- word 0 in an entry, the hashvalue, cannot directly be set or changed, but is managed due to the built in hashfunction.
- -- superfluous parameters are blind.
- -- too few parameters, will be padded up with zero parameters, before the action is executed.

Referring to the format of susercat (see page 94), the detailed interpretation of the parameters in each action will be:

newcat the whole catalog is deleted. The parameters are interpreted strictly sequentially and laid out as entry0 in the catalog from word (+2) and up.

insert the entry named is created and placed in the catalog. The parameters are interpreted and laid out sequentially from word (+2) and up, only the entryname and the succeeding parameter are interchanged to fit the entryformat (see page 94 and example 2).

change changes parts or all of an entry. Every second parameter (after an eventual entryname) indicates a word (= relative halfword address//2) to be changed. The following para-

meter determines the new value to be placed in this word, and succeeding words in case of a name.

- delete the indicated entry will be (marked as) deleted. Parameters given after the entryname has no influence at all. Note that entry0 (fortunately) cannot be deleted by this command.
- print each word in the indicated entry will be printed as one integer word, 2 integer halfwords and 3 characters. Blind, illegal and control characters are printed out as an '*'. Parameters given after the entryname have no influence at all.
- printcat each username included in susercat will be printed out, unsorted. Parameters given after printcat have no influence at all.

Calculation of entry length and 'last used of entry 0'

<last used of entry 0>: as entry 0 has the same length as a job describing entry only a part of the entry may carry information about the devices. 'last used of entry 0' is the last halfword carrying information in entry 0. It can be calculated as

6 + 12 x (no. of devices in susercat)

<entry length>: The length of an entry in susercat. If no. of devices is less than 10 the entry length is calculated as

 $44 + 8 \times (no. of devices)$

else <entry length> equals <last used of entry 0>

To avoid mistakes see to that an area named <:susercat:> is present at all before using the commands. Even before using the new-

cat command an area of this name (no matter the size) should be present.

Some examples (see formats of susercat page 94)

1) scatop newcat 68 42 10 disc 0 0 disc1 0 0 disc2 0 0 creates a new susercat with +2: <entrylength> = 68 halfwords +4: <last used> = 42 (halfwordaddress) +6: <catsize> = 10 segments +8: <name of device 0> = 'disc', padded with zeroes, take up 4 words. +16: <slicelength device 0> +18: <reference> the given values unimpor-

> . and so on, until the parameter list stops, the rest of the entry will be filled with zeroes.

tant, the proper values

will be computed and

inserted.

2) scatop insert japroc 0.0 0 0 6.7 0.1056 0.0 100 200 100 100 20000 FP 100 110 20 1000 20 1000

(Observe that the two first parameters are interchanged, see page 94, hw +2 and hw +4).

An entry named "japroc" is inserted in the catalog. Most values defined by parameters are following the standard claims for a process by "new" command, but three exceptions:

- a) The three bases (std, user and max base) are located to a private interval. (HW +22, +24, +26, +28, +40, +42).
- b) Hw +30 <size> is expanded from normally 12800 to 20000 halfwords.

- c) The bs-claims are somewhat extended as well. (hw +44, +46, +48, +50).
- 3) scatop change japroc 8 4.7 15 15000 16 myprog will change the entry "japroc" by following: word 8 (+16) <buf> changed to 4, <area> left unchanged

4) scatop change 8 42 10 disc2

As no name is indicated as first parameter to change the action is executed upon entry0 (the susercat describing) word 8 (+16) is changed to 42, i.e.

<slice length, device 0> is changed to 42 (there is hardly a reason for making this change)

word 10-13 (+20-26) are changed to contain 'disc2', i.e. the name of device 1 will now be 'disc2'. Note that the <slice length> and <reference> in word 14-15 will not be changed!

- 5) scatop delete japroc The entry with <user name> = 'japroc' is (marked) deleted.
- 6) scatop deleteWill actually be executed, but has no effect at all.
- 7) scatop print japroc The entry with <user name> = japroc will be printed out
- scatop print
 The catalog describing entry0 (no name indicated)
 will be printed out.
- scatop printcat
 All usernames in susercat will be printed out.

10) a job with claims as a "new" process

Scatop insert name 0.0 0 0 7.6 0.1056, 0.0 8388605 8388605 8388605 8388605, 12800 FP 8388605 8388605 0 0 20 800 will correspond to new name run

11) a job with all available bs claims

Scatop insert haps 0.<u>1024</u> 0 0 5.5 0.1056, 0.0 10 20 10 20 10000 FP 10 20

12) Change the job in ex 10 to a job with start adr 60000

Scatop change name 1 0.2 6 60000

Possible errormessages:

Parameter Errors

Preceded by '***scatop: param no <no>:'

Succeded by one of the following:

'action missing' scatop has been called without indication of an action. 'action unknown' the parameter following scatop is not one of the known actionnames.

'unknown delimiter' the parameter has a wrong format.

'too many parameters' the parameterlist is too long.

(the following occurs only when using the change command)

'<integer> index expected'

'index outside entrybounds'

'forbidden field, must not be changed'

an integer was supposed as next parameter, should indicate an index.

the parameter contains an index greater than or equal to the number of words in an entry.

the indicated word cannot be changed by the change command. Try delete followed by insert or create a new susercat.

'one more parameter expected'

after the last index given, a new value to be inserted should follow.

Format of susercat

Entry 0

+ 0		not used	+ 0	<hash value=""></hash>
+ 2		<entry length=""></entry>	+ 2	<prio> <command mask=""/></prio>
+ 4		<last 0="" entry="" of="" used=""></last>	+ 4	<process name=""></process>
6		_ <size catalog="" of=""></size>	б	
8		<name 0="" device=""></name>	8	-
10		-	10	-
12	dev.0	-	12	<first address=""></first>
14		-	14	<work>.<work></work></work>
16		<pre><slice 0="" device="" length=""></slice></pre>	16	<buf> <area/></buf>
18		<reference></reference>	18	<internal> <function></function></internal>
20		<pre>(<name 1="" device="">)</name></pre>	20	working location
22		_	22	<max 11=""></max>
24	dev.1 (-	24	<max ul=""></max>
26		-	26	<std. 11=""></std.>
28		<slice 1="" device="" length=""></slice>	28	<std. ul=""></std.>
30		<reference></reference>	30	<size></size>
32			32	<prog></prog>
34		•	34	-
36		•	36	
38	dev.2		38	_
40			40	<user 11=""></user>
42		•	42	<user ul=""></user>
44		•	44	<entries temp=""></entries>
46		•	46	<segments temp=""> > device 0</segments>
48	dev.3	•	48	<entries perm=""></entries>
50		•	50	<segments perm=""></segments>
52			52	•
54			54	. device 1
56			56	

hashvalue =		-1	empty entry
hashvalue =	-	-2	deleted entry

<reference> points to the start of the claim list for the device in consolebuffer relative to the start of the console buffer.

Number of devices in susercat is installation dependent; standard is all devices.

Explanation of a susercat entry

<hash value>

<command mask>

<prio>

Inserted automatically. See page 90, example 2.

Insert the priority of the process. Corresponds to the prio command.

Only the three bits mentioned under 1, 2 and 3 are used so the standard value of the command mask can be 0.

- 1. if <first address> is set <> 0 add 2 to the command mask
- if you want mode=0 add 4 to the command mask
- if you want "all" bs-resources add 1024 to the command mask

Insert the value 0 except you want the process to start in a specific address. Remember to change the command mask. Corresponds to the addr-command.

Insert the no. of message buffers. Corresponds to the buf-command.

Insert the no. of area processes. Corresponds to the area-command.

Insert the no. of internal processes.

Corresponds to the internal-

<buf>

<first address>

<area>

<internal>

<function></function>	Insert the standard value 1056. Corresponds to the function- command.
<max ll=""> <max ul=""></max></max>	Lower limit of the max base. Upper limit of the max base. Corresponds to the project- command.
<std.ll> <std.ul></std.ul></std.ll>	Lower limit of the standard base. Upper limit of the standard base. Corresponds to the login-command.
<size></size>	Insert the process size in half- words. Corresponds to the size-command.
<prog></prog>	Insert the name fp except you want another program to replace fp. Corresponds to the progcommand.
<user 11=""> <user u1=""></user></user>	Lower limit of the user base. Upper limit of the user base. Corresponds to the user-command.
<entries temp=""> <segments temp=""></segments></entries>	Temporary entries. Temporary segments. Corresponds to the temp-command.
<entries perm=""> <segments perm=""></segments></entries>	Permanent entries. Permanent segments. Corresponds to the perm-command.

.

96

P6

Other Messages

Preceded by '***scatop: ', followed by one of the following:

'entry does not exist' or 'entry exists already'

- xists already' Occurs when the desired action cannot be performed due to one of the given reasons, see the survey in chapter 1.
- 'devi<no> not found in nametabel' During execution of newcat the devicename indicated for device no <no> was not found/known by the system.
- 'catalog full, name not found' Occurs e.g. when the catalog is filled up, and it is attempted to insert a new entry. Delete some entries and insert again, refuse the insertion or create a bigger susercat (and insert all the entries again). Could also occur when e.g. the whole catalog has been searched for an unknown entry. In any case, the operator is warned that the catalog is full (and the name was not found).

'catalog error, hashvalue' This is a hard system error, save a hardcopy of the run and consult the RC support department.

A possible configuration of susercat could be:

Entry 0	Console buffer
•	•
•	•
•	•
+8	•
	•
dev.0	+50 entries/segments
	on first device
+18 <reference></reference>	+56 in entry O
+20	+58 entries/segments
	on second device
dev.1	+64 in entry O
	+66 entries/segments
+30	on second device
+32	+72 in entry 0

dev.2

+42 <reference>

entries/segments on n'th device in entry 0 1 E

In the consolebuffer there are four words for every possible device in chaintable, containing information about permanent/ temporary segments and entries.

REFERENCES

.

2

Α.

- RCSL No 31-D364:
 SYSTEM 3 UTILITY PROGRAMS, Part One
- [2] RCSL NO 31-D379: SYSTEM 3 UTILITY PROGRAMS, Part Three
- [3] RCSL No 31-D697:RC8000 MONITOR, Part Two, Basis System Version 2
- [4] RCSL No 31-D476: RC8000 MONITOR, Part One
- [5] RCSL No 31-D610: Parent Messages in RC8000

B. BACKING STORAGE

Backing storage files are created explicitly by means of the program 'set', but they may also be created implicitly in case an FP-command like 'p=algol' or 'p=edit q' is executed and p does not exist already (or is protected against writing).

A backing store file occupies two kinds of resources: a number of backing store segments and one <u>catalog entry</u>. A file may change length after its creation, thereby occupying more or less segments.

1. Scope

Some files live as long as the user wants, others are cancelled. Some files are only 'visible' to one user, others are visible to all users. Altogether, we distinguish between the following kinds of scope:

Temporary File

A temporary file is cancelled on request of the user, of the autoload function, of the start up of BOSS and in some cases BOSS will cancel a temporary file not in use. A temporary file is visible from all processes with the same login base.

Login Files

A login file is cancelled on request of the user or by start up of BOSS. A login file is visible from all processes with the same login base.

User File

A user file is only cancelled on the request of the user. A user file is 'visible' from all processes created with the same jobname (user base) as when he created the file.

Project File

A project file is only cancelled on the request of a user under the same project base. A project file is visible from all processes with the same project base as when the file was created. в.

System File

A system file may only be created and modified by the maintenance staff. The file is visible from all projects enabling programming.

User, project and system files are named in common as <u>permanent</u> <u>files</u>, because they are never cancelled automatically. When a file is born, it will always start out as a temporary file. Later, the scope of the file may be changed by means of the scope command, which is available as an FP-command.

A login file or a temporary file may be created with the name p even if you already have a user file with that name. When you later refer to p, the login file will be used. If the login file is cleared, the user file will reappear. In the same way, a user file may be created even if a project file with the same name already exists. And finally a project file may be created with the same name as a system file.

B.1 Representation of Scope

Each file in the system is described by an entry in the common file catalog (which itself is a system file). The entry associates a permkey and an interval (the so-called entry base) with the file. The catalog key may be 0, 2 or 3 and defines the 'life time' of the entry. The entry base defines an interval of integers from which the file is visible. Together the permkey and the base define the scope.

A process searching for a file in the catalog will have a <u>catalog</u> <u>base</u> (an interval) from which it looks for visible entries. The result of the lookup will be the file with the name wanted and with the smallest entry base surrounding the catalog base (or equal to the catalog base).

Within certain limits the job may change its catalog base and the entry base of files. To each job is associated 3 limiting intervals specified in the user catalog and defining the access rights B.1

of the job. Typically they appear like this:



The max base, the std base and the catalog base are parts of the process description in the monitor, which maintains these rules: The job may change its catalog base to any interval which is contained in (or equal to) the max base and which contains the std base (or equals it). The catalog base may also be contained in the std base. The job may cancel or modify a file if the job could change its own catalog base to the entry base of the file. Thus files with an entry base outside the max base or adjacent to the std base are protected against the job. Files adjacent to the std base cannot even be read by the job.

Relative to the process, the scopes of files may now be described in this way:

temp files: permkey 0, entry base equals (or is contained in) the std base.

login files: permkey 2, entry base as for temp files.

user files: permkey 3, entry base equals user base.

project files: permkey 3, entry base equals max base.

system files: entry base sorrounds the max base.
Files with permkey 0 or 2 (non-permanent files) cannot be generated with an entry base surrounding the std base, as this would prevent s from distinguishing processes temporary files from other processes. Thus the std bases may never overlap, not even the std base of the maintenance project (which has the largest possible interval as its max base).

A full description of the file system is found in ref. [4].

48

The meaning of the logical status bits is:

- 1 shift 23: <u>Intervention</u>. The device was set in local mode during the operation.
- 1 shift 22: <u>Parity error</u>. A parity error was detected during the block transfer.
- 1 shift 21: <u>Timer</u>. The operation was not completed within a certain time defined in the hardware.
- 1 shift 20: <u>Data overrun</u>. The data channel was overloaded and could not transfer the data.
- 1 shift 19: <u>Block length</u>. A block input from magnetic tape was longer than the buffer area allowed for it.
- 1 shift 18: <u>End of document</u>. Means various things, for instance: Reading or writing outside the backing storage area was attempted, the paper tape reader was empty, the end of tape was sensed on magnetic tape. For further details see the description of External processes (see RCSL 31-D478: External Processes).
- 1 shift 17: <u>Load point</u>. The load point was sensed after an operation on the magnetic tape.
- 1 shift 16: <u>Tape mark</u>. A tape mark was sensed or written on the magnetic tape.
- 1 shift 15: <u>Write-enable</u>. A write-enable ring is mounted on the magnetic tape.
- 1 shift 14: <u>Mode error</u>. It is attempted to handle a magnetic tape in a wrong mode (NRZ or PE).

c.

- 1 shift 13: <u>Read error</u>. Occurs on card reader. See the description of 'External processes'.
- 1 shift 12: Card reject or disc error. Occurs on card reader or disc. See the description of 'External processes'.
- 1 shift 8: <u>Stopped</u>. Less than wanted was output to a file of any kind or zero bytes were input from a backing storage area.
- 1 shift 5: <u>Process does not exist</u>. The document is unknown to the monitor.
- 1 shift 4: <u>Disconnected</u>. The power is switched off on the device.
- 1 shift 2: <u>Rejected</u>. The program may not use the document, or it should be reserved first.
- 1 shift 1: <u>Normal answer</u>. The device has attempted to execute the operation, i.e. '1 shift 5' to '1 shift 2' are not set.



RETURN LETTER

OPERATING SYSTEM s Title: Basis System Version 2 Reference Manual

RCSL No.: 31-D690

A/S Regnecentralen af 1979/RC Computer A/S maintains a continual effort to improve the quality and usefulness of its publications. To do this effectively we need user feedback, your critical evaluation of this manual.

Please comment on this manual's completeness, accuracy, organization, usability, and readability:

Do you find errors in this manual? If so, specify by page.

How can this manual be improved?

Other comments?

Name:	Title:	
Company:		
Address:		
	•	Date:

Thank you

42-i 1288

Fold here

. .

. .

Do not tear - Fold here and staple

. .

. .

Affix postage here



Information Department Lautrupbjerg 1 DK-2750 Ballerup Denmark

IC i	nformation	repl.		ident TSH840706		page	1/13	
				х	RC8000		class	EXT
subj.	CORRECTION TO	RCSL NO.: 31	-D690.	A				
	andra and a state of the state			19/-13		2	N 991	10225

This RC Information Note contains corrections to "Operating System s, Basis System Version 2, Reference Manual" (RCSL No. 31-D690).

1. Page 5.

Add the following commands to the list for command mask bit 1 shift 5:

"connect, disconnect, link, unlink, initkit, linkall"

2. Page 7.

No: 42-i 1321

RCSL

Bottom, insert:

"/closecatopr/connect/disconnect/link/unlink/initkit/linkall"

	information	repl.		ident TSH84()706	page 2/13
				X RC8000		class EXT
ubj.	CORRECTION TO	RCSL NO · 31	-D690		<u></u>	1
			5050.	landalah penangkan apad maninin agi narih terdi dari penangkan di		
	3. Page 19.					
	Bottom, insert	•				
	" 01	C				
	Closecatopr	Command				
	Syntax: clo	secatopr				
	-					
	(privileged	consoles o	nly).			
						1 .
	The core are	ea occupied	by the so	commands i	or initia	liza-
	tion and har	ndling of c	atalogs is	released	and can i	LOW HOW
	on be used i	Jy 5 101 CI	eation of j	JIUCESSES	•	
	and insert:					
	" Connect Comm	nand				
	Suptax: co	nact (name	of mainpr	CREES (t)	vne>	
	Syntax. Con	cm c	or formatte	c> <unit></unit>		no > ¹
					Ĺ	0
	< n .	ame of mair	iprocess> :	:= <name></name>		
	< t :	ype> ::= <u< td=""><td>insigned nur</td><td>nber/</td><td>number</td><td></td></u<>	insigned nur	nber/	number	
		m or format	insigned nu	mber>	IIIIIDEL/	
	< d	evice no> :	::= <unsign< td=""><td>ed number)</td><td>></td><td></td></unsign<>	ed number)	>	
	A connectio	n is create	ed for the	specified	device.	
	The paramet	er 'type' s	specifies t	he kind a	nd type of	the
	device. At	present typ	pe must be	one of th	e followin	g
	kinds:					

	information	repl. i		ident TSH840706			page	3/13
				х	RC8000		class	EXT
subj.	CORRECTION TO	RCSL NO.: 31	-D690.	A				

type	=	0	:	ida disc
		1	:	ida-magtape, model RC3715
		2	:	ida-magtape, model RC8343
		3	:	ida-magtape, model RC8344
		4	:	ifp-general sequential device.

Control module (cm) or formatter defines the (physical) address of the ISI-control module or pertec-interface on the IDA801 adaptor. In case of an IFP-device it defines a sub-kind of the device.

Unit defines the (physical) address of the (disc or tape) unit on the ISI-control module or pertec-interface on the IDA801 adaptor. In case of an IFP-device it defines a subaddress of the device.

Device number defines the RC8000 device number which is going to be used for the connection. It must be a device number of a free IDA/IFP subprocess. If the device number is omitted, a randomly selected free IDA/IFP subprocess is used.

If a connection is made to a disc-unit it will be powered up. In this case the result of the connect operation will be returned when the power up has been finished (takes aprox. 1 minute).

Example: connect idamain 0 1 2 40

1321

No: 42-1

RCSL

The disc unit with device number 2 on control module 1 supervised by ida mainprocess 'idamain' is connected to logical RC8000 device number 40."

E	information	repl.		ident TSH840706	page 4/13
				X RC8000	class EXT
bj.	CORRECTION TO	RCSL NO.: 31	-D690.		
		untere en mer het soch finder den signig und geschlich soch et soch finder at so			
	/				
	4. Page 22.				
	Bottom, inser	t:			
	" Disconnect	command			
	Cuptor, dia	aannaat (d	outoo numb	~ * \	
	Syntax: dis	connect (d	evice numb	el/	
	< d e	vice numbe	r> ::= <u< td=""><td>nsigned number></td><td></td></u<>	nsigned number>	
	m1	1 1			1
	The specifi	ed device	IS disconn	itor is removed	description
	must be an	ida-disc o	r -magtape	device or an i	fp general
	sequential	device.			
	If the devi	ce is an i	da-disc, t	here must not b	e any logi-
	cal disc pr	ocesses cr	eated on t	hat physical di	SC.
	Example:	disconnect	40"		

E	information	repl.		dent TSH840	706	page 5/13
				X RC8000		class EXT
bj.	CORRECTION TO	RCSL NO.: 31-I				
	5. Page 29.					
	Bottom insert	0				
	bottom, insere					
	" Initkit Comm	and				
		1.4.2.1	c	1 1/100 5	<	
	Syntax: init	kit (devno	of physica	*	<size <="" td=""><td></td></size>	
	(46)	no or rogic		0		
	<d ev<="" td=""><td>no of physi</td><td>cal disc></td><td>::= <unsi< td=""><td>gned numbe</td><td>r></td></unsi<></td></d>	no of physi	cal disc>	::= <unsi< td=""><td>gned numbe</td><td>r></td></unsi<>	gned numbe	r>
	<siz< td=""><td>:e> ::= <uns< td=""><td>igned numl</td><td>er></td><td></td><td>$\sum_{i=1}^{n}$</td></uns<></td></siz<>	:e> ::= <uns< td=""><td>igned numl</td><td>er></td><td></td><td>$\sum_{i=1}^{n}$</td></uns<>	igned numl	er>		$\sum_{i=1}^{n}$
	<d ev<="" td=""><td>no of logic</td><td>al disc> :</td><td>:= <unsig< td=""><td>ned number</td><td>//-1</td></unsig<></td></d>	no of logic	al disc> :	:= <unsig< td=""><td>ned number</td><td>//-1</td></unsig<>	ned number	//-1
	A descriptio	on of the di	sc is writ	ten on th	e physical	
	(IDA-) disc	. This descr	iption con	itains inf	ormation a	bout
	the system s	software and	informat	ion about	the logica	1
	discs specif	ied in the	call. For	every log	ical disc	only
	the size is	requested t	o define	the locati	on, as the	
	logical disc	s are place	d in the	order they	are speci	fied
	in the call	. The first	specified	logical d	isc has fi	rst
	segment = 0	, the next h	as first	segment =	start + si	ze of
	the previous	s disc and s	o on.			
	Note that th	he first spe	cified lo	gical disc	specifies	the

autoload part of the disc.

RCSI, No: 42-i 1321

It is possible to specify a RC8000 device number to be used for the logical disc, if the discs are created with the LINKALL command. If this device number equals -1, a randomly selected free IDA/IFP subprocess is used for the logical disc.

Note that this command will destroy a previous description on the disc, and that there must be no logical disc processes created on the physical disc.

C information	repi.		ident TSH840	0706	page 6/13	
			X RC8000		class EXT	
subj.	POST. NO · 31	-D690	L	1		
	KCDL NO JI				and an and a second	
The descript	ion of the	system so	ftware spe	cifies:		
		first segn	ient	no of segm	ents	
IDA801 firmw	are	5		60		
RC8000 bootl	oader	6 5		1		
RC8000 monit	or	66		500		
lst front en	d fw.	566		300		
RC8000 cored	ump	866		500		
dummy file		1366		0		
Example:	initkit 42	2000 43	105000	44 67293	45	
	<i>.</i> . .					
A physical dis	c (with 1/	4293 segme	ents) conne	ected on de	vice	
number 42 are	separated	in three i	logicai dis	scs. Ine fi	rst	
logical disc i	s the auto	ioad disc	with (der)	ned) first	1.0.0	
will be create	d on douig	a size oi	2000 segue	INVAL CON	nand	
is used The c	a on devic	bag first	· cogmont =	2000 and	the	
third disc has	first sea	mant = 200	$- \frac{10500}{100}$. "	LIIE	
CHILD DISC HAS	IIISL SEg	ment - 200	70 F 105000			
	,					

E information	repl.		ident TSH8407	06	page 7/13
			X RC8000		class EXT
CORRECTION T	O RCSL NO.: 31	-D690.		A	
				a da fan an a	
6. Page 31.					
Bottom, inser	:t:				
" Link comman	nd				
Syntax: lir	nk <devno of<="" td=""><th>phys. dis</th><td>c> <first< td=""><td>segment></td><td></td></first<></td></devno>	phys. dis	c> <first< td=""><td>segment></td><td></td></first<>	segment>	
	<number o<="" td=""><th>f segments</th><td>> {<device< td=""><td>no></td><td></td></device<></td></number>	f segments	> { <device< td=""><td>no></td><td></td></device<>	no>	
	<devno of<="" td=""><th>phys. dis</th><td>c> ::= <un< td=""><td>signed num</td><td>ber></td></un<></td></devno>	phys. dis	c> ::= <un< td=""><td>signed num</td><td>ber></td></un<>	signed num	ber>
	<first se<="" td=""><th>gment> ::=</th><td><unsigned< td=""><td>num ber></td><td></td></unsigned<></td></first>	gment> ::=	<unsigned< td=""><td>num ber></td><td></td></unsigned<>	num ber>	
	<number o<="" td=""><th>of segments</th><td>> ::= <uns< td=""><td>igned numb</td><td>er></td></uns<></td></number>	of segments	> ::= <uns< td=""><td>igned numb</td><td>er></td></uns<>	igned numb	er>
	<device n<="" td=""><th>10> ::= <un< th=""><td>signed num</td><td>ber></td><td></td></un<></th></device>	10> ::= <un< th=""><td>signed num</td><td>ber></td><td></td></un<>	signed num	ber>	
The logical	l disc speci	fied in th	e call is	linked on	the
physical (1	IDA) disc.				
First segme	ent of the l	ogical dis.	c must be	specified	
relative to	o the start	of the phy	sical disc	(first se	gment
of physical	l disc = 0).		DA/TED out	areas is	
selected e	no is omitte lse the spec	ified (fre	e IDA/IFP Sub	subproces	s is
used for th	he logical d	lisc.		_F	
Note that	only a RC800)O disc pro	cess is cr	eated; the	disc-
descriptio	n (if any) p	laced on t	he (physic	al) disc i	s not
used.					
Exampl	e: link 40	0 2000	41		
A logical di	sc of 2000 s	segments st	arting in	segment 0	of the
device no Al	c connected	to device	10 40 15 C	ireated usi	14 S
actice no 41	•				

IC info	rmation	repl.		^{ident} TSH840	706	page 8/13				
				X RC8000		class _{EXT}				
subj. CC	ORRECTION TO	RCSL NO.: 31	-D690.		L					
7.	Page 31.									
Dett										
BOTT	iom, insert	•								
" <u>Co</u>	mmand Link	all								
Sy	ntax: link	all <devic< td=""><td>e number></td><td></td><td></td><td></td></devic<>	e number>							
	<d ev<="" td=""><td>ice number</td><td>> ::= <uns< td=""><td>igned numb</td><td>er></td><td></td></uns<></td></d>	ice number	> ::= <uns< td=""><td>igned numb</td><td>er></td><td></td></uns<>	igned numb	er>					
Al	l logical	discs whic	h are desc	ribed in t	he disc de	scrip-				
	lon part, o d (created	r the spec	iried (pny	sical) IDA	-disc, are	1111-				
T f	the catal	og command	s of s sti	ll remain	and a logi	cal				
	isc contain	s a subcat	alog, the	logical di	sc will be	in-				
c	luded in th	e bs-syste	Ξ.							
	Example:	linkall	40							
Note	e that ther	e must be	no logical	discs lin	ked on the					
phys	sical disc.	,	⁰							
1321										
6: 42-1										
RCSL P										

IC in	formation	repi.		^{ident} TSH840)706	page 9/1
				X RC8000		class _{EXT}
subj.	CORRECTION TO	RCSL NO.: 3	1-D690.			and the second se
8	. Page 55.					
B	ottom, insert	::				
44	Command Unl:	ink				
	Syntax: unl:	ink <devic< td=""><td>e number></td><td></td><td></td><td></td></devic<>	e number>			
	(1	dee evente		ianad num	har	
	Kae	vice numbe	r> ::= \un:	igned num	Dely	
	The specifi	ed logical	disc (lin)	ced to an	IDA-disc)	is
	removed. Th	e logical	disc must i	iot be inc	luded in	the bs-
	system.					
	Example:	unlink 41	"			

	information	repl.	repl. ident TSH840706		706	page 10/13
				X RC8000		class EXT
subj.	CORRECTTON TO	RCSL NO.: 3	1-D690.	I		
						ana ang ang ang ang ang ang ang ang ang
· ·						
	9. Page 62.					
	Add the follow	ing error	messages:			
	"connect error	*	an unknown	or illega	1 type of	device
			was specif	ied in the	connect c	ommand
			(see ref.	(b) connec	t device m	es-
			sage).			
	disconnect er	ror*	the specif	ied device	was not a	n
			IDA/IFP de	vice or th	ere still	remain
			logical di	scs on the	specified	IDA-
			disc (see	ref. (6) d	isconnect	device
			message).			
	link error*		device num	ber of phy	eical disc	Was
	IIIR CIIVI		not an IDA	-disc or t	he logical	disc
			could not	be created	(see ref.	(6)
			link logic	al disc me	ssage).	
	unlink error*		the specif	ied disc w	as not a 1	velue
			ded from t	he he-evet	em (gee re	f_{1} (6)
			unlink log	ical disc	message).	1. (0)
					0,	
	disc error*		a read or	write from	/to an IDA	-disc
			was reject	ed (LINKAL	L and INII	KIT
			commands).	(See ref.	(7)).	
	illegal devoc	*	a specifie	d device n	umber was	not an
	IIICEAI UEVIIC		IDA/IFP de	evice or it	was an il	legal
			device num	ber."		
21						
2-1 13						
No: 1						
ACSL						

IC informat	ion repl.	^{ident} TSH840706	page 11/1
		X RC8000	class EXT
ubj. CORRECTI	ON TO RCSL NO.: 31-1	D690.	
10. Page	70.		
Dinch 11	Deploses "WT	ምግ ማታትኩ "የፖርጥ ልም የፖርጥሪክ"	
First II	ne: Replace: <u>Kli</u>	I with <u>KII</u> of <u>KIION</u>	
Next lin	e: Replace: "Syr	ntax : kit" with	
	"Syr	ntax : { kit } " kiton}	
11 Doco	75		
II. rage	<u> </u>		
First li	ne: Replace: "KI	<u>T</u> " with "KIT or KITON"	
Next lin	e: Keplace: Syr "Syr	$\operatorname{htax}: \left\{ \operatorname{kit}_{kit} \right\}$	
		LKILDI	
12. Page	76.		
Remove t	he field ≤no. of	slices> from the KITLABEL	. command.
Number o	f slices is now a	computed as:	
(. i .	a of the logical	disc)//(slice length)	
1912	e of the logical	diddyff (diice iongen)	
Add the	followng error t	ext:	
a		the encodified alies larget	ie too
Slice le small or	the size of the	disc is too large to be d	lescribed
within t	he maximum numbe	r of slices (at present 20)46)).

RCSL No: 42-1 1321

IC information	repi.	repi.		ident TSH840706			
			X RC8000		class EXT		
ubj. CORRECTION	TO RCSL NO.: 31	-D690.					
			<u></u>	<u> </u>	a yang meningkan kanang kan		
13. Page 78	<u>.</u>						
First line:	Replace:	NOKIT wi	ith <u>NOKIT</u> c	r <u>KITOFF</u>			
Next line:	Replace: '	'Syntax :	nokit" with	1			
		'Syntax :(nokit "				
		-					
14. Page 81	•						
Section 3.3	3.1 subsectio	on 3.					
Remove the	last paramet	ter in the	e three kitl	abel comm	ands		
(2045, 2045	5, 1212).						
15. Page 85	5.						
Add the fol	lowing comma	ands to th	ne list:				
" connect	" connect <name mainprocess="" of=""> <type></type></name>				<u>ן</u> 1		
		ormatter/	(unit) ((de	vice no>	ر ا		
disconnec	ct <device m<="" td=""><td>num ber></td><td></td><td></td><td></td></device>	num ber>					
link	<devno o:<="" td=""><td>f phys. d:</td><td>isc> <first< td=""><td>segment></td><td></td></first<></td></devno>	f phys. d:	isc> <first< td=""><td>segment></td><td></td></first<>	segment>			
	<number (<="" td=""><td>of segment</td><td>ts> {<device< td=""><td>$no > \int_{0}^{1}$</td><td></td></device<></td></number>	of segment	ts> { <device< td=""><td>$no > \int_{0}^{1}$</td><td></td></device<>	$no > \int_{0}^{1}$			
unlink	<device (<="" td=""><td colspan="5">(device number)</td></device>	(device number)					
linkall	<device a<="" td=""><td colspan="6"><device number=""></device></td></device>	<device number=""></device>					
			r				
initkit	<devno o:<="" td=""><td>f physical</td><td>l disc> {<si< td=""><td>ze></td><td></td></si<></td></devno>	f physical	l disc> { <si< td=""><td>ze></td><td></td></si<>	ze>			
	<devno o:<="" td=""><td>f logical</td><td>disc></td><td></td><td></td></devno>	f logical	disc>				
			-				
closecato	opr "						

subj.					
subj.				X RC8000	class _{EXT}
	CORRECTIO	N TO RCSL NO.:	31-D690.		an a
	16. Page	86.			
	Replace:	"kit" with "	<pre>kit kiton "</pre>		
	Remove th	e field ≤no	of slices>	from the kitlabe	1 command.
	Replace:	"nokit" with	" { nokit kitoff	}	
	17. Page	99.			
	Add the f	ollowing ref	erences:		
	"(6) RC	SL No 991 09	773:		
	R C	8000/IDA801	Main Proces	s, Reference Man	ual.
	(7) RC	SL No 991 09	775:		
	R C	8000/IDA801	Disc Proces	s, Reference Man	ual."

RCSL No: 42-i 1321