

RCSL: 51-VB474

Author: V. Toft Pedersen

Edited: June 1969

RC 4000 PERIPHERAL DEVICES

AIC401, ANALOG INPUT CONTROLLER

PRELIMINARY SPECIFICATIONS

Abstract

This report describes the logical structure of the AIC401, ANALOG INPUT CONTROLLER when used as ANALOG INPUT UNIT in connection with the RC 4000 computer.

A/S REGNECENTRALEN

Falkoneralle 1

2000 Copenhagen F

MAIN CHARACTERISTICS

The AIC⁴01 Analog Input Controller is connected to the low-speed data channel by means of a buffer register.

It selects the requested analog input channel within max. 102⁴ channels by means of an analog multiplexer, and converts the analog data to digital form by means of a 12-bit A/D-converter. Additionally it selects the requested analog input range, within max. 4 fixed ranges, simultaneously with the channel selection.

AIC⁴01 will always be under remote control.

COMMANDS:

For the AIC⁴01-device the control command and the sense command are available. The value of the modifier-field, bit 18:21 in the effective address of the i/o-instruction is irrelevant as it has no influence on the operation of the device.

1. CONTROL COMMAND:

A control command initiates an analog input operation during which the device is not ready. During the execution of the control command the contents of the working register is transferred to the device buffer register and the value is interpreted as follows:

Bit (0:11): Irrelevant

Bit (12,13): Analog range field where

Bit (12,13) = 00 selects range No. 0 (lowest range)

Bit (12,13) = 01 selects range No. 1

Bit (12,13) = 10 selects range No. 2

Bit (12,13) = 11 selects range No. 3 (highest range)

Bit (14:23): Analog input channel address (integers 0-1023)

The range and channel selection takes place immediately after the transfer of control information, and [130 + 5 : analog range (volts)] microseconds later the analog input operation is finished. This is indicated by the change of the device ready signal from 0 to 1.

2. SENSE COMMAND, STATUS, INTERRUPT:

When an analog input operation is not in progress, a status- and data word may be transferred from the buffer register to a working register by means of a sense command.

The contents of the buffer register has the following meaning:

- Bit (0): Not used (= 0)
- Bit (1): Parity error
- Bit (2:11): Not used (= 0)
- Bit (12:23): Converted analog value (A/D value)

Converted analog value is given as a signed integer where the numerical value 2048 corresponds to a full scale analog input signal.

Parity error = 1 if an overload condition has been present during the preceding analog input operation.

When an overload condition occurs, it may not be possible to achieve valid A/D values within the following 50 milliseconds. Due to this a 50-millisecond timer in the device is started as soon as an overload is detected. This time interval is terminated by an interrupt signal, indicating that the device is available for valid analog input operations.